#### **VE320 – Summer 2022**

#### **Introduction to Semiconductor Devices**

Instructor: Yaping Dan (但亚平) yaping.dan@sjtu.edu.cn

Chapter 5 Carrier Transport Phenomena

## Outline


#### 5.1 Carrier drift

- 5.2 Carrier diffusion
- 5.3 Graded impurity distribution

#### **Drift current density**

#### Drift current

$$I_{drf} = \frac{\Delta Q}{\Delta t} = \frac{q p_0 A_c \Delta L}{\Delta t} = q p_0 A_c v_d$$



for p type semiconductor,  $p_0 \gg n_0$ 


$$I_{drf} = \frac{\Delta Q}{\Delta t} = \frac{q p_0 \Delta L A_c}{\Delta t} = \frac{p_0 q v_d A_c}{\Delta t}$$
 (p: charge density)  $n_0 = N_c \times \frac{1}{4 e^{-\frac{1}{2}}}$ 

# 5.1 Carrier drift (current in an ideal case)

### **Drift current density**

#### Drift current

$$I_{drf} = \frac{\Delta Q}{\Delta t} = \frac{q p_0 A_c \Delta L}{\Delta t} = q p_0 A_c v_d$$



$$\rho$$
: charge density

$$I_{drf} = \frac{\Delta Q}{\Delta t} = \frac{q p_0 \Delta L A_c}{\Delta t} = \frac{p_0 q v_d A_c}{\Delta t}$$

$$I_{drf} = \frac{\Delta Q}{\Delta t} = \frac{q p_0 \Delta L A_c}{\Delta t} = p_0 q v_d A_c$$

$$L = \frac{1}{2} a t^2 \rightarrow t = \sqrt{2L/a}$$

$$\rightarrow V Q = a t = \sqrt{2La} = \sqrt{2Lq E/m_{cp}^*}$$


$$E = V/L \rightarrow Q = \sqrt{2qV/m_{cp}^*}$$


$$\therefore I_{drf} = q p_0 \sqrt{2qV/m_{cp}^*} A_c \qquad However, Ohm's Law tells us  $I = Q \cdot V$$$

$$\Rightarrow \sqrt{q} = at = \sqrt{2La} = \sqrt{2LqE/m_{cp}^*}$$

$$\therefore I_{drf} = qp_0 \sqrt{2qV/m_{cp}^*} A_c$$


$$\therefore I_{drf} = qp_0 \sqrt{2qV/m_{cp}^* A_c} \quad However, Ohm's Law tells us (I) = \sigma \cdot V$$





m.a=F=2.E


# 5.1 Carrier drift (phonons and scatterings)



Thermal vibrations of lattice are phonons

#### **Scatterings** include:

- Electrons scatter with phonons
- Electrons scatter with Impurities





#### **Drift current density**

Hole drift current density

Electron drift current done to

$$J_{p_{\parallel}drf} = qp_0\mu_p E$$

$$J_{n_{\parallel}drf} = q n_0 \mu_n E$$

Both electrons and holes contribute to current:


$$J_{drf} = q(p_0\mu_p + n_0\mu_n)E$$


Table 5.1 | Typical mobility values at T = 300 K and low doping concentrations

	$\mu_n$ (cm <sup>2</sup> /V-s)	$\mu_p  (\text{cm}^2/\text{V-s})$
Silicon	1350	480
Gallium arsenide	8500	400
Germanium	3900	1900

#### **Mobility effect**

Why are resistors heated up by current?





Energy Scatterings →

(hot)


- Slow down electrons
- Reduce electron mobility

Lattice vibrations (hot)


#### **Conclusions:**

- Higher doping concentration → lower mobility
- Higher Temperature → lower mobility

<u>Mobility effect</u>: higher T and higher doping → lower mobility



#### **Conductivity**




For n-type doped semiconductor:

$$\rho = \frac{1}{\sigma} = \frac{1}{q\mu_n n} = \frac{1}{q\mu_n N_d}$$


For p-type doped semiconductor:

$$\rho = \frac{1}{\sigma} = \frac{1}{q\mu_n p} = \frac{1}{q\mu_n N_a}$$






### 5.1 Carrier drift (conductivity dependent on temperature)



## Velocity saturation

$$\frac{1}{2}mv_{th}^2 = \frac{3}{2}kT = 0.03885eV (300K)$$



 $\Rightarrow$  thermal velocity  $v_{th} \approx 10^7$  cm/s

Drift velocity 
$$v_d = \mu_n E = V_{th}$$

$$\Rightarrow E = \frac{v_{di}}{\mu_n} = \frac{10^7 cm/s}{1350 cm^2/(Vs)} = \frac{7 \times 10^3 V/cm}{1350 cm^2/(Vs)}$$






#### **Velocity saturation**

$$v_d \rightarrow v_{th}$$

- Electric field is heating up electrons
- Electrons transfer energy to lattice to reach thermal equilibrium



$$v_n = \frac{v_s}{\left[1 + \left(\frac{E_{on}}{E}\right)^2\right]^{1/2}}$$


$$v_p = \frac{v_s}{\left[1 + \left(\frac{E_{op}}{E}\right)^2\right]^{\frac{1/2}{2}}}$$

Probably a typo in textbook

# Check your understanding

#### Problem Example #1

A bar of p-type silicon at 300K in the figure below has a cross-sectional area  $A = 10^{-6}$  cm<sup>2</sup> and a length  $L = 1.2 \times 10^{-3}$  cm. For an applied voltage of 5V, a current of 2mA is required. What is the required (a) resistance, (b) resistivity, and (c) impurity doping concentration? (d) What is the resulting hole mobility?





## Outline

5.1 Carrier drift

#### 5.2 Carrier diffusion


5.3 Graded impurity distribution





Flux F: number of particles passing through a unit area per second





#### **Diffusion current density**

Electron diffusion current density: 
$$J_{nx|dif} = -qF_n = qD_n \frac{dn}{dx}$$

 $D_n$  is called the electron diffusion coefficient

Hole diffusion current density: 
$$J_{px|dif} = qF_p = -qD_p \frac{dp}{dx}$$

D<sub>p</sub> is called the hole diffusion coefficient

### Total current density

#### Problem Example #2


The hole density in silicon is given by  $p(x) = 10^{16} \exp(-x/L_p)$  ( $x \ge 0$ ) where  $L_p = 2 \times 10^{-4}$  cm. Assume the hole diffusion coefficient is  $D_p = 8 \text{cm}^2/\text{s}$ . Determine the hole current density at  $x = 2 \times 10^{-4}$  cm.

$$J_{p|diff} = -qD_p \frac{dp}{dx}$$


## Outline


- 5.1 Carrier drift
- 5.2 Carrier diffusion
- **5.3** Graded impurity distribution

#### Induced electric field





• Induced electric field





• The Einstein relation





• The Einstein relation

# Chenk your understanding

#### Problem Example #3

Assume the donor concentration in an n-type semiconductor at T =300K is given by  $N_d(x) = 10^{16} exp(-x/L)$  where  $L = 2 \times 10^{-2}$  cm. Determine the induced electric field and drift current density in the semiconductor at  $x = 2 \times 10^{-2}$  cm. Note  $\mu_n \approx 1350 \text{ cm}^2/\text{Vs}$  and  $1200 \text{ cm}^2/\text{Vs}$  near the doping concentration of 3.68 x  $10^{15} \text{ cm}^{-3}$  and  $10^{16} \text{ cm}^{-3}$ , respectively.

$$E_{x} = \frac{1}{q} \frac{kT}{n(x)} \frac{dn(x)}{dx}$$