| Number of valance electrons of atom used to dope p type semi conductor          |
|---|
| Number of valance electrons of atom used to dope p type semi conductor          |
| 3   |
|   |
| List of examples of trivalent impurity used to dope p type semi conductor       |
| • Aluminium   |
| • Boron   |
|   |
| List of activities at formation of p type semi conductors                       |
| Form 3 covalent bonds with semi conductor by impurity                           |
| Form hole at one bond   |
|   |
| Number of covalent bonds formed by impurity with semi conductors in p type semi |
| conductor   |
| 3   |
|   |
| Majority charge carriers at p type semi conductors                              |
| Holes   |
|   |
| Minority charge carriers at n type semi conductors                              |
| Free electrons  |
|   |
|   |
|   |