

# Custom Bootloader Options via One-Time Programmable (OTP) Memory

Christine Peng and Hareesh Janakiraman

## **ABSTRACT**

The *Boot to One-Time-Programmable (OTP)* memory mode in the TMS320x280x devices provides the necessary hooks to support custom bootloaders. This is very useful in a situation where a bootloader option, required by a specific customer application, is not already supported as one of the *built-in* options in the Boot read-only memory (ROM). This application report includes information and examples on how to program a custom bootloader and boot via the OTP memory.

Project collateral and source code discussed in this application report can be downloaded from the following URL: http://www-s.ti.com/sc/techlit/spraaq3.zip

## Contents 2 3 4 Conclusion 4 References 4 **List of Tables** 1 SPI Serial Memory Bootloader Files Used in This Application Report ...... 5 A-1 A-2

## 1 Introduction

The current TMS320x280x Boot ROM supports a limited number of Boot mode options. If other Boot modes are desired, it is possible to program the custom Boot code to OTP and then select the *Boot to OTP* option with the appropriate general-purpose input/output (GPIO) pins. Sample Boot code software, which can be programmed into the OTP, is provided with this application report. The provided sample Boot code software allows you to:

- Boot from both 16-bit and 24-bit addressable electrically erasable programmable read-only memory (EEPROM) and/or Serial Flash.
- Boot properly through the eCAN interface as a workaround to the errata mentioned in the TMS320F280x, TMS320C280x, and TMS320F2801x DSP Silicon Errata (SPRZ171).

This application report explains the process of programming a custom bootloader into OTP and then booting to OTP. As an example, the sample 16/24-bit addressable Serial bootloader code is used to demonstrate the process. Although the examples and text in this application report refer to the TMS320x280x generation of devices, they apply to any C2000™ DSP device with a *Boot to OTP* mode in the Boot ROM.

C2000, Code Composer Studio are trademarks of Texas Instruments. Atmel is a registered trademark of Atmel Corporation or its subsidiaries. All other trademarks are the property of their respective owners.



## 2 Programming the OTP With a Custom Bootloader

This section demonstrates the steps required to configure your custom bootloader code for *Boot to OTP* mode and how to program the OTP. For example purposes, the steps are catered to the TI custom serial bootloader provided with this application report. For your own custom bootloader, other modifications can be required.

1. Include the common Boot ROM files in the project.

## Source Files:

Init\_Boot.asm – This file manages the bootloader stack pointer and calls the custom Boot code. For
this particular example, it calls the SPI\_Boot() function located in SPI\_Boot.c. You can change the
following lines in Init\_Boot.asm to fit the Boot function in your custom bootloader.

```
ref _SPI_Boot ; refers to SPI_Boot() in SPI_Boot.c
LCR _SPI_Boot
```

- Shared\_Boot.c This file includes shared functions used by the normal TI Boot ROM code to move
  data via the peripheral. You can choose to use these functions or create your own.
- Your custom bootloader code (SPI\_Boot.c, for purposes of this example).

## Other:

- 280x\_Boot.h Included in the project via #include in source files This file includes specific
  defines used by Shared\_Boot.c and SPI\_Boot.c. If you do not use these defines in your custom
  bootloader, this include is unnecessary.
- 280x header files, specifically:
  - DSP280x GlobalVariableDefs.c
  - DSP280x\_Headers\_nonBIOS.cmd
  - The previous two files, in conjunction with the 280x header files, automatically ensure the appropriate header and source files are included for those peripherals specific to your bootloader.

For more information on including header files, see the DSP280x/2801x Header Files Quick Start Readme packaged with the 280x header files.

2. Configure a linker command file to link the bootloader code to OTP and add it to the project.

Generate a linker command file, as follows, such that all code (.text) is linked to OTP memory (280x\_boot\_rom\_lnk.cmd in the included examples) . The stack and static variables are located in M1 memory at location 0×400, where the normal Boot ROM stack and static variables are stored.

Note that the .InitBoot code section is linked to the beginning of OTP memory at 0×3D7800, while the rest of the code is linked to subsequent memory. This ensures that when *jump to OTP* occurs at 0×3D7800, the appropriate code is executed first (in this case, the Init\_Boot.asm file). Include this .cmd linker file in your project.

```
MEMORY
PAGE 0 :
     SPIBOOTINIT : origin = 0x3D7800, length = 0x000020
     SPIBOOT : origin = 0x3D7820, length = 0x000200
PAGE 1:
                 : origin = 0x400, length = 0x002
                : origin = 0x402, length = 0x200
        STACK
}
SECTIONS
{
        .InitBoot : load = SPIBOOTINIT, PAGE = 0
        .text : load = SPIBOOT, PAGE = 0
        .stack
                    : load = STACK,
                                         PAGE = 1
                    : load = EBSS,
        .ebss
                                          PAGE = 1
}
```



3. Set the required jumpers for the *Boot to OTP* mode.

The required jumper settings for each Boot mode are shown in Table 1.

Table 1. 280x Boot Mode Settings

GPIO18	GPIO29	GPIO34	Mode
1	1	1	Boot to flash 0x3F7FF6
1	1	0	Call SCI-A bootloader
1	0	1	Call SPI-A bootloader
1	0	0	Call I2C bootloader
0	1	1	Call eCAN-A bootloader
0	1	0	Boot to M0 SARAM 0×000000
0	0	1	Boot to OTP 0×3D7800
0	0	0	Call parallel bootloader

For more detailed information regarding configuring the Boot mode selection pins, see the device-specific documentation for your hardware platform.

For more information on the 280x Boot modes, see the device-specific Boot ROM Reference Guide.

4. Program the device with the built code.

This can be done by using the SDFlash tool available from Spectrum Digital's website (www.spectrumdigital.com). In addition, the C2000™ on-chip Flash programmer plug-in for the Code Composer Studio™ can also be used.

These tools are updated to support new devices as they become available. Please check for updates.

5. Debug the information. Load the project in Code Composer Studio by selecting File -> Load Symbols -> Load Symbols Only

It is useful to load only the symbol information when working in a debugging environment where the debugger cannot or need not load the object code, such as when the code is in ROM or Flash. This operation loads the symbol information from the specified file.

#### 3 **TI-Provided Custom Bootloaders**

In conjunction with the application report, TI has included two custom bootloaders for the TMS320x280x, which are discussed in this section.

#### TMS320x280x Custom Serial Flash Bootloader 3.1

The current serial peripheral interface (SPI) bootloader in the Boot ROM boots from 16-bit addressable SPI Serial EEPROM. There is currently no solution available if an application requires the device to Boot from 24-bit addressable memory.

To remedy this, Texas Instruments has provided the bootloader code, which can be programmed into the OTP memory on 280x devices. The /f280x otp2spi boot rom directory, in the included software package, includes all of the project code and source files required to boot from either 16-bit or 24-bit addressable serial memories.

Note: The code is provided as-is and has been tested on Atmel® SPI Serial EEPROMs (AT25HP256/512 and AT25128/256A) and Atmel 1Mb high-speed SPI Serial Flash memory (AT25F1024A). The functions can be modified to support other memories, if necessary or desired.

For information on how the original SPI-A bootloader functions, see the TMS320x280x, 2801x, 2804x Boot ROM Reference Guide (SPRU722). The SPI bootloader included in the software package has been modified slightly from the original SPI-A bootloader to support 24-bit addressable serial memories.



In the modified custom serial bootloader, after the SPI-A outputs a READ command for the serial memory, it no longer sends only 2 bytes of 0×00's (16-bits), indicating a starting address of 0×0000 for a downloadable packet. Instead, it performs the following steps:

- 1. SPI-A sends three bytes of 0×00's (24-bits) indicating a starting address of 0×000000 for a downloadable packet from the serial memory.
- 2. The bootloader fetches a byte of data while the SPI-A transmits the third 0×00 (the SPI receives data while it transmits), and checks to see if the received data byte is the least significant bit (LSB) of the key value (0×08AA).
  - a. If the data equals 0×AA, the memory is 16-bit addressable (after sending two bytes of 0×00's, the key value is received), and the bootloader fetches one more data byte to check for an 0×08 to ensure the entire key value is correct.
  - b. If the data does not equal 0×AA, it is assumed the memory is 24-bit addressable. Three bytes of 0×00's must be sent before the key value is received. The bootloader fetches two more bytes and checks to see that they match the 0×08AA key value for an 8-bit stream.
- The rest of the SPI bootloader functions exactly as the original SPI Boot ROM code in the 280x devices. For more information, see the TMS320x280x, 2801x, 2804x Boot ROM Reference Guide (SPRU722).

## 3.2 TMS320x280x Custom eCAN Bootloader

As noted in the *TMS320F280x, TMS320C280x, and TMS320F2801x DSP Silicon Errata* (SPRZ171), the eCAN-A boot mode in the current Boot ROM does not work as intended due to a 16-bit R/W employed to check the status of the CCE bit. The boot code has been fixed, and can be programmed into the OTP memory for *Boot to OTP mode*.

The fixed eCAN bootloader project code can be found in the <code>/f280x\_otp2can\_boot\_rom</code> directory of the included software package. After the bootloader is programmed into the OTP and the GPIO pins are configured for <code>Boot</code> to <code>OTP</code> mode, the device can boot from the eCAN-A peripheral via the OTP bootloader the same way it would if the eCAN-A bootloader were in Boot ROM.

For more information on how the eCAN-A bootloader functions, see the *TMS320x280x*, 2801x, 2804x Boot ROM Reference Guide (SPRU722).

## 4 Conclusion

Booting from a custom bootloader via OTP is a solution for those bootloader options not provided by TI in the Boot ROM code. Two examples have been explained in this application report and included in the attached software package as building blocks for you to begin generating your own custom bootloader. Although this application report specifically targets the TMS320x280x generation of devices, the same general tips can be used for other devices with on-chip OTP memory and a *Boot to OTP* option with minor modifications.

## 5 References

- TMS320x280x, 2801x, 2804x Boot ROM Reference Guide (SPRU722)
- TMS320F280x, TMS320C280x, and TMS320F2801x DSP Silicon Errata (SPRZ171)
- Spectrum Digital's website (www.spectrumdigital.com)



# **Appendix A Code Listing**

# A.1 Common Files

The application code's projects consists of the files shown in Table A-1 and Table A-2. This project collateral and source code can be downloaded from the following URL: <a href="http://www-s.ti.com/sc/techlit/spraaq3.zip">http://www-s.ti.com/sc/techlit/spraaq3.zip</a>

Table A-1. SPI Serial Memory Bootloader Files Used in This Application Report

Filename	Contents		
DSP280x_headers	The DSP280x header files which are utilized by the bootloader code		
Init_Boot.asm	280x Boot ROM initialization and exit routines		
Shared_Boot.c	280x bootloader shared functions		
SPI_Boot.c	280x 16/24-bit addressable SPI boot mode routines		
F280x_Boot.h	F280x Boot ROM definitions		
f280x_otp2spi_boot_rom.pjt	16/24-bit addressable SPI bootloader project file		
F280x_boot_rom_lnk.cmd	F280x Boot ROM linker command file		

Table A-2. eCAN-A Bootloader Files Used in This Application Report

Filename	Contents	
DSP280x_headers	The DSP280x header files which are utilized by the bootloader code	
Init_Boot.asm	280x Boot ROM initialization and exit routines	
CAN_Boot.c	280x CAN boot mode routines	
Shared_Boot.c	280x bootloader shared functions	
F280x_Boot.h	F280x Boot ROM definitions	
f280x_otp2can_boot_rom.pjt	280x CAN bootloader project file	
F280x_boot_rom_lnk.cmd	F280x Boot ROM linker command file	

## **IMPORTANT NOTICE**

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its hardware products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by government requirements, testing of all parameters of each product is not necessarily performed.

TI assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using TI components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any TI patent right, copyright, mask work right, or other TI intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information published by TI regarding third-party products or services does not constitute a license from TI to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of TI information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. Reproduction of this information with alteration is an unfair and deceptive business practice. TI is not responsible or liable for such altered documentation. Information of third parties may be subject to additional restrictions.

Resale of TI products or services with statements different from or beyond the parameters stated by TI for that product or service voids all express and any implied warranties for the associated TI product or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

TI products are not authorized for use in safety-critical applications (such as life support) where a failure of the TI product would reasonably be expected to cause severe personal injury or death, unless officers of the parties have executed an agreement specifically governing such use. Buyers represent that they have all necessary expertise in the safety and regulatory ramifications of their applications, and acknowledge and agree that they are solely responsible for all legal, regulatory and safety-related requirements concerning their products and any use of TI products in such safety-critical applications, notwithstanding any applications-related information or support that may be provided by TI. Further, Buyers must fully indemnify TI and its representatives against any damages arising out of the use of TI products in such safety-critical applications.

TI products are neither designed nor intended for use in military/aerospace applications or environments unless the TI products are specifically designated by TI as military-grade or "enhanced plastic." Only products designated by TI as military-grade meet military specifications. Buyers acknowledge and agree that any such use of TI products which TI has not designated as military-grade is solely at the Buyer's risk, and that they are solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI products are neither designed nor intended for use in automotive applications or environments unless the specific TI products are designated by TI as compliant with ISO/TS 16949 requirements. Buyers acknowledge and agree that, if they use any non-designated products in automotive applications, TI will not be responsible for any failure to meet such requirements.

Following are URLs where you can obtain information on other Texas Instruments products and application solutions:

	Applications	
amplifier.ti.com	Audio	www.ti.com/audio
dataconverter.ti.com	Automotive	www.ti.com/automotive
dsp.ti.com	Broadband	www.ti.com/broadband
interface.ti.com	Digital Control	www.ti.com/digitalcontrol
logic.ti.com	Military	www.ti.com/military
power.ti.com	Optical Networking	www.ti.com/opticalnetwork
microcontroller.ti.com	Security	www.ti.com/security
www.ti-rfid.com	Telephony	www.ti.com/telephony
www.ti.com/lpw	Video & Imaging	www.ti.com/video
	Wireless	www.ti.com/wireless
	dataconverter.ti.com dsp.ti.com interface.ti.com logic.ti.com power.ti.com microcontroller.ti.com www.ti-rfid.com	amplifier.ti.com  dataconverter.ti.com  dsp.ti.com  interface.ti.com  logic.ti.com  power.ti.com  microcontroller.ti.com  www.ti-rfid.com  www.ti-com/lpw  Audio  Automotive  Broadband  Digital Control  Military  Optical Networking  Security  Telephony  Video & Imaging

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265 Copyright © 2007, Texas Instruments Incorporated