

# 2-1. PREPARATION.

- 1. Review "Section 1 (General Information)" of this TO for system general warnings, cautions, and notes.
- 2. Review task "Functional Input Conditions" page for task specific safety conditions.
- 3. Attach warning tag to PITCH TRIM switch on FCS ACTR panel.




ICN-88277-G2742030-002-01

4. Attach warning tag to **STAB TRIM** handles.



ICN-88277-G2742031-004-01


- 5. Enter vertical stabilizer (00-00-02, task 02-1).
- 6. Install rig pin 5-3 in cable control crank.



ICN-88277-G2742032-003-01


# 2-2. REMOVAL FOR 2742MP061 AND 2742MP062.

- 1. Remove cotter pin, nut, washers, and bolt.
- 2. Remove cotter pin, nut, washers, and bolt.
- 3. Remove nut, washers, bolt, and pitch trim stabilizer control valve crank assembly.



# 2-3. REMOVAL FOR 2742MP065 AND 2742MP066.

- 1. Remove cotter pin, nut, washers, bushings, and bolt.
- 2. Remove nut, washers, bolt and pitch trim stabilizer control valve crank assembly.



27-42-12-2 2-101/(2-102 blank)

# PITCH TRIM STABILIZER CONTROL VALVE CRANK ASSEMBLY INSTALLATION (27-42-12-3)

# **FUNCTIONAL INPUT CONDITIONS:**

Applicability:	Task
All	All
Additional information:	
This procedure consists of the following tasks:	
<ul><li>3-1. Installation for 2742MP061 and 2742MP062.</li><li>3-2. Installation for 2742MP065 and 2742MP066.</li><li>3-3. Follow-on maintenance.</li></ul>	
Additional data:	Task
TO 1300i-2-00JG-00-1	3-3
TO 1300i-2-27JG-40-1	3-3
TO 1300i-2-27JG-40-6	3-3
TO 1300i-23	3-1, 3-2
Personnel recommended:	Task
One	All
Safety conditions:	Task
NA	


# Support equipment:

	Nomenclature	<u>PN</u>	<u>Specification</u>	Qty	<u>Task</u>
1	NA				
	Supplies:				
	<u>Nomenclature</u>	<u>PN</u>	<u>Specification</u>	Qty	<u>Task</u>

<u>Nomenclature</u>	<u>PN</u>	<u>Specification</u>	Qty	<u>Task</u>
Pin, Cotter	MS24665-151		2	3-1
Pin, Cotter	MS24665-151		1	3-2
Sealant	PR-1775	AMS 3265	AR	3-1, 3-2


# 3-1. INSTALLATION FOR 2742MP061 AND 2742MP062.

- 1. Review "Section 1 (General Information)" of this TO for system general warnings, cautions, and notes.
- 2. Review task "Functional Input Conditions" page for task specific safety conditions.
- 3. Perform wet fastener installation (TO 1300i-23, Chapter 1, Section III).
- 4. Position pitch trim stabilizer control valve crank assembly and install bolt, washers, and nut.
- 5. Install bolt, washers, nut, and cotter pin.
- 6. Install bolt, washers, nut, and cotter pin.




# 3-2. INSTALLATION FOR 2742MP065 AND 2742MP066.

- 1. Review "Section 1 (General Information)" of this TO for system general warnings, cautions, and notes.
- 2. Review task "Functional Input Conditions" page for task specific safety conditions.
- 3. Perform wet fastener installation (TO 1300i-23, Chapter 1, Section III).
- 4. Position pitch trim stabilizer control valve crank assembly and install bolt, washers, and nut.
- 5. Install bolt, washers, bushings, nut, and cotter pin.




# 3-3. FOLLOW-ON MAINTENANCE.

- 1. Perform pitch trim vertical stabilizer crank assemblies to stabilizer control valve crank assemblies adjustment (27-42-01, task 01-4).
- 2. Remove rig pin 5-3 from cable control crank.
- 3. Exit vertical stabilizer (00-00-02, task 02-8).




ICN-88277-G2742039-004-01

4. Remove warning tag from **STAB TRIM** handles.



ICN-88277-G2742038-004-01

- 5. Remove warning tag from **PITCH TRIM** switch on **FCS ACTR** panel.
- 6. Perform horizontal stabilizer position sensor operational checkout (27-45-11, task 1-1).



ICN-88277-G2742037-002-01