TECHNICAL MANUAL

JOB GUIDE ORGANIZATIONAL MAINTENANCE

FLIGHT CONTROLS HORIZONTAL STABILIZER

(27-40-00 AND 27-42-13)

300i
AIRCRAFT

MCDONNELL DOUGLAS CORPORATION
MILITARY TRANSPORT AIRCRAFT
F33657-81-C-2108
FA8526-21-D-0001

THIS MANUAL SUPERSEDES TO 1300i-2-27JG-40-3 DATED 1 JULY 2019.

<u>DISCLOSURE NOTICE</u> - This information is furnished upon the condition that it will not be released to another nation without the specific authority of the Department of the Air Force of the United States; that it will be used for military purposes only; that individual or corporate rights originating in the information, whether patented or not, will be respected; that the recipient will report promptly to the United States, any known or suspected compromise; and that the information will be provided substantially the same degree of security afforded it by the Department of Defense of the United States. Also, regardless of any other markings on the document, it will not be downgraded or declassified without written approval of the originating United States agency.

<u>DISTRIBUTION STATEMENT D</u> - Distribution authorized to the Department of Defense and U.S. DoD contractors only; (Administrative and Operational Use); (12 May 2001). Other requests for this documentation shall be referred to AFLCMC/WLM, Robins AFB, GA 31098-2428.

<u>WARNING</u> - This document contains technical data whose export is restricted by the Arms Export Control Act (Title 22, U.S.C., Sec. 2751 et seq.) or the Export Administration Act of 1979 (Title 50, U.S.C., App. 2401 et seq.), as amended. Violation of these export laws are subject to severe criminal penalties. Disseminate in accordance with provisions of DoD Directive 5230.25.

Basic and all changes have been merged to make this a complete publication.

Published under authority of the Secretary of the Air Force

1 JULY 2022

HANDLING AND DESTRUCTION NOTICE - Comply with distribution statement and destroy by any method that will prevent disclosure of the contents or reconstruction of the document.

INSERT LATEST CHANGED PAGES. DESTROY SUPERSEDED PAGES.

LIST OF EFFECTIVE PAGES

NOTE: The portion of the text affected by the changes is indicated by a vertical line in the outer margins of the page. Changes to illustrations are indicated by miniature pointing hands.

Dates of issue for original and changed pages are:

Original 0 1 Jul 22

TOTAL NUMBER OF PAGES IN THIS PUBLICATION IS 212 CONSISTING OF THE FOLLOWING:

Page No.	* Change No.	Page No.	* Change No.
Title thru T-2			
	•		

*Zero in this column indicates an original page.

TABLE OF CONTENTS

SECTION	TO NO.	S/S/SN or PAGE
INTRODUCTION		
Scope		iii
Model(s) covered		iii
Abbreviations		iii
Change request		iii
300i TO informatio	n	. iii
List of Time Complian	nce Technical Orders (TCTO)	iv
1. GENERAL INFORM	ATION (27-40-00)	
General information	on	1-1
General warnings,	, cautions, and notes	1-1
2. MAINTENANCE INS	STRUCTIONS	
Cable assembly (2	2742MP003 thru	
2742MP014)		27-42-13

INTRODUCTION

SCOPE.

This job guide provides maintenance procedures for the removal of horizontal stabilizer components.

MODEL(S) COVERED.

All

ABBREVIATIONS.

The following is a list of non-standard abbreviations used throughout this manual:

STA Station

CHANGE REQUEST.

Recommended changes to this manual shall be submitted in accordance with TO 00-5-1.

300i TO INFORMATION.

General 300i TO/eTO, TO Manager, Supplement and finalized Recommended Change (RC) information can be found in the Enhanced Technical Information Management System (ETIMS), System of Record.

LIST OF TIME COMPLIANCE TECHNICAL ORDERS (TCTO).

This list of TCTO's contains all current TCTO's that affect the technical content of text or illustrations found in this manual.

TCTO NUMBER	TITLE	TCTO DATE	APPLICABILITY

SECTION 1

GENERAL INFORMATION (27-40-00)

1-1. GENERAL INFORMATION.

- 1-2. This section provides general information that is essential for ensuring complete and safe maintenance procedures contained throughout this job guide manual.
- 1-3. All adhesive sealants, sealants, and compounds used in this manual are listed with a primary part number and/or primary specification number. Any suitable substitutes and/or interchangeable adhesive sealants, sealants, and compounds may be used unless otherwise specified. Suitable substitutes and/or interchangeable adhesive sealants, sealants, and compounds are listed in the system peculiar corrosion control manual (Refer to TO 1300i-23, Chapter 1, Section III).
- 1-4. Flight control surfaces are to be cleared prior to turning off hydraulic auxiliary pumps from the loadmaster control panel. Flight control surface movement may occur.

1-5. GENERAL WARNINGS, CAUTIONS, AND

NOTES.

WARNING

All flight control surfaces and thrust reversers shall be clear of personnel and equipment prior to applying or removing hydraulic power. Failure to comply may cause injury to personnel and damage to aircraft.

SECTION 2

CABLE ASSEMBLY (27-42-13)

MASTER INPUT CONDITIONS:


Reference designators:

2742MP003	Cable Assembly
2742MP004	Cable Assembly
2742MP005	Cable Assembly
2742MP006	Cable Assembly
2742MP007	Cable Assembly
2742MP008	Cable Assembly
2742MP009	Cable Assembly
2742MP010	Cable Assembly
2742MP011	Cable Assembly
2742MP012	Cable Assembly
2742MP013	Cable Assembly
2742MP014	Cable Assembly


Applicable functions:


-2 Removal.

Access data:





ICN-88277-G2742060-004-01





ICN-88277-G2742062-003-01





ICN-88277-G2742433-001-01

CABLE ASSEMBLY REMOVAL (27-42-13-2)

FUNCTIONAL INPUT CONDITIONS:

Аррисавшіту:	Task
All	All

Additional information:

This procedure consists of the following tasks:

- Preparation for cable run 29A, REF DES 2742MP003, and cable run 30A, REF DES 2742MP004.
- Preparation for cable run 31A, REF DES 2742MP005, and cable run 32A, REF DES 2742MP006.
- 2-3. Preparation for cable run 29B, REF DES 2742MP007, cable run 30B, REF DES 2742MP008, cable run 31B, REF DES 2742MP009, cable run 32B, REF DES 2742MP010, cable run 31C, REF DES 2742MP011, cable run 30C, REF DES 2742MP012, cable run 29C, REF DES 2742MP013, and cable run 32C, REF DES 2742MP014.
- 2-4. Removal for cable run 29A, REF DES 2742MP003.
- 2-5. Removal for cable run 30A, REF DES 2742MP004.
- 2-6. Removal for cable run 31A, REF DES 2742MP005.
- 2-7. Removal for cable run 32A, REF DES 2742MP006.
- 2-8. Removal for cable run 29B, REF DES 2742MP007.
- 2-9. Removal for cable run 30B, REF DES 2742MP008.
- 2-10. Removal for cable run 31B, REF DES 2742MP009.
- 2-11. Removal for cable run 32B, REF DES 2742MP010.
- 2-12. Removal for cable run 29C, REF DES 2742MP013.
- 2-13. Removal for cable run 30C, REF DES 2742MP012.
- 2-14. Removal for cable run 31C, REF DES 2742MP011.
- 2-15. Removal for cable run 32C, REF DES 2742MP014.

Additional data:

	Task
ГО 1300i-2-00JG-00-1	2-1,
	2-2,

2 - 3

Personnel recommended:

Task

Two

All

Person (A) performs task.

Person (B) assists person (A).

Safety conditions:

Task

NA --

Support equipment:

	Nomenclature	<u>PN</u>	Specification	<u>Qty</u>	<u>Task</u>
	Kit, Rig Pin	17G140015-1			
	Assembly, Clamp	17G140015-7		1	2-4, 2-5, 2-6, 2-7, 2-12, 2-13, 2-14, 2-15
.	Assembly, Clamp	17G140015-7		2	2-8, 2-9, 2-10, 2-11
í	Pin 5-3, Rig	17G140015-31		2	2-1, 2-2, 2-3
	Pin 5-8, Rig	17G140015-15		1	2-1, 2-2


<u>Nomenclature</u>	<u>PN</u>	Specification	Qty	<u>Task</u>	TO
Tool, Turnbuckle Adjustment	17G140019-1		1	2-4, 2-5, 2-6, 2-7, 2-8, 2-9, 2-10, 2-11, 2-12, 2-13, 2-14	1300i-2-27JG-40-3

Supplies:

<u>Nomenclature</u>	<u>PN</u>	<u>Specification</u>	Qty	<u>Task</u>
Cord, Nylon Utility	300NOR17NAT		50 ft	2-4, 2-5, 2-6, 2-7, 2-8, 2-9, 2-10, 2-11, 2-12, 2-13, 2-14
Tag, Warning			2	2-1, 2-2, 2-3


2-1. PREPARATION FOR CABLE RUN 29A, REF DES 2742MP003, AND CABLE RUN 30A, REF DES 2742MP004.

- 1. Review "Section 1 (General Information)" of this TO for system general warnings, cautions, and notes.
- 2. Review task "Functional Input Conditions" page for task specific safety conditions.
- 3. (A) Set **PITCH TRIM** switch on **FCS ACTR** panel to **MECH** and attach warning tag.




ICN-88277-G2742063-003-01

4. (A) Attach warning tag to **STAB TRIM** handles.




ICN-88277-G2742064-003-01

- 5. Enter vertical stabilizer (00-00-02, task 02-1).
- 6. (A) Install rig pins 5-3 in cable crank assemblies.




ICN-88277-G2742065-005-01

- 7. $\langle \overline{AA} \rangle \rightarrow \langle \overline{CJ} \rangle$ (A) Loosen fasteners and remove cover assembly (212AZC).
- 7. $\langle \overline{CK} \rangle \rightarrow$ (A) Loosen fasteners and remove panel assembly (212AZP).
- 8. $\langle \overline{AA} \rangle \rightarrow \langle \overline{CJ} \rangle$ (A) Loosen fasteners and remove cover assembly (212BZC).
- 8. $\langle \overline{CK} \rangle \rightarrow$ (A) Loosen fasteners and remove panel assembly (212BZP).




ICN-88277-G2742409-002-01

9. (A) Install rig pin 5-8 through both rig pin holes of the lower pedestal control assembly.




ICN-88277-G2742067-005-01

- 10. (A) Remove screws from upper crew compartment floor panel (216EZY).
- 11. (A) Remove and discard nylon cords.
- 12. (A) Remove panel.
- 13. (A) Remove screws from upper crew compartment floor panel (217BZY).
- 14. (A) Remove and discard nylon cords.
- 15. (A) Remove panel.




ICN-88277-G2742068-004-01

16. (A,B) Identify and remove screws, washers, and panel (237EZM).




PREPARATION FOR CABLE RUN 31A, REF 2-2. DES 2742MP005, AND CABLE RUN 32A, REF DES 2742MP006.

- 1. Review "Section 1 (General Information)" of this TO for system general warnings, cautions, and notes.
- 2. Review task "Functional Input Conditions" page for task specific safety conditions.
- 3. (A) Set PITCH TRIM switch on FCS ACTR panel to MECH and attach warning tag.




ICN-88277-G2742070-003-01

4. (A) Attach warning tag to **STAB TRIM** handles.




ICN-88277-G2742071-003-01

- 5. Enter vertical stabilizer (00-00-02, task 02-1).
- 6. (A) Install rig pins 5-3 in cable crank assemblies.




- 7. $\langle \overline{AA} \rangle \rightarrow \langle \overline{CJ} \rangle$ (A) Loosen fasteners and remove cover assembly (212AZC).
- 7. $\langle \overline{CK} \rangle \rightarrow$ (A) Loosen fasteners and remove panel assembly (212AZP).
- 8. $\langle \overline{AA} \rangle \rightarrow \langle \overline{CJ} \rangle$ (A) Loosen fasteners and remove cover assembly (212BZC).
- 8. $\langle \overline{CK} \rangle \rightarrow$ (A) Loosen fasteners and remove panel assembly (212BZP).




ICN-88277-G2742411-002-01

9. (A) Install rig pin 5-8 through both rig pin holes of the lower pedestal control assembly.




ICN-88277-G2742074-005-01


- 10. (A) Unlatch and open survival equipment stowage door assembly (235EZD).
- 11. $(\overline{AA}) \rightarrow (\overline{BR})$ (A) Remove forward bulkhead survival equipment locker curtain.
- 11. $\langle \overline{BS} \rangle \rightarrow$ (A) Remove forward bulkhead survival equipment locker access panels.



12. (A,B) Identify and remove screws, washers, and panel (237EZM).




- 2-3. PREPARATION FOR CABLE RUN 29B, REF DES 2742MP007, CABLE RUN 30B, REF DES 2742MP008, CABLE RUN 31B, REF DES 2742MP009, CABLE RUN 32B, REF DES 2742MP010, CABLE RUN 31C, REF DES 2742MP011, CABLE RUN 30C, REF DES 2742MP012, CABLE RUN 29C, REF DES 2742MP013, AND CABLE RUN 32C, REF DES 2742MP014.
- 1. Review "Section 1 (General Information)" of this TO for system general warnings, cautions, and notes.
- 2. Review task "Functional Input Conditions" page for task specific safety conditions.
- 3. (A) Set **PITCH TRIM** switch on **FCS ACTR** panel to **MECH** and attach warning tag.




ICN-88277-G2742077-003-01

4. (A) Attach warning tag to **STAB TRIM** handles.




ICN-88277-G2742078-003-01

- 5. Enter vertical stabilizer (00-00-02, task 02-1).
- 6. (A) Install rig pins 5-3 in cable crank assemblies.




27-42-13-22-45

- 7. $\langle \overline{AA} \rangle \rightarrow \langle \overline{CJ} \rangle$ (A) Loosen fasteners and remove cover assembly (212AZC).
- 7. $\langle \overline{CK} \rangle \rightarrow$ (A) Loosen fasteners and remove panel assembly (212AZP).
- 8. $\langle \overline{AA} \rangle \rightarrow \langle \overline{CJ} \rangle$ (A) Loosen fasteners and remove cover assembly (212BZC).
- 8. $\langle \overline{CK} \rangle \rightarrow$ (A) Loosen fasteners and remove panel assembly (212BZP).



ICN-88277-G2742413-002-01


9. (A) Install rig pin 5-8 through both rig pin holes of the lower pedestal control assembly.



ICN-88277-G2742399-004-01


2-4. REMOVAL FOR CABLE RUN 29A, REF DES 2742MP003.

- 1. (A) Install clamp assembly on cable runs 29 and 30 forward of fairlead at Station (STA) 511.
- 2. (A) Remove and discard safety clips; loosen turnbuckle on cable run 30 at STA 450.
- 3. (A) Remove and discard safety clips; remove turnbuckle from cable run 29 at STA 432.




ICN-88277-G2742082-003-01

4. (A) Remove cotter pin, nut, washer, and bolt from lower pedestal control assembly.




5. (A) Remove guard pin from cable pulley at STA 191.




ICN-88277-G2742084-003-01

6. (A) Remove guard pins from cable pulley at STA 227.




ICN-88277-G2742085-003-01

7. (A) Remove guard pins from cable pulley at STA 240.




- 8. (A) Remove guard pin from cable pulley at STA 340.
- 9. (A) Remove guard pin from cable pulley at STA 413.
- 10. (A,B) Attach nylon utility cord on cable assembly end; remove cable and untie cord.



ICN-88277-G2742087-003-01


2-5. REMOVAL FOR CABLE RUN 30A, REF DES 2742MP004.

- 1. (A) Install clamp assembly on cable runs 29 and 30 forward of fairlead at Station (STA) 511.
- 2. (A) Remove and discard safety clips; loosen turnbuckle on cable run 29 at STA 432.
- 3. (A) Remove and discard safety clips; remove turnbuckle from cable run 30 at STA 450.




ICN-88277-G2742088-003-01

4. (A) Remove safety wire and cable assembly end from lower pedestal control assembly.




5. (A) Remove guard pin from cable pulley at STA 191.




ICN-88277-G2742090-003-01

6. (A) Remove guard pins from cable pulley at STA 227.




ICN-88277-G2742091-003-01

7. (A) Remove guard pins from cable pulley at STA 240.




- 8. (A) Remove guard pin from cable pulley at STA 340.
- 9. (A) Remove guard pin from cable pulley at STA 413.
- 10. (A,B) Attach nylon utility cord on cable assembly end; remove cable and untie cord.




ICN-88277-G2742093-003-01

2-6. REMOVAL FOR CABLE RUN 31A, REF DES 2742MP005.


- 1. (A) Install clamp assembly on cable runs 31 and 32 forward of fairlead at Station (STA) 511.
- 2. (A) Remove and discard safety clips; loosen turnbuckle on cable run 32 at STA 478.
- 3. (A) Remove and discard safety clips; remove turnbuckle from cable run 31 at STA 446.



4. (A) Remove safety wire and cable assembly end from lower pedestal control assembly.




5. (A) Remove guard pin from cable pulley at STA 191.




ICN-88277-G2742097-003-01

6. (A) Remove guard pins from cable pulley at STA 227.




ICN-88277-G2742098-003-01

7. (A) Remove guard pins from cable pulley at STA 240.




- 8. (A) Remove guard pin from cable pulley at STA 340.
- 9. (A) Remove guard pin from cable pulley at STA 413.
- 10. (A,B) Attach nylon utility cord on cable assembly end; remove cable and untie cord.



ICN-88277-G2742100-003-01


2-7. REMOVAL FOR CABLE RUN 32A, REF DES 2742MP006.

- 1. (A) Install clamp assembly on cable runs 31 and 32 forward of fairlead at Station (STA) 511.
- 2. (A) Remove and discard safety clips; loosen turnbuckle on cable run 31 at STA 446.
- 3. (A) Remove and discard safety clips; remove turnbuckle from cable run 32 at STA 478.



ICN-88277-G2742103-003-01

4. (A) Remove cotter pin, nut, washer, and bolt from lower pedestal control assembly.



ICN-88277-G2742101-004-01

5. (A) Remove guard pin from cable pulley at STA 191.