Lecture X

Capstone Project

© 2024 Open Project Space, Institute of Electrical and Electronics Engineers at the University of California, Irvine. All Rights Reserved.

SECTION I


Winter Quarter Recap


Remote Control PCB Capstone

- Design your own remote control PCB for the Capstone Rover Project.
- Due date: 4/4/2025 at 11:59PM
- This project is optional!

Learning Concepts:

- KiCAD
- Schematics
- PCB Design
- PCB Manufacturing





Project Extension Requests

- Considerations for a project extension:
 - Legitimate reason, or prove you've made significant progress (We appreciate honesty!)
 - Plan and timeline to finish the project(s)
- Deadline: Sunday 4/6/2025 to submit an extension for projects 5-7



SECTION II


Capstone Overview

Capstone Project

- Build and control a Rover remotely with a custom PCB.
- Due date: 4/4/2025 at 11:59PM

Learning Concepts:


Everything!!!



Capstone Project Requirements

Build a remote-controlled rover

- The rover must be controlled wirelessly via the remote control
- The remote control should use a joystick for user input
- A user should be able to intuitively use the joystick to control the rover
 - This means that pivoting the joystick left should move the rover left, not backward



Capstone Project Requirements (Cont.)


- You must design a PCB for the remote control
 - The PCB must adhere to the provided manufacturer constraints.
 - LIKE, WE CAN ACTUALLY FAB IT
 - The PCB must be less than 100x100mm in size
- The rover must be able to move forward, backward, left, and right in response to commands sent by the remote
- Lastly, the rover must be stable and reliable
 - There should be no spontaneous movement, no wireless connection issues, and absolutely no sparks.

Capstone Project Schedule

Week	Lecture	Workshop
1	RC Rover: Getting Started	
2		Capstone Rover Assembly
3	Senior Design Project Showcase	
4		Capstone PCB Assembly
5	OPS Midterm	
6		Capstone Programming
7	End of the Year Review/Reflection	
8		
9		Rover Competition
10	Capstone Submission Deadline	

Capstone Rover Assembly (Week 2)

- We will be assembling the rover first w/ a Hot Glue Gun
- Parts needed:
 - x2 Gearbox Motor
 - o x2 Wheel
 - x1 Ball Caster + Mount
 - x1 9V Battery Holder
 - o x1 4" x 4" Wood Plate
 - x1 Breadboard
 - x1 Battery (If your battery is weak, stop by lab hours for a new one)
 - x1 9V Battery Snap Connector with Dupont Terminals



Capstone PCB Assembly (Week 4)

- We will be soldering and assembling the Remote Control PCB
- Parts needed:
 - x1 Remote Control PCB
 - x2 1x12 Socket Header
 - x1 1x5 Socket Header, Right Angle
 - x2 220Ω Resistor
 - x2 LED (Red, Green)




Capstone Programming (Week 6)

- You will be programming the Remote Control and Rover to meet Project Requirements
- Core Concepts:
 - digitalRead()/digitalWrite()
 - analogRead()/analogWrite()
 - Transmitting and Receiving
 Data w/ ESP32 Wifi Library
 - Reading Datasheets
 - Reading Pinout Diagrams

WeAct Studio ESP32-C3Fx4 Mini Core

PINOUT



Capstone Project Deadlines

Deadlines

- PCB Design Submission: April 4th, 2025 at 11:59 PM
 - After the deadline, we will review the submissions and send them in a bulk order to JLCPCB for manufacturing
 - If you submit late, your PCB will not be manufactured, but you can still receive full marks (before the final submission deadline)
- Final Submission: June 6th, 2025 at 11:59 PM

One More Thing...

Raffle Prizes for Completing Projects!

- Each completed project = 1 Raffle Ticket
- Completed Capstone Project = 3
 Raffle Tickets
- Tickets will be drawn for:
 - Gaming Keyboard + Mouse (1 Winner)
 - Soldering Kits (2 Winners)
 - In-n-Out Gift Card (3 Winners)



SECTION III

Getting Started

Brainstorming the Problem

- Let's pretend someone came to you and asked you to make a rover for them...
- As you brainstorm, consider your **design constraints** early on...
 - Cost How much are you willing to spend on parts?
 - Time How much time can you commit?
 - Complexity Do you have a sufficient understanding to create this?
 - Equipment What tools, parts, and lab space are available to you?

SECTION IV

Picking Parts and Drawing the Schematic

Picking Parts

- Now, it's time to start looking for parts to buy...
- Choose a seller that's right for you!
 - If you want quality parts and reliable shipping, consider buying from a more reputable supplier:
 - <u>DigiKey</u>, <u>Mouser</u>, or <u>Newark</u>
 - If you want to save money with a reasonable chance of quality parts, consider one of the following options:
 - Amazon, Ebay, or Aliexpress
 - Exercise caution: Examine the listings' reviews and descriptions

Picking Parts from DigiKey




- An advantage to buying from an electronics supplier is that they typically have part search tools
 - You can define all the part's specifications to refine the search
 - \circ Ex) Looking for a resistor? Specify its resistance (Ω), tolerance, max power rating, and packaging
- Let's use DigiKey to demonstrate the power of a <u>parts search tool</u> by looking for the following resistor:
 - \circ 130 Ω ± 5%, THT, Axial, 2W, Cut Tape

- DigiKey
- Don't know what parts do, and how to connect them so that they could operate properly? Solution: Read the datasheet

Datasheets

- A datasheet is a document that tells you how a part works and how to operate
 it
- Can usually be found under parts description
- Reading datasheets is an essential skill of any engineer!



Reading Datasheets

- Use Ctrl + F to navigate and find specific information you need
- Start with the Overview / General Description
 - a. Typically the first page
 - b. Key features
 - c. Gives you the big picture















L293, L293D SLRS008D - SEPTEMBER 1986 - REVISED JANUARY 2016

L293x Quadruple Half-H Drivers

1 Features

- Wide Supply-Voltage Range: 4.5 V to 36 V
- Separate Input-Logic Supply
- Internal ESD Protection
- High-Noise-Immunity Inputs
- Output Current 1 A Per Channel (600 mA for L293D)
- Peak Output Current 2 A Per Channel (1.2 A for L293D)
- Output Clamp Diodes for Inductive Transient Suppression (L293D)

2 Applications

- Stepper Motor Drivers
- DC Motor Drivers
- Latching Relay Drivers

3 Description

The L293 and L293D devices are quadruple highcurrent half-H drivers. The L293 is designed to provide bidirectional drive currents of up to 1 A at voltages from 4.5 V to 36 V. The L293D is designed to provide bidirectional drive currents of up to 600-mA at voltages from 4.5 V to 36 V. Both devices are designed to drive inductive loads such as relays, solenoids, DC and bipolar stepping motors, as well as other high-current/high-voltage loads in positivesupply applications.

Each output is a complete totem-pole drive circuit, with a Darlington transistor sink and a pseudo-Darlington source. Drivers are enabled in pairs, with drivers 1 and 2 enabled by 1,2EN and drivers 3 and 4 enabled by 3,4EN.


The L293 and L293D are characterized for operation from 0°C to 70°C.

Device Information(1)

PART NUMBER	PACKAGE BODY SIZE (NON	
L293NE	PDIP (16)	19.80 mm × 6.35 mm
L293DNE	PDIP (16)	19.80 mm × 6.35 mm

 For all available packages, see the orderable addendum at the end of the data sheet.


Logic Diagram



Reading Datasheets (Cont.)

- 2. Look at the Pinout Diagram
 - a. Tells you what pins do what
 - i. Power and ground pins
 - En pins (active low or active high)
 - iii. Input/output pins
 - iv. Special function pins
- 3. Make sure to respect the Absolute Maximum Ratings!
 - You won't have to worry too much about this in OPS... (Highest Supply Voltage we use is 9V)

5 Pin Configuration and Functions



Pin Functions

PIN		7/05	DESCRIPTION	
NAME	NO.	TYPE	DESCRIPTION	
1,2EN	1	1	Enable driver channels 1 and 2 (active high input)	
<1:4>A	2, 7, 10, 15	1	Driver inputs, noninverting	
<1:4>Y	3, 6, 11, 14	0	Driver outputs	
3,4EN	9	1	Enable driver channels 3 and 4 (active high input)	
GROUND	4, 5, 12, 13	_	Device ground and heat sink pin. Connect to printed-circuit-board ground plane with multiple solid vias	
V _{CC1}	16	-	5-V supply for internal logic translation	
V _{CC2}	8	_	Power VCC for drivers 4.5 V to 36 V	

6.1 Absolute Maximum Ratings

over operating free-air temperature range (unless otherwise noted)(1)

	MIN	MAX	UNIT
Supply voltage, V _{CC1} ⁽²⁾		36	V
Output supply voltage, V _{CC2}		36	V
Input voltage, V _I		7	V
Output voltage, V _O	-3	V _{CC2} + 3	V
Peak output current, I _O (nonrepetitive, t ≤ 5 ms): L293	-2	2	Α
Peak output current, I _O (nonrepetitive, t ≤ 100 μs): L293D	-1.2	1.2	Α
Continuous output current, Io: L293	-1	1	Α
Continuous output current, I _O : L293D	-600	600	mA
Maximum junction temperature, T _J		150	°C
Storage temperature, T _{stq}	-65	150	°C

Drawing the Schematic

- While you pick the parts, you should also draw the first draft schematic
 - The advantage of performing these tasks simultaneously is that you research the datasheets/pinouts before committing to the parts
- Use a schematic capture tool:
 - Fritzing (Small one-time license fee)
 fritzing
 - Fritzing is beginner-friendly and offers a "breadboard"-level visual representation of parts and connections
 - KiCAD EDA (Free)
 - If your design is more sophisticated, KiCAD is the better option

SECTION V

Prototyping

Implementing Solutions Safely

- Always consider safety requirements when working with high voltage and current:
 - Make sure designs are properly grounded
 - Watch where power is dissipated...
 Heat can build up fast
 - Exercise caution when testing live AC circuits so you don't electrocute yourself
 - Always check that power sources are unplugged before manipulating circuits



Analog Joystick



- You will be using the Analog Joystick to control the rover
- The GND and +5V pins power the Joystick
- VX and VY carry analog signals for the horizontal and vertical position of the joystick, respectively. These pins must be connected to analog pins on the ESP32
- When you use a button or, in our case, the SW pin of the joystick, you should use a pull-up resistor.
 - Instead of building an external circuit, you can use an internal pull-up resistor in the ESP32. You may do so by setting the pin mode as follows:
 - pinMode(pin, INPUT PULLUP);

Sending Joystick Data

- Use the RemoteData class to send data
- Ex. RemoteData data;
 - data.vx = 34;
 - o data.vy = 70;
 - o data.sw = 0;
 - send_data(receiverAddress, data);

```
Winclude (WifiConfig.h)
//Find the mac address of your receiver ESP32 first, then enter it in here:
uint8_t receiverAddress[] = {0x34, 0xB7, 0xDA, 0xF6, 0x3E, 0x78};
RemoteData data:
void setup()
 Serial.begin(115200);
                                       // Serial setup
 wifi setup():
                                     // start wifi mode and ESP-NOW
 peer_setup(receiverAddress);
                                     // configure receiving address
 set_data_receiver(&data);
                                // configure the receiver ESP32 to update data's values upon reception
void loop()
 data.vx = 34;
 data.vy = 70;
 data.sw = 0;
 send data(receiverAddress, data);
 Serial.print("VX: ");
 Serial.println(data.vx);
 delay(1000);
```

Arduino Functions

 Understand the purpose of each function in a code (Don't just blindly copy and paste code!)

Visit the <u>Arduino Language</u>
 <u>Reference</u> for an explanation of the most common Arduino functions

Language Reference Arduino programming language can be divided in three main parts: functions, values (variables and constants), and structure.

analogReadResolution()

analogReference()

analogWrite() analogWriteResolution()

Variables Structure Functions For controlling the Arduino board and performing computations. Digital I/O Math Bits and Bytes digitalRead() abs() bit() digitalWrite() constrain() bitClear() pinMode() bitRead() map() bitSet() max() bitWrite() min() highByte() pow() sq() lowByte() sgrt() Analog I/O Trigonometry **External Interrupts** analogRead() cos() attachInterrupt()

detachInterrupt()

digitalPinToInterrupt()

sin()

Using the Serial Monitor

```
File Edit Sketch Tools Help

Select Board

demo_sketch.ino.ino

1 //
2
3 void setup() {
4 // put your setup code here, to run once:
5
6 }
7
```

- Serial.print is an excellent tool to help debug programs and tune sensors
 - Print values to track the photoresistor's value in the resistor divider
 - Find the photoresistor's value when the room is bright, and when the room is dark to determine the range of the photoresistor between 0-4095

SECTION VI

Analog Joystick Exercise

Analog Joystick



- Take out your parts kits! We will practice the fundamentals once again
- Goal: Get data from Joystick and use it to do something
- Step 1: Connect the Joystick to the ESP32
- Step 2: Use Arduino Functions to read data from the Joystick

FAIR USE DISCLAIMER

Copyright Disclaimer under section 107 of the Copyright Act 1976, allowance is made for "fair use" for purposes such as criticism, comment, news reporting, teaching, scholarship, education and research.

Fair use is a use permitted by copyright statute that might otherwise be infringing.

Non-profit, educational or personal use tips the balance in favor of fair use.

CC BY-NC-SA 4.0

This work by the Institute of Electrical and Electronics Engineers, UC Irvine Branch, is licensed under CC BY-NC-SA 4.0