## **LECTURE IV**

# ESP32 Programming Pt. 2

This work by the Institute of Electrical and Electronics Engineers, UC Irvine Branch, is licensed under CC BY-NC-SA 4.0

**SECTION I** 

# **Project III Review**


### **Project 3 Review**

- Official Due Date: Friday, Week 9 by 11:59PM
- Ask questions and seek help (online or @Lab Hours), so you can finish it on time!

#### Learning Concepts:

- Embedded Systems
- Microcontrollers
- ESP32
- Arduino IDE
- Pulse Width Modulation (PWM)







#### **New Deadlines**


- For the full \$20 refund for Fall Quarter, Final Project Deadlines will be:
  - Project 1: By the end of Finals Week (12/13/2024 at 11:59PM)
  - Project 2: By the end of Finals Week (12/13/2024 at 11:59PM)
  - Project 3: By the end of Winter Break (1/5/2025 at 11:59PM)
  - Project 4: By the end of Winter Break (1/5/2025 at 11:59PM)

 Ask project-specific questions in the #ops-help channel on the Discord. We'll answer during the break!

# SECTION II **Project IV**


## Project 4 Overview

 Build a sundial that measures the brightness of your room by controlling a micro servo with an ESP32 and photoresistor.



#### You will learn:


- ESP32 (Continued)
- Servos
- Arduino Libraries
- Tips for Programming in Arduino IDE





#### Servo


- A servo motor is a type of motor that converts electrical energy into mechanical energy to achieve precise control between 0°-180°
- Has three different wires; the power (red),
   ground (brown), and pulse-width modulation
   (orange) wires
  - Insert jumper wires into the female end of the micro servo and to connect it to the ESP32 on a breadboard
- You will be controlling the position of the servo
   with a photoresistor to make a sundial





#### Servo Pinout

- Connect the power (red) to 5V pin of the ESP32
- Connect the pulse-width modulation (orange) wire into a GPIO pin of the ESP32
- Connect the ground (brown) to GND of the ESP32



Servo Motor

ESP32\_C3\_Mini

### **SECTION IV**

# **Arduino Libraries**

#### **Arduino Library**


- A collection of pre-written code that makes it easier to interface with hardware or perform specific tasks
- Libraries made by Arduino's development team or Arduino community members
- Libraries can be downloaded from the library manager

```
servo_example | Arduino IDE 2.3.2
File Edit Sketch Tools Help
                 Select Board
      servo example.ino
              #include <ESP32Servo.h>
              // Assign variable to pin number of Servo's PWM pin
              int servoPin = 10;
              // Initialize servo object with name myServo
              Servo myServo;
              void setup() {
                // Attach object myServo to the physical servo
        13
                myServo.attach(servoPin);
        14
        15
        16
              void loop() {
                // Writes a 0 degree angle to the servo
                myServo.write(0);
                delay(1000);
        21
                // Writes a 90 degree angle to the servo
                myServo.write(90);
                // Writes a 180 degree angle to the servo
                myServo.write(180);
        26
                delay(1000);
        27
        28
```

#### **Servo Library**

 The ESP32Servo library will need to be installed to control the Servo in Project 4

- 1. Click on the Library manager icon
- 2. Type in ESP32Servo
- Download the first result by Kevin Harrington,John K. Bennet



### **Servo Library (Continued)**

- Must #include <ESP32Servo.h> to use the library
- Servo your\_servo\_name
  - Initializes servo object with whatever you want to name the servo object
- your servo name.attach(int pin)
  - Links the servo object to physical pin int pin
- your\_servo\_name.write(int angle)
  - Moves the servo to a specified degree (0°-180°)


```
servo_example | Arduino IDE 2.3.2
File Edit Sketch Tools Help
                Select Board
             #include <ESP32Servo.h>
             // Assign variable to pin number of Servo's PWM pin
             int servoPin = 10;
             // Initialize servo object with name myServo
              Servo myServo;
              void setup() {
               // Attach object myServo to the physical servo
        13
               myServo.attach(servoPin);
        14
        15
        16
              void loop() {
                // Writes a 0 degree angle to the servo
               myServo.write(0);
                // Writes a 90 degree angle to the servo
        22
               myServo.write(90);
                // Writes a 180 degree angle to the servo
                myServo.write(180);
        25
        26
               delay(1000);
        27
        28
```

## SECTION V

# **ESP32 Concepts**

#### **PWM**


- The ESP32 board is a **digital source**, meaning it can only output a **HIGH** (3.3V) or **LOW** (0V) voltage
  - Then how does analogwrite output analog signals?
- Pulse Width Modulation (PWM) is an oscillating digital waveform that emulates an analog output
  - By oscillating a signal from HIGH to LOW quickly, the average voltage over time will be between HIGH and LOW - an analog value



The average value, the analog value, of this waveform is **1.65V** 

#### **PWM Duty Cycle**

- The duty cycle of the PWM wave is the percentage of time where the signal is HIGH
  - For example, a 50% duty cycle translates to an average value of 1.65V (50% of 3.3V)
  - Allows us to output a continuous range of voltages between HIGH and LOW
  - Duty cycle is controlled by a timer inside the ESP32 microcontroller




#### ADC and analogRead

- analogRead utilizes the analog-to-digital converter inside the microcontroller to measure the real-world, analog signal and convert it to a digital signal
  - The measurement resolution is 12 bits, which is why the function returns values from 0-4095



#### **Resistor Divider**


- A circuit configuration with two resistors that is used to scale down a voltage (Vout).
- Creates a ratio of two resistors to achieve a desired output voltage
  - R1 and R2 are connected in series
  - Vin is the input voltage
  - Vout is the output voltage across R2




$$V_{out} = \left(\frac{R_2}{R_1 + R_2}\right) V_{in}$$

#### **Resistor Divider in Project 4**

- A potentiometer is an adjustable resistor divider
  - A wiper/slider divides the resistive element into two adjustable parts
- A photoresistor in series with a 4.7kΩ
   resistor is a light-dependent resistor divider
  - Photoresistor's resistance changes with the intensity of light to sense light levels
  - Resistor divider converts this change into a voltage that can be easily measured





**SECTION VI** 

Tips for Project 4

#### **Arduino Functions**

 Understand the purpose of each function in a code (Don't just blindly copy and paste code!)

Visit the <u>Arduino Language</u>
 <u>Reference</u> for an explanation of the most common Arduino functions

#### Arduino programming language can be divided in three main parts: functions, values (variables and constants), and structure. Variables Structure Functions For controlling the Arduino board and performing computations. Digital I/O Math Bits and Bytes digitalRead() abs() bit() digitalWrite() constrain() bitClear() pinMode() bitRead() map() bitSet() max() bitWrite() min() highByte() pow() sq() lowByte() sgrt() Analog I/O Trigonometry **External Interrupts** analogRead() cos() attachInterrupt() analogReadResolution() sin() detachInterrupt()

digitalPinToInterrupt()

Language Reference

analogReference()

analogWrite() analogWriteResolution()

## **Using the Serial Monitor**

```
File Edit Sketch Tools Help

Select Board

demo_sketch.ino.ino

1 //
2
3 void setup() {
4 // put your setup code here, to run once:
5
6 }
7
```

- Serial.print is an excellent tool to help debug programs and tune sensors
  - Print values to track the photoresistor's value in the resistor divider
    - Find the photoresistor's value when the room is bright, and when the room is dark to determine the range of the photoresistor between 0-4095

#### **Map Function**

- Re-maps a number from one range to another
- map(int inputValue, int min\_range\_1, int max\_range\_1, int min\_range\_2, int
  max range 2)
  - min\_range\_1 and max\_range\_1 are the min and max values of the first range, and min\_range\_2 and max\_range\_2 are the min and max values of the second range

#### Map function in Project 4 Checkpoint 1:


• You will need to map the range of the potentiometer (0-4095) to the servo range (0-180)


#### Ex.

```
potValue = analogRead(potPin)
map(potValue, 0, 4095, 0, 180)
```

### **Fall Quarter Recap**


- Completed 4 Projects in total!
  - LED there be Light
  - o 555 Piano
  - LED RGB Wizard
  - Sundial





- Main Learning Concepts:
  - o Ohm's Law
  - Breadboarding & Soldering
  - Basic Circuit Analysis
  - o ESP32
  - Programming in Arduino IDE





#### **Winter Quarter**


- 4 New Projects!
  - o iPoduino 2.0
  - Weather Station
  - o Digital Stopwatch
  - Capstone PCB Design





- Main Learning Concepts:
  - Communication Protocols (UART, SPI, I<sup>2</sup>C)
  - Interrupts, Timers
  - PCB Design





#### FAIR USE DISCLAIMER

Copyright Disclaimer under section 107 of the Copyright Act 1976, allowance is made for "fair use" for purposes such as criticism, comment, news reporting, teaching, scholarship, education and research.

Fair use is a use permitted by copyright statute that might otherwise be infringing.

Non-profit, educational or personal use tips the balance in favor of fair use.

#### CC BY-NC-SA 4.0

This work by the Institute of Electrical and Electronics Engineers, UC Irvine Branch, is licensed under CC BY-NC-SA 4.0