

BBC MICRO:BIT
NONE




ENTER
micro:bit

The logo consists of the word "ENTER" in a bold, white, sans-serif font. Below it, the words "micro:bit" are written in a smaller, white, lowercase sans-serif font. Behind the text is a circular graphic composed of several concentric, wavy lines that radiate outwards from the bottom center, creating a dynamic, soundwave-like effect.

BBC MICRO:BIT

PRVÁ KAPITOLA



V prvej kapitole budeme pracovať iba s micro:bitom, USB káblom a baterkou. Prejdeme si, aké súčiastky micro:bit obsahuje a ako ho programovať v prostredí [Microsoft Makecode](#).

ZOZNAM LEKCIÍ

- 1.1. Zoznamovací program
- 1.2. Digitálna menovka
- 1.3. Tlačidlá
- 1.4. Senzor pohybu
- 1.5. Počítadlo ľudí
- 1.6. Krokomer
- 1.7. Kameň, papier, nožnice
- 1.8. Poslušne hlásim!