







USER CREATIVE ROBOT





Part List of a Figure Skater

X 2	X 1 (long) X 1	X 1 X 1 X 1	X1 X1	
1	2	3	35 x 1 4	5
3000E X 1 30C X 1 30C X 1 30C X 1 30C X 1	7	3C X 1		1.0
X1	/	8	9	10
11	12	13	14	15



USER CREATIVE ROBOT