





USER CREATIVE ROBOT





- Use microphone sensor instead of remote sensor.
- In that case, connect the microphone sensor to the IN-1 and run the sound reacting mode in BP(Basic Program) mode






USER CREATIVE ROBOT



Part List of a Tricycle



[Parts list for extension model]









📮 X 1