

How to Tow Your Aventro Car

Whether you've had a breakdown, a minor accident, or just need to move your Aventro vehicle, towing it safely is critical. Below is a step-by-step guide for both manual and automatic Aventro car models.

Before You Begin

- **Check Owner's Manual:** Refer to your specific model's owner's manual for any towing restrictions or recommendations.
 - **Warning!** Never tow with wheels on the ground if your model is electric. Use a flatbed truck.
-

Step 1: Gather Necessary Tools

- Tow strap or tow rope (rated for your car weight)
 - Tow hook (provided with vehicle, usually in trunk/tool kit)
 - Torch (for visibility at night)
 - Warning triangle or cones
-

Step 2: Locate the Tow Hook Covers

1. **Front and Rear Bumper:**
 - Look for small plastic covers on the bumper (often marked by a tow symbol).
 2. **Remove the Cover:**
 - Use a plastic pry tool or key to open the cover.
-

Step 3: Attach the Tow Hook

1. **Retrieve the Tow Hook:**
 - Found in your car's tool kit or trunk.
 2. **Screw in the Tow Hook:**
 - Insert into the exposed thread & rotate clockwise until tight.
-

Step 4: Connect the Tow Strap or Tow Rope

- **Attach to Tow Hook:**
Ensure the strap/rope is securely fastened to the tow hook.

- **Other Vehicle:**

Attach the other end to the towing vehicle's tow point.

Step 5: Prepare the Vehicle for Towing

- **Manual Transmission:**

Place in Neutral, release the parking brake.

- **Automatic Transmission:**

Place in Neutral (N), release the parking brake.

CAUTION: For automatics and hybrids, flatbed towing is recommended to avoid transmission damage.

- **Electric Vehicles:**

ONLY FLATBED TOWING. Do not tow with wheels on ground.

Step 6: Safety Measures

- Place warning triangle/cones at a safe distance behind both vehicles.
 - Switch ON hazard lights on both vehicles.
 - Ensure both drivers agree on signaling and communication.
-

Step 7: Towing

- The towing vehicle should accelerate slowly – no sudden jerks.
 - Maximum speed should not exceed 25 km/h.
 - Keep the towed vehicle's ignition ON (to prevent steering lock and allow brake assist).
 - Steer and brake gently in the towed vehicle.
-

Step 8: After Towing

- Park both vehicles safely.
 - Unscrew the tow hook and store it back with your tools.
 - Replace the plastic tow hook cover.
-

Important Safety Notice

- Never tow on highways unless necessary.
- Do not allow passengers in the towed vehicle.

- If in doubt, use Aventro Roadside Assistance or professional towing.
-

Contact Aventro Motors Roadside Assistance

- **Phone:** +91 124 1234567
 - **Email:** info@aventromotors.com
-

For model-specific instructions, always refer to your Aventro Owner's Manual.