

CHICKEN VARUTHARACHA

चकिन VARUTHARACHA

OTO

Total Input (Excl. Pump Water):
1123 gm

Total Output:
700 G

⌚

Total Cooking Time:
10:00 mins

I

Accessories:
Pan Honeycomb
(Non-Stick), Silicone Stirrer



ची वरुथराचा
CHI VARUTHARACHA

सभी कच्ची सामग्री
All Raw Ingredients

कुल सामग्री वजन: 700 G
Total Ingredient Weight: 700 G

1. तेल और तड़का (83 gm)
Oil & Tadka (83 gm)



नारियल तेल 80 g
Coconut Oil 80 g



सौंफ 2 g
Fennel Seeds 2 g



करी पत्ता 1 g
Curry Leaves 1 g

2. कटा प्याज़, हरी मिर्च, कटे टमाटर (280 gm)
Chopped Onion, Green Chilli, Diced Tomato (280 gm)



कटा प्याज़ 150 g
Chopped Onion 150 g



हरी मिर्च 30 g
Green Chilli 30 g



कटे टमाटर 100 g
Diced Tomato 100 g

3. भुना मसाला (81 gm)
Roasted Masala (81 gm)



ताज़ा नारियल 50 g
Fresh Coconut 50 g



लाल मिर्च पाउडर 8 g
Red Chilli Powder 8 g



धनिया पाउडर 4 g
Coriander Powder 4 g



हल्दी पाउडर 2 g
Turmeric Powder 2 g



इलायची 4 Nos
Cardamom 4 Nos



दालचीनी 1 Nos
Cinnamon 1 Nos



लौंग 4 Nos
Cloves 4 Nos



सौंफ 4 g
Fennel Seeds 4 g



काली मिर्च 4 g
Black Pepper 4 g



सूखी लाल मिर्च 6 Nos
Dry Red Chilli 6 Nos



करी पत्ता 1 g
Curry Leaves 1 g



नमक 8 g
Salt 8 g

4. चिकन करी कट, अदरक-लहसुन पेस्ट, नमक (529 gm)
Chicken Curry Cut, Ginger Garlic Paste, Salt (529 gm)



चिकन करी कट 500 g
Chicken Curry Cut 500 g



अदरक-लहसुन पेस्ट 20 g
Ginger Garlic Paste 20 g



नमक 9 g
Salt 9 g

⌚ Cooking Time

On2Cook: 10:00 mins
Normal Cooking: 30 mins

Accessories:

Pan Honeycomb (Non-Stick), Silicone Stirrer

I Ingredients

83 g Oill & Tadka

80 g Coconut Oil, 2 g Fennel Seeds
1 g Curry Leaves

280 g Chopped Onion 150g, Green Chilli 30g, Diced Tomato 100g

81 g Roasted Masala

50 g Fresh Coconut
8 g Red Chilli Powder
4 g Coriander Powder
2 g (1/2Tbsp Turmeric Powder
4 Nos Cardamom, 1 Nos Cinnamon
4 Nos Cloves, 4 g Fennel Seeds
4 g Balck Pepper
6 Nos Dry Red Chilli
1 g Curry Leaves, 8 g Salt

529 g Chicken Curry Cut 500g, Ginger Garlic Paste 20g, Salt 9g

150 ml Water (Auto)

Step 1

0:00 secs

83 g Oill & Tadka

I 0

M 0

Step 2

4:00 mins

30g, Diced Tomato 100g
Chopped Onion 150g, Green Chilli

I 100

M 100

Step 3

3:00 mins

Garlic Paste 20g, Salt 9g
Chicken Curry Cut 500g, Ginger
81 g Roasted Masala, 529 g

I 100

M 100

Step 4

3:00 mins

Garlic Paste 20g, Salt 9g
Chicken Curry Cut 500g, Ginger

I 40

M 100

Recipe Steps

Please place the required cooking vessel on the On2Cook induction top. Then follow only the manual setup or ingredient-addition steps shown below:

Prerequisite: Set up the required accessories: Pan Honeycomb (Non-Stick); Silicone Stirrer.

Step 1: Add 83 g Oill & Tadka and 280 g Chopped Onion 150g, Green Chilli 30g, Diced Tomato 100g to the pan. Close the lid to start cooking.

Step 2: Open the lid and add 81 g Roasted Masala and 529 g Chicken Curry Cut 500g, Ginger Garlic Paste 20g, Salt 9g to the pan. Close the lid to continue cooking.

Disclaimer

When an accessory setup step is shown, use only the listed accessories and complete that setup before adding ingredients. Plain Water listed simply as 'Water' is dispensed automatically by the On2Cook pump from the connected water bottle. Do not add this plain Water manually.

Any named or special water—such as Stock Water, Coconut Water, Rice Water, or another recipe-prepared liquid—must be added manually whenever it appears in the steps.

Open the lid only for the ingredient-addition prompts shown above, then set the lid as instructed before cooking continues. Please open the lid of the On2Cook device, take out the food, and serve it.

पकाने के चरण

कृपया आवश्यक कुकिंग वेसल को On2Cook इंडक्शन टॉप पर रखें। फरि केवल नीचे दएि गए मैनुअल सेटअप या सामग्री डालने वाले चरणों का पालन करें:

पूर्व तैयारी: आवश्यक एक्सेसरीज़ सेट करें: Pan Honeycomb (Non-Stick); Silicone स्ट्रिरर।

चरण 1: पैन में 83 g Oill और Tadka और 280 g कटा हुआ प्याज 150g, हरी मरिच 30g, Diced टमाटर 100g डालें। खाना पकाना शुरू करने के लिए ढक्कन बंद करें।

चरण 2: ढक्कन खोलें और पैन में 81 g Roasted मसाला और 529 g चकिन करी Cut 500g, अदरक लहसुन पेस्ट 20g, नमक 9g डालें। खाना पकाना जारी रखने के लिए ढक्कन बंद करें।

असवीकरण

जब एक्सेसरी सेटअप चरण दिखाया जाए, केवल सूचीबद्ध एक्सेसरीज़ का उपयोग करें और सामग्री डालने से पहले सेटअप पूरा करें।

यदि सामग्री में केवल 'Water' लिखा है, तो यह सामान्य पानी On2Cook कनेक्टेड पानी की बोतल से पंप द्वारा अपने-आप डालता है। यह सामान्य पानी हाथ से न डालें।

Stock Water, Coconut Water, Rice Water या किसी अन्य वशिष/रिसपि में तैयार कएि गए पानी या तरल को चरणों में दखाए जाने पर हाथ से डालें।

ढक्कन केवल ऊपर दएि गए सामग्री डालने वाले चरणों में खोलें और खाना पकना जारी होने से पहले नरिदेश के अनुसार ढक्कन की स्थतिरिखें।

कृपया On2Cook डवाइस का ढक्कन खोलें, खाना नकालें और परोसें।

Total Output: 700 G