



# Instruções e Linguagem de Máquina

Guiou Kobayashi guiou.kobayashi@ufabc.edu.br

2º Quadrimestre, 2014





# **CONTEÚDO PROGRAMÁTICO:**

- História e Evolução dos Computadores e Sistemas
- Estrutura de Computadores Digitais
- Lógica Digital Binária
- Processamento
- Instruções e linguagem de máquina
- Microprocessadores modernos: pipeline, super escalar, RISC
- Memórias cache e gerenciamento de memórias
- Arquitetura de computadores pessoais
- Arquitetura de Computadores Paralelos
- Sistemas Computacionais: desempenho e confiabilidade






# Tipos de Instruções



## **INSTRUÇÕES DE UM BYTE**

## AND REGISTRADOR X



### Exemplo:

AND ACC, R1: (ACC ← ACC AND R1)

## 1: FETCH INSTRUÇÃO

Q1:  $PC \rightarrow Via de Endereços$ 

Q2: Comando de Leitura

Q3: Memória → Via de Dados

Q4: Via de Dados → IR

### 2: Acumulador = Acumulador AND R1

Q1: R1 → Barramento B

Q2: ULA: Operação AND

Q3: ULA: Retenção Barramento A Q4: Barramento C → Acumulador

 $(4. \text{ Danial Herito } C \rightarrow Actimula)$ 

### 3: PC = PC + 1

Q1: ULA: Bloqueia Barramento A


Q2: PC → Barramento B

Q3: ULA: Incrementa Barramento B

Q4: Barramento  $C \rightarrow PC$ 




## **INSTRUÇÕES DE DOIS BYTES**






# **INSTRUÇÕES DE TRÊS BYTES - 1**



# LEITURA DE UM DADO DA MEMÓRIA RAM: INSTRUÇÃO LOAD

Especificar o endereço de 16 bits da posição da memória a ser lida

Exemplo: leitura da posição A0F1, que contém o valor 7C



### Exemplo:

LOAD A0F1:  $(ACC \leftarrow [A0F1])$ 

1: FETCH INSTRUÇÃO

2: PC = PC + 1

3: FETCH ENDEREÇO 1 (+signif.)

4: PC = PC + 1

5: FETCH ENDEREÇO 2 (-signif.)

**6: MDR ← [ENDEREÇO]** 

Q1: MAR → Via de Endereços

Q2: Comando de Leitura

Q3: Memória → Via de Dados

Q4: Via de Dados → MDR

# 7: Transferência para Acumulador ACC ← MDR

Q1: ULA: Bloqueia Barramento A

Q2: MDR → Barramento B

Q3: ULA: bypass Barramento B


Q4: Barramento C → Acumulador

8: PC = PC + 1






## FLUXO DE INFORMAÇÕES PARA LEITURA







# **INSTRUÇÕES DE TRÊS BYTES - 2**




# SALTO INCONDICIONAL: INSTRUÇÃO GOTO ou JUMP

Especificar o endereço de 16 bits da próxima posição do programa

### Exemplo:


**GOTO 203F** 

- 1: FETCH INSTRUÇÃO
- 2: PC = PC + 1
- 3: FETCH ENDEREÇO 1 (+signif.)
- 4: PC = PC + 1
- 5: FETCH ENDEREÇO 2 (-signif.)
- **6: PC ← ENDEREÇO**






# **INSTRUÇÕES DE TRÊS BYTES - 3**



## CHAMADA DE ROTINA: INSTRUÇÃO CALL

Especificar o endereço de 16 bits da posição da rotina



### Exemplo:

### CALL 203F

- 1: FETCH INSTRUÇÃO
- 2: PC = PC + 1
- 3: FETCH ENDEREÇO 1 (+signif.)
- 4: PC = PC + 1
- 5: FETCH ENDEREÇO 2 (-signif.)
- 6: SP = SP + 1
- 7: [SP] ← PC
- 8: PC ← ENDEREÇO

### **RETURN**


- 1: FETCH INSTRUÇÃO
- 2: PC ← [SP]
- 3: SP = SP 1
- 4: PC = PC + 1





## **NÍVEIS DE SUB-ROTINAS**

### Chamada de Rotinas de dentro das Rotinas





## **INSTRUÇÕES: RESUMO**

- Instruções são executadas em ciclos de máquinas, que estabelecem os passos necessários até a sua execução. O número de ciclos depende da instrução.
- Instruções possuem tamanhos diferentes em bytes, sendo compostas por um código de operação (Op Codes) seguido por parâmetros que podem ser valores constantes, endereços, etc.

Tamanho: 1 byte OPCODE

2 bytes OPCODE VALOR

3 bytes OPCODE ENDEREÇO 1 ENDEREÇO 2

- Etapas típicas de um ciclo de instruções:
  - 1 Fetch da instrução, da memória para o registrador de instruções (IR)
  - 2 Incrementa o contador de instruções (PC), apontando-o para a próxima instrução
  - 3 Determina o tipo de instrução carregada (Decode)
  - 4 Se a instrução utiliza mais parâmetros, busca por fetch sucessivos
  - 5 Se a instrução realiza acesso à memória (leitura ou escrita), efetua o acesso
  - 6 Executa a instrução
  - 7 Vai para a etapa 1 para iniciar a execução da próxima instrução





# Exemplos de Linguagens de Máquina



## EXEMPLO DE ASSEMBLY DE UM PROCESSADOR HIPOTÉTICO

OBS: PROCESSADOR DE 8 BITS E ENDEREÇAMENTO DE 16 BITS

## **OPERAÇÕES COM INTEIROS**

ADD 1-2 (1 ou 2 bytes)

SUB 1-2

AND 1-2 OPERANDO:

IOR 1-2 - Registrador (1 byte)

XOR 1-2 - Constante (2 bytes)

COMP 1

CLR 1 FORMATO:

INC 1 Instrução Destino, Origem

DEC 1

## **OPERAÇÕES DE DESLOCAMENTO**

RL 1 (Rotate Left Acumulador) RR 1 (Rotate Right Acumulador)

## **OPERAÇÕES DE FLUXO DE DADOS**

MOV 1 (Acumulador  $\leftarrow \rightarrow$  Registrador)

MOVC 1 (Acumulador ← Constante)

PUSH 1 (Insere na Pilha) POP 1 (Retira da Pilha)

LOAD 3 (Memória: Endereço 2 bytes) SAVE 3 (Memória: Endereço 2 bytes)

IN 3 (Dispositivos I/O: Endereço 2 bytes)
OUT 3 (Dispositivos I/O: Endereço 2 bytes)

BITs DE ESTADO (do Acumulador)

Z (Zero): = 1 se Acumulador = 0

C (Carry): = se Vai-um após soma

### **REGISTRADORES ESPECIAIS**

ACC (Acumulador)

PC (Program Counter)

IR (Instruction Register)

SP (Stack Pointer)

MAR (Memory Address Reg)
MDR (Memory Data Reg)
IND (Indirect Address Reg)

### **REGISTRADORES DE DADOS**

R0 a R7 Registradores de uso geral

### **OPERAÇÕES DE FLUXO DE CONTROLE**

GOTO 3 (Endereço 2 bytes)

CALL 3

RET 1 (Return)

**Condicionais** 

JZ 3 (Jump on Zero)

JNZ 3 (Jump on Non-Zero)

JC 3 (Jump on Carry)

JNC 3 (Jump in Non-Carry)



# INSTRUÇÕES DE MÁQUINA: Exemplos Reais

	Loads	В	oolean
LDSB ADDR,DST	Load signed byte (8 bits)	AND R1,S2,DST	Boolean AND
LDUB ADDR,DST	Load unsigned byte (8 bits)	ANDCC "	Boolean AND and set icc
LDSH ADDR,DST	Load signed halfword (16 bits)	ANDN "	Boolean NAND
LDUH ADDR,DST	Load unsigned halfword (16)	ANDNCC "	Boolean NAND and set icc
LDSW ADDR,DST		OR R1,S2,DST	Boolean OR
LDUW ADDR,DST	Load unsigned word (32 bits)	ORCC "	Boolean OR and set icc
LDX ADDR,DST	Load extended (64-bits)	ORN "	Boolean NOR
		ORNCC "	Boolean NOR and set icc
	Stores	XOR R1,S2,DST	Boolean XOR
STB SRC,ADDR	Store byte (8 bits)	XORCC "	Boolean XOR and set icc
STH SRC,ADDR	Store halfword (16 bits)	XNOR "	Boolean EXCLUSIVE NOR
STW SRC,ADDR	Store word (32 bits)	YNORCC "	Pooles EVOL NOD

XNORCC

	alah at		sfer of control
	rithmetic	BPcc ADDR	Branch with prediction
ADD R1,S2,DST	Add	BPr SRC,ADDR	Branch on register
ADDCC "	Add and set icc	CALL ADDR	Call procedure
ADDC "	Add with carry	RETURN ADDR	Return from procedure
ADDCCC "	Add with carry and set icc	JMPL ADDR,DST	Jump and Link
SUB R1,S2,DST	Subtract	SAVE R1,S2,DST	
SUBCC "	Subtract and set icc		Advance register windows
SUBC "		RESTORE "	Restore register windows
	Subtract with carry	Tcc CC,TRAP#	Trap on condition
SUBCCC "	Subtract with carry and set icc	PREFETCH FCN	Prefetch data from memory
MULX R1,S2,DST	Multiply	LDSTUB ADDR,R	Atomic load/store
SDIVX R1,S2,DST	Signed divide	1	
		MEMBAR MASK	Memory barrier
UDIVX R1,S2,DST	Unsigned divide		
TADCC R1.S2.DST	Tagged add	NA:-	and an annual state of the stat

	- Lugged add	] iviis	cellaneous
		SETHI CON, DST	Set bits 10 to 31
	nifts/rotates	MOVcc CC,S2,DST	Move on condition
SLL R1,S2,DST	Shift left logical (32 bits)	MOVr R1,S2,DST	Move on register
SLLX R1,S2,DST	Shift left logical extended (64)	NOP	No operation
SRL R1,S2,DST	Shift right logical (32 bits)	POPC S1,DST	Population count
SRLX R1,S2,DST	Shift right logical extended (64)	RDCCR V,DST	Read condition code register
SRA R1,S2,DST	Shift right arithmetic (32 bits)	WRCCR R1,S2,V	Write condition code register
SRAX R1,S2,DST	Shift right arithmetic ext. (64)	RDPC V,DST	Read program counter

SRC = source register	TRAP# = trap nu
DST = destination register	FCN = function of
R1 = source register	MASK = operation
S2 = source: register or immediate	CON = constant
ADDR = memory address	
ADDN - memory address	V = register desi

Store extended (64 bits)

STX SRC,ADDR

CC = condition code set R =destination register ion type cc = condition r = LZ, LEZ, Z, NZ, GZ, GEZ

Boolean EXCL. NOR and set icc

Figure 5-34. The primary UltraSPARC II integer instructions.

	• • • • • • • • • • • • • • • • • • •		
Loads		Compa	ırison
typeLOAD IND8	Push local variable onto stack	IF_ICMPrel OFFSET16	Conditional branch
typeALOAD	Push array element on stack	IF_ACMPEQ OFFSET16	Branch if two ptrs equal
BALOAD	Push byte from an array on stack	IF_ACMPNE OFFSET16	Branch if ptrs unequal
SALOAD	Push short from an array on stack	IFrel OFFSET16	Test 1 value and branch
CALOAD	Push char from an array on stack	IFNULL OFFSET16	Branch if ptr is null
AALOAD	Push pointer from an array on "	IFNONNULL OFFSET16	Branch if ptr is nonnull
		LCMP	Compare two longs
	Stores	FCMPL	Compare 2 floats for <
typeSTORE IND8		FCMPG	Compare 2 floats for >
typeASTORE	Pop value and store in array	DCMPL	Compare doubles for <
BASTORE	Pop byte and store in array	DCMPG	Compare doubles for >
SASTORE	Pop short and store in array	23 4	Compare deadles for F
CASTORE Pop char and store in array		Transfer	of control
AASTORE	Pop pointer and store in array	INVOKEVIRTUAL IND16	Method invocation
		INVOKESTATIC IND16	Method invocation
Pushes		INVOKEINTERFACE	Method invocation
BIPUSH CON8	Push a small constant on stack	INVOKESPECIAL IND16	Method invocation
CIDITICAL CONTR	Dunh 16 hit constant on stock		

AASIUNE	Fup pointer and store in array	INVOKEVIATOALINDIO	Method invocation
		INVOKESTATIC IND16	Method invocation
	Pushes	INVOKEINTERFACE	Method invocation
BIPUSH CON8	Push a small constant on stack	INVOKESPECIAL IND16	Method invocation
SIPUSH CON16	Push 16-bit constant on stack	JSR OFFSET16	Invoke finally clause
LDC IND8	Push constant from const pool	typeRETURN	Return value
typeCONST_#	Push immediate constant	ARETURN	Return pointer
ACONST_NULL	Push a null pointer on stack	RETURN	Return void
	Arithmetic	RET IND8	Return from finally
typeADD	Add	GOTO OFFSET16	Unconditional branch
typeSUB	Subtract	Array	/b

ANEWARRAY IND16

Create array of ptrs

Multiple

Divide

Swap top two ints on stack

typeDIV

		MEMADDAI ATTE	Create array or atype
typeREM	Remainder	MULTINEWARRAY IN16,D	Create multidim array
typeNEG	Negate	ARRAYLENGTH	Get array length
	Boolean/shift	Miscella	neous
ilAND	Boolean AND	IINC IND8,CON8	Increment local variable
iior	Boolean OR	WIDE	Wide prefix
ilXOR	Boolean EXCLUSIVE OR	NOP	No operation
iISHL	Shift left	GETFIELD IND16	Read field from object
IISHR	Shift right	PUTFIELD IND16	Write field to object
IUSHR	Unsigned shift right	GETSTATIC IND16	Get static field from class
	Conversion	NEW IND16	Create a new object
x2y	Convert x to y	INSTANCEOF OFFSET16	Determine type of obj
j2c	Convert integer to char	CHECKCAST IND16	Check object type
i2b	Convert integer to byte	ATHROW	Throw exception
	T content mineger to 5/15	LOOKUPSWITCH	Sparse multiway branch
5	Stack management	TABLESWITCH	Dense multiway branch
DUPxx	Six instructions for duping	MONITORENTER	Enter a monitor
POP	Pop an int from stk and discard	MONITOREXIT	Leave a monitor
POP2	Pop two ints from stk and discard	INDR/16 index of least year	able typo v v – l l E [

IND8/16 = index of local variable type, x, y = I, L, F, D

CON8/16, D, ATYPE = constant OFFSET16 for branch



#### Moves

MOV DST,SRC	Move SRC to DST
PUSH SRC	Push SRC onto the stack
POP DST	Pop a word from the stack to DST
XCHG DS1,DS2	Exchange DS1 and DS2
LEA DST,SRC	Load effective addr of SRC into DST
CMOV DST,SRC	Conditional move

#### Arithmetic

Add ODO L DOT
Add SRC to DST
Subtract DST from SRC
Multiply EAX by SRC (unsigned)
Multiply EAX by SRC (signed)
Divide EDX:EAX by SRC (unsigned)
Divide EDX:EAX by SRC (signed)
Add SRC to DST, then add carry bit
Subtract DST & carry from SRC
Add 1 to DST
Subtract 1 from DST
Negate DST (subtract it from 0)

### Binary coded decimal

DAA	Decimal adjust
DAS	Decimal adjust for subtraction
AAA	ASCII adjust for addition
AAS	ASCII adjust for subtraction
AAM	ASCII adjust for multiplication
AAD	ASCII adjust for division

### Boolean

AND DST,SRC	Boolean AND SRC into DST
OR DST,SRC	Boolean OR SRC into DST
XOR DST,SRC	Boolean Exclusive OR SRC to DST
NOT DST	Replace DST with 1's complement

### Shift/rotate

SAL/SAR DST,#	Shift DST left/right # bits
SHL/SHR DST,#	Logical shift DST left/right # bits
ROL/ROR DST,#	Rotate DST left/right # bits
RCL/RCR DST,#	Rotate DST through carry # bits

### Test/compare

TST SRC1,SRC2	Boolean AND operands, set flags
CMP SRC1,SRC2	Set flags based on SRC1 - SRC2

#### Transfer of control

INTO	Interrupt if overflow bit is set
INT ADDR	Initiate a software interrupt
LOOPxx	Loop until condition met
IRET	Return from interrupt
RET	Return from procedure
CALL ADDR	Call procedure at ADDR
Jxx ADDR	Conditional jumps based on flags
JMP ADDR	Jump to ADDR

#### Strings

Load string Store string
Store string
Move string
Compare two strings
Scan Strings

#### Condition codes

STC	Set carry bit in EFLAGS register
CLC	Clear carry bit in EFLAGS register
CMC	Complement carry bit in EFLAGS
STD	Set direction bit in EFLAGS register
CLD	Clear direction bit in EFLAGS reg
STI	Set interrupt bit in EFLAGS register
CLI	Clear interrupt bit in EFLAGS reg
PUSHFD	Push EFLAGS register onto stack
POPFD	Pop EFLAGS register from stack
LAHF	Load AH from EFLAGS register
SAHF	Store AH in EFLAGS register

#### Miscellaneous

SWAP DST	Change endianness of DST
CWQ	Extend EAX to EDX:EAX for division
CWDE	Extend 16-bit number in AX to EAX
ENTER SIZE,LV	Create stack frame with SIZE bytes
LEAVE	Undo stack frame built by ENTER
NOP	No operation
HLT	Halt
IN AL,PORT	Input a byte from PORT to AL
OUT PORT,AL	Output a byte from AL to PORT
WAIT	Wait for an interrupt

SRC = source DST = destination # = shift/rotate count LV = # locals

Figure 5-33. A selection of the Pentium II integer instructions.





# Exercício





## EXERCÍCIO DE PROGRAMAÇÃO EM ASSEMBLY

Utilizando as instruções da página anterior, desenvolver em linguagem de máquina (Assembly) um programa que implementa um relógio digital.

### Dados:

- um gerador de sinais no endereço F000, que gera pulsos a cada 1 segundo;
- um display no endereço F001, que apresenta as horas;
- um display no endereço F002, que apresenta os minutos;
- um display no endereço F003, que apresenta os segundos.

Utilizar rótulos (labels) para identificar posições de endereços no programa.

O gerador de sinais e displays são dispositivos de E/S (I/O)

