



NOTES:

SEN0DIO - "Diag LED" on PCB. Set High to turn on the diagonal sensor LED's

SEN1DIO - "Frnt LED" on PCB. Set High to turn on the front sensor LED

SEN2DIO - "Left LED" on PCB. Set High to turn on the left Indicator LED. D1

SEN3DIO - "Mid LED" on PCB. Set High to turn on the middle Indicator LED. D2

SEN4DIO - "Right LED" on PCB. Set High to turn on the right Indicator LED. D3

SEN0AIP - "Left ADC" on PCB. Read via ADC pin to get value from the left photodiode. LDPD1

SEN1AIP - "Front ADC" on PCB. Read via ADC pin to get value from the front photodiode. FPD1

SEN2AIP - "Right ADC" on PCB. Read via ADC pin to get value from the left photodiode. RDPD1

Redesign of the UKMARS Advanced board to use SMD and Duncan's design

Sheet: /
File: UKMARSBOT_RP2040Wall-Sensor-Basic.kicad_sch

Title: Mouse SMD UKMARS Advanced Sensor Board

Size: A4	Date: 2024-12-19	Rev: 1
KiCad E.D.A. 8.0.9		Id: 1/1