## PWM PROTOTYPE

## Manual de Usuario

- 1. Conecte su PWM PROTOTYPE a una fuente de 5V DC.
- 2. Compruebe el funcionamiento de cada dispositivo accionando los switches correspondientes.
  - Switch amarillo acciona Pilot Light
     Amarillo
  - x Switch Verde acciona Pilot Light Verde
  - x Switch Rojo acciona Pilot Light Rojo
  - x Switch negro acciona el abanico
  - x Switch de palanca acciona la bocina
- Si desea varia la velocidad de encendido y apagado de cada uno de los componentes, modifique los valores en la programación base.

```
`timescale 1ns / 1ps
2
                           ## Clock signal
3 🖯 module top(
4
     input CLK,
                           set property -dict {PACKAGE_PIN E3 IOSTANDARD LVCMOS33} [get ports {CLK}];#IO_L12P_T1_MRCC_35 Sch=gclk[100]
5
      output reg [3:0] out
                           create clock -add -name sys clk pin -period 10.00 -waveform {0 5} [get ports {CLK}];
7
8
     reg [32:0] counter;
                           ##Pmod Header JB
9
10
11 ⊖
         always @ (posedge CLK) set property -dict { PACKAGE_PIN E15 IOSTANDARD LVCMOS33 } [get ports { out[0] }]; #IO L11P T1 SRCC 15 Sch=jb p[1]
                          13
     counter <= counter + 1;
                          14
     out[0] <= counter[23];
1.5
     out[1] <= counter[24];
                          16
      out[2] <= counter[25];
17
      out[3] <= counter[18];
18
19 🖨
      end
20 🖨 endmodule
```