


1	Sample Selection Display	s.11
2	Load Sample Buttons	s.12
3	Prelisten Buttons	s.13
4	LOOP Buttons	s.14
5	Listen Button	s.15

6	Sample Selection Dial	s.16
7	Tempo Knob	s.17
8	START/STOP Button	s.18
9	In- and Out-Point Fader	s.19
10	Sample Tempo Knobs	s.20
11	Sequencer	s.21

Front Panel



Power Connector & Switch	s.11	2 CLOCK Output	s.16
3 Audio Output L+R	s.12	4 USB Connector	s.17
5 RJ45 Network Connector	s.12		