



PCB EDGE

X2

X3

X4

X5

X12

X9

X11

1 2
53 54
X1
55 56
99 100

X10

X13

TP2

TP1

X15

X14

U1

U2

C5 R2 C10
C4 R3 C6
C3 C7
C2 C8
C1 C9

C15 R5 C20
C14 R6 C16
C13 C17
C12 C18
C11 C19

X6

X8

X7

