




160,98

155,99

141,11

100,00

Serial #
Serial #

UltraZohm_DigitalVoltage
Revision: 3v00
Designer: T. Wendt
03/2021

FPGA and CPLD
must be configured
accordingly!

Input
Output

SW1

ENABLE
PS_GPIO1
HARD

Jumper to GND (9)

MODE
TTL
CMOS

R5A R4A R3A
R6A R7A R8A
0R 0R 0R

R5B R4B R3B
R6B R7B R8B
0R 0R 0R

R5D R4D R3D
R6D R7D R8D
0R 0R 0R

R5E R4E R3E
R6E R7E R8E
0R 0R 0R

15V PS (9)

Jumpers (2)

LS 3V3 to 5V (1)

LS 5V to 15V (5)

DIG_IO_P

IO_P

IO_N1

GND

GND

GND

X2

X3

UltraZohm

RS422 Receiver (3)
RS422 Transmitter (4)

Termination N (7)