Navigation map

Device-first firmware / current source routes. Physical verification is separate.

01 / Connect

No saved Wi-Fi

Not connected > Tap to pair > Wi-Fi setup. App download QR installs the app; Show pairing QR starts Bluetooth provisioning.

Saved Wi-Fi

Wait for association/IP. Recovery offers Set up Wi-Fi or Later; saved credentials remain.

Local Codex link

Wi-Fi ready without a link prepares a code. A saved link searches its PC. BOOT > Settings > Connections manages Keep link, Pair again or confirmed Forget.

02 / Dashboard and Options

Counter / carousel

Counter mode defaults On: swipe reset, context and model pages. When Off, the available statistics carousel and Cody Home are available.

BOOT / Settings

Short BOOT: Settings, Events, Counters, About. Settings includes Connections, Codex, Display, Behavior and device information. Swipe within categories for more pages.

About and availability

System > Memory > Firmware > project QR. Settings require confirmed storage; statistics are filtered by available data.

03 / Events and local tools

Questions

Open > numbered choice rows > full review > Send. Recipient acknowledgement permits Reply sent. Back, offline and timeout never answer automatically.

Power and sound

PWR toggles standby. Authenticated events can wake retained-link standby. Sounds and quiet hours govern optional cues.

Optional voice

Default: no microphone acquisition. The wake-word variant uses Sophia for standby wake; Codex voice capture is separately gated and excluded from that profile.

09 November 2026 / ERRATA	Map page 1: carousel, Options, local tools and recipient delivery.
13 November 2026 / ERRATA	Map page 1: Counter mode, timer removal and wake profile; device verification remains separate.