Your first picture

Music, artwork and PC readings on your USB display.

1 Get the app

Open Downloads. Choose the **x64** or **ARM64** MSI for your Windows PC and follow the installer. Using a ZIP? Extract the whole folder and keep its files together.

2 Open it


Connect your compatible USB screen. Open **Thermalright VibeWare** from Start, or **ThermalrightVibeWare.exe** in the extracted folder. **Run as administrator** and approve the Windows permission prompt.

3 Pick something to show

Choose **Music**, **System** or **Codex**, then a theme. Look at the preview. For Music, start playback in a player that shares a Windows media session. No music login is needed here. Codex needs its optional plugin setup.

4 Send it to the screen

Choose your screen in **USB DISPLAY** and press **Show on display**. Press **Stop** to stop output. A preview alone does not start output. After reconnecting an active screen, press **Show on display** again.



Real app capture supplied by the maintainer, taken before the rename. Not AI-generated.

Make it yours

A few easy choices

Appearance: change the font. Enable color filters to adjust hue, saturation, brightness and contrast. Filters off means the sliders do not affect the picture.

Refresh: start with **1 s**. Other choices are 500, 250, 100, 50 and 25 ms. This is the requested interval; your PC and screen determine actual speed.

Quality: choose Poor, Low, Medium or High. Start with **High**; lower quality makes smaller, rougher pictures.

Pages: use the page arrows. Edit timings in the theme files. Auto-cycle switches enabled screens every 20 seconds; with one enabled screen, it cycles that screen's themes.

Keep it running, or stop it

Your current setup is saved. **Minimize to tray** keeps the app running by the clock. Use **Close app** or the tray menu's **Exit** to quit.

With Windows startup enabled, the app restores your saved screen and theme in the tray at sign-in. If that screen is not ready yet, it waits for it. **Stop** cancels the wait for this run. The usage guide explains how to turn off future startup.

Good to know

Missing sensor readings stay unavailable. Open **Sensor access** or the sensor guide for setup details.

Themes run Python code on your PC. For now, only download themes from the official repository.

Useful links

Downloads | Full usage guide | Sensor setup | Make a theme

An independent, unofficial hobby project by Umberto Giacobbi, provided as is without warranty. I do not work for Thermalright and am not affiliated with or sponsored by Thermalright. All trademarks belong to their respective owners.