


Snapdragon Flight[™] Kit (Developer's Edition) Quick Start Guide



Package Contents

- Snapdragon Flight development board with Qualcomm® Snapdragon™ 801 processor, 2GB LPDDR3 RAM / 32GB eMMC Flash
- Serial debug adaptor board and USB/serial debug cable
- 5 V DC power supply, power cord and power adaptor cable
 - 1. RAM pop memory on top of Snapdragon 801 processor
 - 2. Serial number
 - 3. Micro USB 3.0 (Type AB) (OTG) port, J2
 - 4. Remote receiver connector, J15 *
 - 5. eMMC flash
 - 6. Serial board connector, J3
 - 7. IMU connector, J9 *
 - 8. Micro SD card slot
 - 9. GPS antenna connector, J6 *
 - 10. WLAN antenna connectors, J7 & J8*
 - 11. Gimbal connector, J12 *
 - 12. ESC connector, J13 *
 - 13. Power connector, J14
 - 14. 4K camera
 - 15. Optic flow camera *
 - * on bottom side





Snapdragon Flight[™] Kit (Developer's Edition) Quick Start Guide



Setup

- 1. Remove the development kit board carefully from the anti static bag
- 2. Connect the serial debug adapter board to the USB/serial debug cable, then connect the adaptor board to the serial board connector, #6, on the board [optional]
- 3. Connect the power adapter cable to the power connector, #13, then connect the power supply to the adaptor cable; the board will boot automatically



Power adapter cable

4. Documentation and software

To access the documentation, platform BSP software and much more, please register at: http://support.intrinsyc.com



Support

You have questions? contact us at support@intrinsyc.com

Should you require additional technical support for your Development Kit you can easily purchase a block of technical support hours from the Intrinsyc store: http://shop.intrinsyc.com

Thank you for acquiring the Snapdragon Flight Kit

The Intrinsyc team