
## **DCB Assembly Summary List**

- Gather materials (5 min)
- Place thermal filler on *flat* side of backplate (1 min)
  - o Remove excess thermal filler in screw holes (5 min)
- Install heat pipes
  - Spread thermal paste on two heat pipes (3 min)
  - o 2x10 M3 countersunk screws (3 min)
  - Place sticker on backplate



- Inspect new DCB
  - Visually inspect DCB: connectors, pins, scratches, solder globs (2 min)
  - Place Kapton tape on solder pads (1 min)
  - Place sticker on board
- Screw in board to baseplate, attach jumpers
  - Note: Check ground isolation with only a few screws in (1 min)
  - 16 M2.5 countersunk screws with 2.5mm Kapton washers and stand-off hex nuts
    (12 min)
  - o 8 M3 countersunk screws with 3mm Kapton washers and hex nuts (6 min)
  - Tighten all screws--don't hurt the board! (3 min)
  - Check ground isolation with all screws in (1 min)
  - Attach 10 jumpers (3 min)
- Assemble 4 mezzanines per board
  - Clip off nubs (4x1=4 min)
  - O Attach VTT/Rx, screw in 2 M1.4 screws (4x2=8 min)
- Update the database, put assembled DCB and mezzanines away (2 min)

Note to self: insert pic of assembled DCB (top) along with mezzanine

