Company [PCBU]:	Gyprock Professionals	Project Name/No:	All Jobs
Work Activity / Task:	INSULATION INSTALLER	Principal Contractor:	Cape Cod Australia Pty Ltd
Prepared by:	Sean Jones	Date:	9.09.14
Signature:		Note: Sign off to be provided at Tool Box talk	

Note: Review of Control Measures -

If there are any tasks that may be included by way of variation to the plans or an alternative approach to the set task. It is a requirement to carry out a specific Risk Assessment for the tasks.

	Task/Problem	Hazard						
7								

Item	Job Step	Potential Hazard	Controls	Responsible Person/s
1	Access to site	 Slips, trips, falls and accessibility. UV / weather exposure. 	 Site specific induction. All "workers" to read the General Construction Safety Plan signage and Risk Assessment form before entering site. Tool box talk to highlight any WHS concerns relative to the site. Ensure that the site and work place access is unobstructed. 	Gyprock Professionals Gyprock Professionals Gyprock Professionals

Reviewed by:	Gary Klomp	Construction Manager
	Principal Contractor's Representative	Position
	At .	10,9,14
	Coignature	Date

		е	У						

	٧			٧		1			

								and the same of th	
					<u></u>				

Item	Job Step	Potential Hazard	Controls	Responsible Person/s
1	Access to site	Slips, trips, falls and accessibility.		Gyprock Professionals
		UV / weather exposure.	 Site specific induction. All "workers" to read the General Construction Safety Plan signage and Risk Assessment form before entering site. Tool box talk to highlight any WHS concerns relative to the site. Ensure that the site and work place access is unobstructed. Ensure all weather access to work areas. Provision of designated waste areas. Storage of materials in designated areas. Regular site clean ups. 	Gyprock Professionals Gyprock Professionals Gyprock Professionals Cape Cod Cape Cod Gyprock Professionals Cape Cod
				Professionals & Cape Cod
2	Unloading of equipment and	Manual handling injuries.	Training of "workers" in correct lifting and carrying methods.	Gyprock Professionals

Reviewed by:	Gary Klomp	Construction Manager		
•	Principal Contractor's Representative		Position	
	//	_		

	materials	 Slips, trips and falls. Proximity of other "workers". Public access. 	Unload and move the tools and materials to a designated area to keep footpath / work place access clear.	Gyprock Professionals
3	Setting up equipment	 Manual handling injuries. Slips, trips and falls. Proximity of other "workers". 	 Set up in a clear area and maintain a clear travel path. Training of "workers" in the setting up of ladders / trestles. 	Gyprock Professionals Gyprock Professionals
4	Ground floor installation	 Slips, trips, falls and accessibility. Electrocution. Fall from height. Hazardous substances. Exposure to noise Exposure to dust. Manual handling. Sprains and strains. Cuts and abrasions. Proximity of other "workers". Public access. 	 Assess the site conditions and conduct a Risk Assessment before commencing. Identify location of electrical and water services Identify that the electrical service has been isolated or safely recommissioned before commencing work. Ensure that all exposed openings and voids in the floor are guard railed or covered. Training of "workers" in correct lifting and carrying methods. Ensure that the correct lifting and carrying techniques are used at all times. Rotate "workers" and vary tasks performed. Training of "workers" in safe working from ladders. Check the ladder / trestles for damage / defect before use. Check that the trestle work platform is stable before use. Limit the use of ladders as work platforms. Provide MSDS for hazardous 	Gyprock Professionals Cape Cod & Gyprock Professionals Cape Cod & Gyprock Professionals & Cape Cod Gyprock Professionals & Cape Cod Gyprock Professionals & Cape Cod
		·	 Provide MSDS for hazardous substances – insulation product. 	Gyprock

Reviewed by:	Gary Klomp	Construction Manager		
•	Principal Contractor's Representative		Position	
	/ //			

10,9,14

 Use scaffolding for void and raked ceilings. Storage of materials in 	ck sionals ck sionals ck
 Monitor for air borne dust when installation is being undertaken. Ensure that adequate lighting and ventilation is available. Use scaffolding for void and raked ceilings. Storage of materials in designated areas. Maintain a clean and tidy work area by placing off cuts of insulation in the plastic packaging and tie off in manageable parcels for easy handling and disposal in the designated waste area. Profess Gyproduction Gyproducti	ck sionals ck sionals ck sionals
Gyprod Profes & Cape Gyprod	sionals ck sionals e Cod
Gypro	ck

Reviewed by:	Gary Klomp	Construction Manager		
•	Principal Contractor's Representative		Position	

& Ignature

10/9/14 Date

				Professionals & Cape Cod Gyprock Professionals & Cape Cod Gyprock Professionals & Cape Cod Gyprock Professionals
5	Carry materials up ramp. External access to upper floor	 Slips, trips, falls and accessibility. Electrocution. Fall from height. Hazardous substances. Exposure to noise Exposure to dust. Manual handling. Sprains and strains. Cuts and abrasions. Proximity of other "workers". 	 Assess the site conditions including the weather and conduct a Risk Assessment before commencing work. Identify that the electrical service has been isolated and that 'tiger tails' are in place as protection from overhead wires and points of attachment before commencing the installation work. Ensure that the guard rails to the ramp are in place and that the surface of the ramp is clean before commencing. Ensure that the perimeter protection is in place [scaffolding and edge protection] and level walk platforms are in place before accessing work from roof surface. Ensure that the edge protection to the roof surface [roof rail] and level work platforms are in place before accessing the upper floor level from roof surface. Ensure that the perimeter protection [temporary guard rail] is in place to balconies before commencing. 	Gyprock Professionals Cape Cod Gyprock Professionals & Cape Cod Gyprock Professionals & Cape Cod Gyprock Professionals & Cape Cod

Reviewed by:	Gary Klomp	<u>Construction Manager</u>		
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	Principal Contractor's Representative		Position	

Signature Date

 Training of "workers" in safe working at heights and movement on scaffolding and roof surfaces. 	Gyprock Professionals
 Training of "workers" in safe working at heights including over internal stairwell voids. Ensure that all exposed openings 	Gyprock
and voids in the floor are guard railed or covered.Provide scaffolding or platform	Professionals
cover to the stairwell void. • Ensure that temporary guard	Gyprock
rails and scaffolding is in place over stairwell void before commencing work.	Professionals & Cape cod
Identify that the electrical service has been isolated or safely recommissioned before	Cape Cod
 commencing work. Provide "Restricted Access" warning signage and establish a 	Gyprock Professionals
"No access area" by barricading to prevent access of anyone not connected with the installation	Gyprock
into the work area.Training of "workers" in correct lifting and carrying methods.	Professionals & Cape
 Ensure that the correct lifting and carrying techniques are used at all times. 	Gyprock
 Rotate "workers" and vary tasks performed. 	Professionals
 Training of "workers" in safe working from ladders. 	
Check the ladder for damage / defects before use.	Comments
 Check that the ladder is stable before use and is secured top and bottom. 	Gyprock Professionals
 Limit the use of ladders as work platforms. Provide MSDS for hazardous 	Gyprock Professionals
Provide MSDS for Hazardous	

Reviewed by:	Gary Klomp	<u>Construction Manager</u>		
	Principal Contractor's Representative	-	Position	

10,9,14 Date

Allen	substances i.e. insulation	
	product.	Gyprock
	Training of "workers" in the safe	Professionals
	handling and use of the insulation product.	Gyprock
	Use appropriate PPE – safety glasses, appropriate footwear in ceiling void, noise and particulate	Professionals
	dust protection [disposable] and gloves.	Gyprock Professionals
	 Monitor for air borne dust when installation is being undertaken. 	Gyprock
	 Ensure that adequate lighting and ventilation is a available. 	Professionals
	 Use long stick where insulation is required in hard to reach sections so as to avoid overstretching. 	Gyprock Professionals
	 Use scaffolding for void and raked ceilings. 	Gyprock Professionals
	 Storage of materials in designated areas. 	
	Maintain a clean and tidy work area by placing off cuts of insulation in the plastic packaging and tie of in	Gyprock Professionals
	manageable parcels for easy handling and disposal in the designated waste area.	Gyprock Professionals
		Gyprock Professionals
		Gyprock Professionals
		& Cape Cod
		Gyprock
		Professionals
		1

Reviewed by:	Gary Klomp	Construction Manager		
-	Principal Contractor's Representative		Position	

109/12/

SAFE WORK METHOD STATEMENT [cont.]

Page 9 of 9

 		Gyprock Professionals
		& Cape Cod
		Gyprock Professionals
		& Cape Cod
		Gyprock Professionals

Reviewed by:	Gary Klomp	Construction Manager		
,	Principal Contractor's Representative	•	Position	
		>		

Signature Date