Company Name:	Fresh Start Construction	Project Name/No:	All Jobs
Work Activity / Task:	ASBESTOS OR [ACM] [ACD] REMOVAL - OVER 10.0m ²	Principal Contractor:	Cape Cod Australia Pty. Ltd.
Prepared by:	Christian Moerman	Date: 17/9/14	
Signature:	comme	Note: Sign off to be provided at Tool Box talk	

Note 1: Removal of materials that *may contain asbestos* [ACM] or [ACD] must meet the requirements of WHS Regulation 2011 - Chapter 8

Note 2: Review of Control Measures - If there are any tasks that may be included by way of variation to the plans or an alternative approach to the set task, it is a requirement to carry out a "Specific Risk Assessment" for the tasks.

Item	Job Step	Potential Hazard	Controls	Responsible Person/s
1	Access to site	 Slips, trips, falls and accessibility UV light / weather exposure 	 Site specific induction. All "workers" to register before entering the site; to read the General Construction Safety Plan signage; and to read the Site Specific Risk Assessment form. 	The Duilde Fresh Start
			 Tool box talk to highlight any WHS concerns. Ensure site access is unobstructed. Ensure all weather access to work areas. Wear appropriated PPE - hat, long sleeves, sun screen, sunglasses, and fluids and reduce 	Fresh Start Fresh Start Fresh Start
			 exposure where possible. Provision of designated waste areas. Storage of materials in designated areas. Regular site clean ups. 	The Buller Fresh Start The Buller

Reviewed by: _	Gary Klomp	Construction Manager
	On behalf of Cape Cod	Position

Signature Date

Page 2 of 8 v1.13

Item	Job Step	Potential Hazard	Controls	Responsible Person/s
2	Unloading plant and equipment	 Manual task injuries Slips, trips and falls. Proximity of other "workers" and public. Public access. 	 Team lifting and carrying. Training of "workers" in correct lifting methods. Unload and move the equipment to designated area to keep footpath / work place access clear. 	Fresh start Fresh start
3	Setting up equipment	 Manual task injuries Slips, trips and falls. Proximity of other "workers". Public access. 	 Set up in a clear area and maintain a clear travel path. Training of "workers" in setting up of electrical leads, power tools and nail guns. Ensure proper use of all safety guards provided to plant and equipment. Ensure all electrical leads, plant and equipment have current tagging. Ensure electrical equipment is attached to a residual current device [RCD]. 	Fresh Sturt Fresh Sturt Fresh Sturt Fresh Sturt Fresh Sturt Fresh Sturt
4	Removing asbestos or ACM sheet from ground level	 Slips, trips, falls and accessibility Fall from height Hazardous materials Exposure to dust Identification of services Electrocution Exposure to noise Manual task injuries Cuts and abrasions. Proximity of other "workers" and public. Public access. 	 Assess site conditions including weather and conduct a Site Specific Risk Assessment before commencing. Identify the location of the electrical service and that the electrical service has been isolated or safely relocated before commencing work. Provide "Restricted Access" warning signage and establish a "No access area" by barricading to prevent access of anyone not connected with the removal activity into the work area and to control contamination. 	Fresh Start Fresh Start The Builder

Reviewed by:	Gary Klomp	Construction Manager
	On behalf of Cape Cod	Position

Signature

19 | 4 | 4 | Date

Page 3 of 8 v1.13

Item	Job Step	Potential Hazard	Controls	Responsible Person/s
			Position warning signage containing the words "DANGER ASBESTOS REMOVAL IN PROGRESS" in a prominent visible position at the front of the site. Signage to include the details of the licensed Contractor [PCBU].	The Builder
			 Seal all windows and doors to prevent dust entering the building during the removal and clean up process. 	Fresh start
			 All products and materials "that may" contain asbestos [ACM] or [ACD] are to be stored, transported and disposed of in accordance with the NSW Protection of the Environment Operations Act [1997] and NSW Protection of the Environment Operations [Waste] Regulation [2005] 	The Builder
			 Prior to the removal process all products and materials "that may" contain asbestos [ACM] or [ACD] to be sealed with PVA sealant or kept damp. Prevent and or contain excess run off water. 	F-1854 STU-7
			 All products and materials "that may" contain asbestos [ACM] or [ACD] is to be either wrapped in recommended 200-micron thick plastic sheeting or placed in leak proof lined bins or vehicles and covered. 	Fress 572-7
			All products and materials "that may" contain asbestos [ACM] or [ACD] is to be stored in a secure area and removed from site as	The Builder

Reviewed by:	Gary Klomp	Construction Manager	
•	On behalf of Cape Cod	Position	
	1/-7		

Signature

19 | 9 | 4 Date

Page 4 of 8 v1.13

Item	Job Step	Potential Hazard	Controls	Responsible Person/s
			soon as practical in a covered leak proof vehicle.	
			 All products and materials "that may" contain asbestos [ACM] or [ACD] is to be disposed of in a manner, and at a site approved by the NSW Office of Environment and Heritage [OEH], appropriate disposal Authority or Local Council. 	The Bulder
			 Care in removing wall sheets and eave soffits to minimise breakage of sheets - where possible keep sheets intact. 	Fresh sturt
			 Ensure that adequate lighting and ventilation is a available. 	Fresh Start
			 Systematic safe removal of materials. 	Fresh STRAT
			 Training of "workers" in safe working from step and extension ladders. 	Fresh SZE-7
			 Training of "workers" in the safe removal and handling of products and materials "that may" contain asbestos [ACM] or [ACD]. 	Fresh start
			 Ensure "workers" wear safety glasses, noise protection, respiratory protection [disposable], protective footwear, disposable coveralls and gloves during the removal and clean up process. 	Fresh 57a-7
			 Regularly monitor for air borne dust when removal work is being undertaken. 	The
			 Pick up visible asbestos debris around the removal area, then decontaminate using wet 	Fresh sturt

Reviewed by:	Gary Klomp	Construction Manager
	On behalf of Cape Cod	Position

Signature

191914 Date

Page 5 of 8 v1.13

Item	Job Step	Potential Hazard	Controls	Responsible Person/s
			methods or suitable vacuum cleaner. Use approved vacuum cleaning equipment [HEPA] that complies with AS/NZS 60335.2.69 — Industrial vacuum cleaners or its equivalent for particulates hazardous to health, to prevent the release of lead containing dust while it is being removed. Do not use household vacuum cleaners. PVA seal residues of asbestos cement that cannot be removed from timber framed members. Plastic sheets used for drop sheets and debris is not be reused and is to be disposed of as asbestos waste. Training of "workers" in correct lifting and carrying methods. Ensure that the correct lifting and carrying techniques are used	Supplied by the builder Supplied by builder applied by Frost start Frest start Frest start
5	Stripping of asbestos or ACM sheet roof covering	 Slips, trips, falls and accessibility. UV light / weather exposure. Fall from height. Hazardous materials. Identification of services. 	 at all times. Rotate "workers" and vary tasks performed. Ensure running water is available Assess the site conditions including the weather and conduct a Site Specific Risk Assessment before commencing. Provide "Demolition in Progress" and "Restricted Access" warning signage and establish a "No access area" by barricading to 	Fresh STUT The Builder Fresh STUT Supplied by The Builder erected by Fresh STUT
		Electrocution. Falling objects.	prevent access of anyone not connected with the removal activity into the work area and to control contamination. Provide a	

Reviewed by: _	Gary Klomp	Construction Manager	
Reviewed by.	On behalf of Cape Cod	Position	
		1919114	

Signature

Page 6 of 8 v1.13

Item	Job Step	Potential Hazard	Controls	Responsible Person/s
		 Exposure to dust. Exposure to noise. Manual task injuries Sprains and strains. Cuts and abrasions. Proximity of other "workers". Public access. 	spotter where necessary. Position warning signage containing the words "DANGER ASBESTOS REMOVAL IN PROGRESS" in a prominent visible position at the front of the site. Signage is to include the details of the licensed Contractor [PCBU].	Fresh stert
			Identify that the electrical service has been isolated and that 'tiger tails' are in place as protection from overhead wires and points of attachment before commencing.	Fresh start
			Use Licensed Electrician to isolate, disconnect and relate existing services.	The Bullher
			Ensure that the guard rails to the ramp are in place and that the surface of the ramp is clean before commencing.	Fresh Glanz
			 Ensure that the perimeter protection is in place [scaffolding and edge protection] are in place before accessing work from roof surface. 	Fresh Start
			 Ensure that the edge protection to the roof surface [roof rail] is in place before accessing the roof surface. 	Fresh grary
			 Training of "workers" in safe working at heights and safe movement on scaffolding and on roof. 	Fresh Start
			 Training of "workers" in the safe removal and handling of products and materials "that may" contain asbestos. 	Fresh Sturt

Reviewed by:	Gary Klomp	Construction Manager
	On behalf of Cape Cod	Position
	,	

Signature 1919 Date

Page 7 of 8 v1.13

ltem	Job Step	Potential Hazard	Controls	Responsible Person/s
			 Ensure that the scaffolding is safe and erected by a qualified Scaffolder. 	Fresh Start
			Check the access ladder for damage / defects before use.	Fress start
			Check that the ladder is stable and secured top and bottom before use.	Fress 37art
			Correct use of access ladder.	Fr 899 5 Carl
			 Limit use of ladders as working platforms. 	Fress Stert
			 Ensure "workers" wear hats, safety glasses, noise protection, respiratory protection [disposable], protective footwear, disposable coveralls and gloves during the removal and clean up process. 	
			Systematic safe removal of materials.	Frosh STR-7
			 Training of "workers" in correct lifting and carrying methods. 	Fresh start
			Team lifting and carrying.	Fress) car
			 Rotate "workers" and vary tasks performed. 	Frais Start
			 Ensure that materials are not stored on roof or scaffold. 	Front start
			 Prior to the removal process asbestos seal the roofing sheets with PVA sealant or wet down. 	Frogh Star7
			 Ensure dampening of the roofing sheets is done well before removal to allow the roof surface to dry sufficiently so "workers" do not slip. 	Frost start
			 Prevent and or contain excess run off water from the roof surface. 	Frost grant

Reviewed by:	Gary Klomp	Construction Manager
•	On behalf of Cape Cod	Position

Signature Date

Page 8 of 8 v1.13

Item	Job Step	Potential Hazard	Controls	Responsible Person/s
			 Remove fixings and remove the asbestos cement sheets with minimal breakage. Lower whole sheets to the ground where possible and place in prepared designated waste area. Provide a spotter where necessary. 	Fresh grant
			 Regularly monitor for air borne dust when removal work is being undertaken. 	The Boulder
			 Provide shade cloth around work area and wet down dust as required to prevent wind borne dust. 	The Builder
			 Pick up visible asbestos debris in the roof space and around the removal area and then decontaminate using wet methods or suitable vacuum cleaner. 	Fresh 57ar7
			 PVA seal residues of asbestos cement that cannot be removed from timber framed members. 	Fresh Start
			 Plastic sheets used for drop sheets and debris is not be reused and is to be disposed of as asbestos waste. 	Frosh Stary
			Regular site clean ups.Ensure running water is available.	The Builder
-	Site clean up on	Manual task injuries Exposure to dust	Remove any temporary barricades if no longer required	Fresh STR-7 Fresh STR-T Fresh STR-T
	completion of work	Exposure to hazardous substances-	designated waste storage at the	Fresh start
			 Leave site / work area in a clean and tidy condition 	trest "

Reviewed by:	Gary Klomp	Construction Manager	
•	On behalf of Cape Cod	Position	
	47		

Signature

19|9| |4 Date