Company [PCBU]:	Tobi Spiteri	Project Name/No:	All Jobs
Work Activity / Task:	SCAFFOLDER- ERECTION	Principal Contractor:	Cape Cod Australia Pty Ltd
Prepared by:	Tobi Spiteri	Date:	28/07/15
Signature:		Note: Sign off to be provided at Tool Boxtalk	

Note: Review of Control Measures -

If there are any tasks that may be included by way of variation to the plans or an alternative approach to the set task. It is a requirement to carry out a specific Risk Assessment for the tasks.

Task/ Problem	Hazard	Lik	elihoo	F	esult		Possible Control	Action By	Date
Variation to plan	Unknown		d				Tool Box Talk	Contractor	
Change of Brief							Work Method Statement	Supervisor	
		√		$\sqrt{}$		1			
							14.74.11		

Item	Job Step	Potential Hazard	Controls	Responsible Person/s
1	Access to site.	 Slips, trips, falls and accessibility. UV / weather exposure. 	Site specific induction. All "workers" to read the General Construction Safety Plan signage and Risk Assessment form before entering site.	Cape Cod Contractor
			 Tool box talk to highlight any WHS concerns relative to the site. Ensure that the site and work place access is unobstructed. 	Contractor
			 Ensure all weather access to work areas. 	Cape Cod
			Wear appropriated PPE- hat, long sleeves, sun screen, sunglasses, and fluids and reduce exposure where possible.	Contractor Contractor
	ved by: pal Contractor's Repr	Gary Klomp esentative	 Storage of materials / Construction designated areas. 	Manager
			Provide and maintain barricades	Contractor

Sanature

Item	Job Step	Potential Hazard	Controls	Responsible Person/s
			to all materials stored on footpath and on site. Regular site dean ups.	Cape Cod
				Cape Cod
2	Unloading tools, ladders and scaffold components	 Manual handling injuries. Slips, trips and falls. Proximity of other "workers". Public access. 	 Team lifting and carrying. Training of "workers" in correct lifting and carrying methods. Unload and move the tools, ladders and scaffold components to a designated area to keep 	Contractor Contractor Contractor
3	Setting up	Manual handling injuries. Sips, tripsand falls.	footpath / work place access clear. Assess the site conditions including the weather and conduct a Risk Assessment	Contractor
	 Falls from height. Uneven site. UV / weather exposure. Proximity of other 	before commending. Set up in a dear area and maintain a dear travel path. Identify the location of the electrical, sewer and stormwater services.	Contractor Cape Cod	
		"workers". • Public access.	Identify that the electrical service has been isolated or safely recommissioned before commencingwork.	Cape Cod
			 All scaffolding is to be erected by WorkCover NSW certified Scaffolders. 	Cape Cod
			 Training of "workers" in the setting up of ladders, electrical equipment and use of safety harnesses. 	Contractor
			 Ensure the proper use of all safety guards and systems provided. 	Contractor
			 Ensure that all power tools and electrical leads have current tagging. 	Contractor
			Ensure that power tools are attached to a residual current	Contractor

Construction Manager
Position
1

Signature //

Item	Job Step	Potential Hazard	Controls	Responsible Person/s
			device [RCD]. Provide "Restricted Access" warning signage. Establish a "No access area" to work areas by barricading to prevent access to the area of work. Provide a spotter where necessary.	Contractor Contractor
4	Erection of scaffold to 2.0m. Passing scaffolding components from building level or ground.	 Slips, trips, falls and accessibility. Fall from heights. Manual handling injuries. Sprains and strains. Outs and abrasions Electrocution. Exposure to noise. Exposure to dust. UV / weather exposure. Proximity of other "workers". Public access. 	 Assess the site conditions and conduct a Risk Assessment before commending. Identify the location of the electrical, sewer and stormwater services. Identify that the electrical service has been isolated and that 'tiger tails' are in place as protection from overhead wires and points of attachment before commencing. Provide "Restricted Access" warning signage. Establish a "No access area" below overhead work areas by barricading to prevent access to the area of work. Provide a spotter where necessary. Training of "workers" in correct lifting and carrying methods. Ensure correct lifting and carrying techniques are used at all times. Rotate "workers" and vary tasks performed. Ensure "workers" have safety glasses, noise and dust 	Contractor Cape Cod Cape Cod Cape Cod Contractor Contractor Contractor Contractor Contractor Contractor
			protection, appropriate protective footwear, hard hat and gloves. Training of "workers" in the safe	Contractor

Reviewed by:	Gery Klomp	Constru	ction Manager
Principal Contractor'	s Representative	Position	•
			.
	8gnature	Dat	e

Item	Job Step	Potential Hazard	Controls	Responsible Person/s
			use of power tools and equipment. Ensure that all power tools have working safety guards Storage of surplus scaffold components in designated areas so not to endanger the public or other "workers". Maintain a clean and tidy work area. Clearly display "Scaffold incomplete" sign to incomplete scaffold at all times prior to sign off of the scaffold.	Contractor Cape Cod Cape Cod Cape Cod
5	Continue to erect scaffold top out Work from two [2] plank width working platform	 Sips, trips, falls and accessibility. Fall from heights. Manual handling injuries. Sprains and strains. Outs and abrasions Electrocution. 	 Assess the site conditions and conduct a Risk Assessment before commencing. Identify that the electrical service has been isolated and that 'tiger tails' are in place as protection from overhead wires and points of attachment before commencing. 	Contractor
		 Exposure to noise. Exposure to dust. UV / weather exposure. Proximity of other "workers". 	 Provide "Restricted Access" warning signage. Establish a "No access area" below overhead work areas by barricading to prevent access to the area of work. Provide a spotter where necessary. 	Cape Cod Contractor
		Public access.	 Training of "workers" in correct lifting and carrying methods. Ensure correct lifting and carrying techniques are used at all times. Rotate "workers" and vary tasks performed. Training of "workers" in the setting up of ladders and use of safety harnesses. Ensure workers have safety 	Contractor Contractor Contractor

Reviewed by:	Gary Klomp	Construction Manager
Principal Contractor	's Representative	Position
		7/8

Date

Item	Job Step	Potential Hazard	Controls	Responsible Person/s
			glasses, noise and dust protection, appropriate protective footwear, hard hat and gloves.	Contractor
			Training of "workers" in the safe use of power tools and equipment.	Contractor
			 Ensure that all power tools have working safety guards Storage of surplus scaffold 	Contractor
			components in designated areas so not to endanger the public or other "workers"	Cape Cod
			Maintain a clean and tidy work area.	Cape Cod
			Clearly display "Scaffold incomplete" sign to incomplete scaffold at all times prior to sign off of the scaffold.	Cape Cod
6	Continue to erect scaffold top out.	Slips, trips, falls and accessibility. Fall from heights	Assess the site conditions and conduct a Risk Assessment before commending.	Contractor
	Access to be built up with scaffold. Access to scaffold by ladder,	 Manual handling injuries. Sprains and strains. Outs and abrasions. Electrocution. 	Identify that the electrical service has been isolated and that 'tiger tails' are in place as protection from overhead wires and points of attachment before commencing.	Contractor
	balcony deck internal stair or ladder.	Exposure to noise. Exposure to dust	Provide "Restricted Access" warning signage.	Cape Cod
		 UV / weather exposure. Proximity of other "workers". 	Establish a "No access area" below overhead work areas by barricading to prevent access to the area of work. Provide a spotter where necessary.	Cape Cod
		Public access.	Training of "workers" in correct lifting and carrying methods.	Contractor
			Ensure correct lifting and carrying techniques are used at all times.	Contractor
			Rotate "workers" and vary tasks	

Reviewed by: Gary Klomp	Construction Manager
Principal Contractor's Representative	Position
Signature	7/8 Date

SAFEWORK METHOD STATEMENT [cont.]

Page 6 of 6

Item	Job Step	Potential Hazard	Controls	Responsible Person/s
			performed. • Ensure "workers" have safety glasses, noise and dust protection, appropriate protective footwear, hard hat and gloves.	Contractor Contractor
			Training of "workers" in the safe use of power tools and equipment.	Contractor
			 Ensure that all power toolshave working safety guards. Storage of surplusscaffold components in designated areas so not to endanger the public or "workers". 	Contractor Cape Cod
			 Maintain a dean and tidy work area. Gearly display "Scaffold incomplete" sign to incomplete scaffold at all times prior to sign off of the scaffold. 	Cape Cod Cape Cod
7	Ste dean up on completion of work	 Manual task injuries Exposure to dust Exposure to hazardous 	 Remove any temporary barricades if no longer required Place all rubbish/ debris in designated waste storage area 	Cape Cod
		substances	Leave site/ work area in a dean and tidy condition	Contractor Contractor

Reviewed by:	Gary Klomp	Construction Mana	ager
Principal Contractor's Representative		Position	

agnature

/// O Date