Company [PCBU]:	Gyprock Professionals	Project Name/No:	All Jobs
Work Activity / Task:	Demolition and removal of materials by hand	Principal Contractor:	Cape Cod Australia Pty Ltd
Prepared by:	Sean Jones	Date:	9.09.14
Signature:	DA	Note: Sign off to be provided at Tool Box talk	

Note: Review of Control Measures -

If there are any tasks that may be included by way of variation to the plans or an alternative approach to the set task. It is a requirement to carry out a specific Risk Assessment for the tasks.

Task/Problem	Hazard						
			13				

Item	Job Step	Potential Hazard	Controls	Responsible Person/s
1	Access to site	 Slips, trips, falls and accessibility. UV / weather exposure. 	 Site specific induction. All "workers" to read the General Construction Safety Plan signage and Risk Assessment form before entering site. Tool box talk to highlight any WHS concerns relative to the site. Ensure that site and work place access is unobstructed. 	Gyprock Professionals Gyprock Professionals Gyprock Professionals Gyprock Professionals

Reviewed by:	Gary Klomp Constructi	on Manager
	Principal Contractor's Representative	Position
		10,9,14
	Signature	Date

			 Ensure all weather access to work areas. Wear appropriated PPE - hat, long sleeves, sun screen, sunglasses and fluids and reduce exposure where possible. Provision of designated waste areas. Storage of materials in designated areas. Regular site clean ups. 	Gyprock Professionals Gyprock Professionals Cape Cod Cape Cod Cape Cod & Gyprock Professionals
2	Unloading plant, equipment and tools	 Manual handling injuries Slips, trips and falls. Proximity of other "workers". Public access. 	 Team lifting and carrying. Training of "workers" in correct lifting and carrying methods. Unload and move the equipment to designated area to keep footpath / work place access clear. 	Gyprock Professionals Gyprock Professionals Gyprock Professionals
3	Setting up equipment	 Manual handling injuries Slips, trips and falls. Proximity of other "workers". Public access. 	 Set up in a clear area and maintain a clear travel path. Training of "workers" in setting up of electrical leads and power tools and pneumatic tools. Ensure proper use of all safety guards provided. Ensure that all power tools and electrical leads have current tagging. Ensure that all power tools are attached to a residual current device [RCD]. 	Gyprock Professionals Gyprock Professionals Gyprock Professionals Gyprock Professionals Gyprock Professionals
4	Stripping of external cladding	 Slips, trips, falls and accessibility UV / weather exposure Electrocution Hazardous materials Exposure to dust Exposure to noise 	 Assess the site conditions and conduct a Risk Assessment before commencing. Identify that the electrical service has been isolated and that 'tiger tails' are in place as protection from overhead wires and points of attachment 	Gyprock Professionals Cape Cod

Reviewed by:	Gary Klomp	Construction Manager
	Principal Contractor's Representative	Position
	Signature	10,9,14 Date

		 Manual handling Cuts and abrasions. Proximity of other "workers". Public access. 	before commencing installation work. Provide "Demolition in Progress" and "Restricted Access" warning signage. Establish a "No access area" to work areas by barricading to	Gyprock Professionals Gyprock Professionals
			prevent access to the area of work. Provide a spotter where necessary. Identify any products or materials that <i>may</i> contain asbestos.	Cape Cod
			Ensure that the scaffolding is safe and erected by a qualified Scaffolder before commencing.	Cape Cod Cape Cod
			Ensure that the scaffolding and edge protection is in place before commencing. Correct use of ladder.	Gyprock Professionals
			 Correct use of ladder. Use appropriate PPE – safety glasses, footwear, noise / hearing protection, dust protection [disposable], gloves 	Gyprock Professionals
			 and hard hats. Training of "workers" in the safe use of hand tools and power tools. 	Gyprock Professionals
			 Systematic safe removal of materials. Team lifting and carrying. 	Gyprock Professionals Gyprock
			Storage of materials in designated waste areas	Professionals Gyprock Professionals
			 Regular site clean ups. Ensure materials are not stored on roof surface or scaffold. 	Gyprock Professionals
5	Demolishing of ground floor by hand	Slips, trips, falls and accessibility.UV / weather	 Assess the site conditions and conduct a Risk Assessment before commencing. 	Gyprock Professionals
		exposure.Hazardous materials.Identification of	 Identify any products or materials that may contain asbestos. 	Cape Cod
		services.	 Identify services and make sure all electrical, gas, water and 	Cape Cod

Reviewed by:	Gary Klomp	Construction Manager
·	Principal Contractor's Representative	Position
		10,9,12
	Signature	, , Date

6	Domalishina	 Electrocution. Gas explosions. Falling objects. Exposure to dust. Exposure to noise. Manual handling. Heavy lifting. Cuts and abrasions. Proximity of other "workers". Public access. 	sewerage services have been isolated or safely relocated before commencing. Use Licensed Electrician and Plumber to isolate, disconnect and relate existing services. Provide "Demolition in Progress" and "Restricted Access" warning signage. Establish a "No access area" to work areas by barricading to prevent access to the area of work. Provide a spotter where necessary. Monitor air quality. Ensure that all exposed openings and voids in the floor are guard railed or covered. Use appropriate PPE – safety glasses, footwear, noise / hearing protection, dust protection [disposable], gloves, and hard hats. Training of "workers" in the safe use of pneumatic and electrical power tools. Systematic safe removal of materials. Team lifting and carrying. Provide shade cloth around work area and wet down dust as required to prevent wind borne dust. Storage of materials in designated waste areas Regular site clean ups. Ensure all exposed nails are removed. Assess the site conditions and	Cape Cod Gyprock Professionals Gyprock Professionals Cape Cod Gyprock Professionals Gyprock Professionals Gyprock Professionals Gyprock Professionals Cape Cod Gyprock Professionals Gyprock Professionals Gyprock Professionals Gyprock Professionals Cape Cod
U	Demolishing brickwork by hand	 accessibility. Hazardous materials. Identification of services. Electrocution. 	conduct a Risk Assessment before commencing. Provide "Demolition in Progress" and "Restricted Access" warning signage.	Gyprock Professionals

Reviewed by:	Gary Klomp	Construction Manager
•	Principal Contractor's Representative	Position
	Signature	10,9,1 X

Falling objects. Exposure to dust. Exposure to noise. Manual handling. Heavy lifting. Cuts and abrasions. Proximity of other trades. From trades. From the trades and plumber to isolate, disconnect and relate existing services. Use appropriate PPE – safety glasses, footwear, noise / hearing protection, dust protection [disposable], gloves, and hard hats. Fraining of "workers" in safe use of pneumatic and electrical power tools. Systematic safe removal of materials. Fram lifting and carrying. To upper floor areas provide a shute for materials into designated waste area as required. Provide a spotter where necessary. Monitor air quality. Provide shade coth around work area and wet down dust as required to prevent wind borne dust. Storage of materials in designated waste areas Regular site clean ups. From the area of work. Professionals cape Cod Assess the site conditions including the weather and conduct a Risk Assessment			Gas explosions.	• Establish a "No access area" to	Gyprock
Manual handling. Heavy lifting. Cuts and abrasions. Proximity of other trades. Proximity of other trades. Identify any products or materials that may contain asbestos. Identify services and ensure all electrical, gas, water and sewerage services have been isolated or safely relocated before commencing. Use Licensed Electrician and Plumber to isolate, disconnect and relate existing services. Use appropriate PPE—safety glasses, footwear, noise / hearing protection, dust protection (disposable), gloves, and hard hats. Training of "workers" in safe use of pneumatic and electrical power tools. Systematic safe removal of materials. To upper floor areas provide a shute for materials into designated waste area as required. Provide a spotter where necessary. Monitor air quality. Provide shade cloth around work area and wet down dust as required to prevent wind borne dust. Storage of materials in designated waste areas Regular site clean ups. Slips, trips, falls and accessibility. eldentify any products or materials that may contain asbestos. Identify any products or material as the deletrical gas, water and severage services have been isolated or safely relocated before commencing. Cape Cod Cape Cod			Falling objects.Exposure to dust.	prevent access to the area of work. Provide a spotter where	Professionals
electrical, gas, water and sewerage services have been isolated or safely relocated before commencing. • Use Licensed Electrician and Plumber to isolate, disconnect and relate existing services. • Use appropriate PPE – safety glasses, footwear, noise / hearing protection, dust protection [disposable], gloves, and hard hats. • Training of "workers" in safe use of pneumatic and electrical power tools. • Systematic safe removal of materials. • Team lifting and carrying. • To upper floor areas provide a shute for materials ind designated waste area as required. Provide ashade cloth around work area and wet down dust as required to prevent wind borne dust. • Storage of materials in designated waste areas • Regular site clean ups. • Slips, trips, falls and accessibility.			Manual handling.Heavy lifting.	Identify any products or materials that <i>may</i> contain	Cape Cod
Use Licensed Electrician and Plumber to isolate, disconnect and relate existing services. Use appropriate PPE – safety glasses, footwear, noise / hearing protection, dust protection [disposable], gloves, and hard hats. Training of "workers" in safe use of pneumatic and electrical power tools. Systematic safe removal of materials. Team lifting and carrying. To upper floor areas provide a shute for materials into designated waste area as required. Provide a spotter where necessary. Monitor air quality. Provide shade cloth around work area and wet down dust as required to prevent wind borne dust. Storage of materials in designated waste areas Storage of materials in designated waste areas Regular site clean ups. Stripping of existing roof Stripping of existing roof Slips, trips, falls and accessibility. Cape Cod			=	electrical, gas, water and sewerage services have been isolated or safely relocated	Cape Cod
glasses, footwear, noise / hearing protection, dust protection (disposable), gloves, and hard hats. • Training of "workers" in safe use of pneumatic and electrical power tools. • Systematic safe removal of materials. • Team lifting and carrying. • To upper floor areas provide a shute for materials into designated waste area as required. Provide a spotter where necessary. • Monitor air quality. Provide shade cloth around work area and wet down dust as required to prevent wind borne dust. • Storage of materials in designated waste areas • Storage of materials in designated waste areas • Regular site clean ups. • Slips, trips, falls and accessibility. • Slips, trips, falls and accessibility.				Use Licensed Electrician and Plumber to isolate, disconnect	Cape Cod
of pneumatic and electrical power tools. Systematic safe removal of materials. Team lifting and carrying. To upper floor areas provide a shute for materials into designated waste area as required. Provide a spotter where necessary. Monitor air quality. Provide shade cloth around work area and wet down dust as required to prevent wind borne dust. Storage of materials in designated waste areas Regular site clean ups. Stripping of existing roof Slips, trips, falls and accessibility. of pneumatic and electrical power tools. Systematic safe removal of Professionals Gyprock Professionals Gyprock Professionals Cape Cod Ocape Cod Cape Cod				glasses, footwear, noise / hearing protection, dust protection [disposable], gloves,	• •
Team lifting and carrying. To upper floor areas provide a shute for materials into designated waste area as required. Provide a spotter where necessary. Monitor air quality. Provide shade cloth around work area and wet down dust as required to prevent wind borne dust. Storage of materials in designated waste areas Regular site clean ups. Stripping of existing roof Slips, trips, falls and accessibility. Professionals Gyprock Professionals Cape Cod				of pneumatic and electrical	Professionals
To upper floor areas provide a shute for materials into designated waste area as required. Provide a spotter where necessary. Monitor air quality. Provide shade cloth around work area and wet down dust as required to prevent wind borne dust. Storage of materials in designated waste areas Regular site clean ups. Stripping of existing roof Slips, trips, falls and accessibility. Professionals Cape Cod				•	• •
shade cloth around work area and wet down dust as required to prevent wind borne dust. Storage of materials in designated waste areas Regular site clean ups. Stripping of existing roof Slips, trips, falls and accessibility. Assess the site conditions including the weather and				 To upper floor areas provide a shute for materials into designated waste area as required. Provide a spotter 	Professionals
designated waste areas • Regular site clean ups. 7 Stripping of existing roof • Slips, trips, falls and accessibility. • Assess the site conditions including the weather and				shade cloth around work area and wet down dust as required to prevent wind borne dust.	Cape Cod
existing roof accessibility. including the weather and				designated waste areas	Cape Cod
covering exposure. before commencing. • Fall from height.	f	existing roof frame and	accessibility.UV / weather exposure.	including the weather and conduct a Risk Assessment	Cape Cod

Reviewed by:	Gary Klomp C	onstruction Manager	
	Principal Contractor's Representative	Position	
		10918	

Signature

 Hazardous materials. Identification of services. Electrocution. Gas explosions. Falling objects. Exposure to dust. Exposure to noise. Manual handling. Heavy lifting. Cuts and abrasions. Proximity of other trades 	dentification of ervices. Electrocution. Gas explosions. Falling objects. Exposure to dust.	Identify any products or materials that <i>may</i> contain asbestos. Identify services and ensure all electrical, gas, water and sewerage services have been isolated or safely relocated before commencing.	Cape Cod
	Manual handling. Heavy lifting. Cuts and abrasions.	 Use Licensed Electrician and Plumber to isolate, disconnect and relate existing services. Training of "workers" in safe working at heights. 	Cape Cod Gyprock Professionals
	I —	Provide "Demolition in Progress" and "Restricted Access" warning signage. Establish a "No access area" below overhead work areas by barricading to prevent access to the area of work. Provide a spotter where necessary.	Gyprock Professionals Gyprock Professionals
	•	Ensure that the scaffolding and edge protection is in place before commencing. Correct use of ladder	Gyprock Professionals Gyprock Professionals
	•	Use appropriate PPE – safety glasses, footwear, noise / hearing protection, dust protection [disposable], gloves and hard hats.	Gyprock Professionals
	•	Training of "workers" in the safe use of hand tools and power tools.	Gyprock Professionals
	•	Systematic safe removal of materials.	Gyprock Professionals
	•	Team lifting and carrying. Provide a shute for materials into designated waste area as required. Provide a spotter where necessary.	Gyprock Professionals Cape Cod
	•	Provide shade cloth / mesh around work area and wet down dust as required to prevent wind borne dust.	Cape Cod

Reviewed by:	Gary Klomp	Construction Manager	
_	Principal Contractor's Representative	Positi	on
		10,9,14	
	Signature	Date	

	 Ensure all roof tarps are tied down and not weighted with tiles. Ensure materials are not stored on the roof or scaffold. 	Gyprock Professionals

Reviewed by:	Gary Klomp	Construction Manager	
,	Principal Contractor's Representative	Position	
	h	in a NA	

Signature