## Fresh Start

## Safe Work Method Statement

Project / Location: All Jobs

version 1.0

Activity / Task: Scaffold - Dismantle

Company: Fresh Start

Signed by: Chris Moerman Date: 09/11/2015

Principle Contractor: Cape Cod

Accepted by: Tara Antoniolli Date: 06/07/2016

| Steps                           | Potential Hazards Contr   | rols / Responsible Person(s)   |
|---------------------------------|---|--|
| 1. Access to site.              | accessibility.  UV light / weather exposure.  Too  En:  We wh  Sto  | "workers" to register before entering the site; to read the General Construction Safety Plan nage; and to read the Site Specific Risk Assessment form. By: Principle Contractor & Fresh Start of box talk to highlight any WHS concerns relative to the site. By: Fresh Start sure that the site and work place access is unobstructed. By: Principle Contractor are appropriated PPE - hat, long sleeves, sun screen, sunglasses and fluids and reduce exposure ere possible. By: Fresh Start trage of materials /plant in designated areas. By: Fresh Start vide and maintain barricades to all materials stored on footpath and on site. By: Fresh Start gular site clean ups. By: Principle Contractor   |
| Handling of scaffold components | <ul><li>Slips, trips and falls.</li><li>Proximity of other</li><li>Un</li></ul>   | am lifting and carrying <b>By: Fresh Start</b> ining of "workers" in correct lifting and carrying methods. <b>By: Fresh Start</b> load and move the tools and equipment to a designated area to keep footpath / work place less clear. <b>By: Fresh Start</b>  |
| 3. Dismantling scaffold         | accessibility.  Fall from heights.  Falling objects.  Manual task injuries  Sprains and strains.  Cuts and abrasions.  Electrocution.  Exposure to noise.  Exposure to dust  UV / weather exposure.  Proximity of other "workers".  Public access.  beta Seri | sess the site conditions including the weather and conduct a Site Specific Risk Assessment fore commencing. By: Fresh Start  sup in a clear area and maintain a clear travel path. By: Fresh Start  Intify the location of the electrical service. By: Fresh Start  Intify that electrical service has been isolated and that 'tiger tails' are in place as protection moverhead wires and points of attachment before commencing. By: Principle Contractor scaffolding is to be dismantled by WorkCover NSW certified Scaffolders. By: Principle Intractor  Sure "workers" have safety glasses, noise and dust protection, appropriate protective footwear, do hat and gloves. By: Fresh Start  Inining of "workers" in the setting up of ladders, electrical equipment and use of fall arrest tems [harnesses]. By: Fresh Start  Sure the proper use by "workers" of all safety guards and fall arrest systems provided. By: Fresh rt  Sure Scaffolder ["worker"] is harnessed up to scaffold at all times when dismantling components Fresh Start  Sure that all power tools and electrical leads have current tagging. By: Fresh Start  Sure that power tools are attached to a residual current device [RCD]. By: Fresh Start  Sure that power tools are attached to a residual current device [RCD]. By: Fresh Start  Surice "Restricted Access" warning signage. By: Fresh Start  ablish a "No access area" to work areas by barricading to prevent access to the area of work.  Noted a spotter where necessary. By: Fresh Start |

Dismantle shade cloth and mesh by undoing from bottom to top. By: Fresh Start

mesh has been removed to reduce wind loading on the scaffold. By: Fresh Start

Pull shade cloth and mesh into scaffold and pass down to man ["worker"] on ground. By: Fresh

Ensure that the dismantling of scaffold components is only undertaken once shade cloth and

- Slips, trips, falls and accessibility.
- Fall from heights.
- Falling objects.
- Manual task injuries
- Sprains and strains.
- Cuts and abrasions.
- Electrocution.
- Exposure to noise.
- Exposure to dust.
- UV / weather exposure.
- Proximity of other "workers".
- Public access.

- Assess the site conditions including the weather and conduct a Site Specific Risk Assessment before commencing. By: Fresh Start
- Set up in a clear area and maintain a clear travel path. By: Fresh Start
- Identify the location of the electrical services By: Fresh Start
- Identify that the electrical service has been isolated or safely recommissioned before commencing work. By: Principle Contractor
- Identify that the electrical service has been isolated and that 'tiger tails' are in place as protection from overhead wires and points of attachment before commencing. By: Principle Contractor
- All scaffolding is to be dismantled by WorkCover NSW certified Scaffolders. By: Fresh Start
- Ensure "workers" have safety glasses, noise and dust protection, appropriate protective footwear, hard hat and gloves By: Fresh Start
- Training of "workers" in the setting up of ladders, electrical equipment and use of fall arrest systems [harnesses]. By: Fresh Start
- Ensure the proper use by "workers" of all safety guards and fall arrest systems provided.
   By: Fresh
   Start
- Ensure Scaffolder ["worker"] is harnessed up to scaffold at all times when dismantling components
   By: Fresh Start
- Ensure Scaffolder ["worker"] only disconnects when working on two [2] planks and protected by handrail. By: Fresh Start
- Ensure that all power tools and electrical leads have current tagging. By: Fresh Start
- Ensure that power tools are attached to a residual current device [RCD]. By: Fresh Start
- Provide "Restricted Access" warning signage. By: Fresh Start
- Establish a "No access area" to work areas by barricading to prevent access to the area of work.
   Provide a spotter where necessary. By: Fresh Start
- Ensure working platforms [decks] are clean. By: Fresh Start
- Dismantle shade cloth and mesh by undoing from bottom to top By: Fresh Start
- Pull shade cloth and mesh into scaffold and pass down to man on ground. By: Fresh Start
- Ensure scaffold ties are only removed when shade cloth and mesh has been dismantled and only
  once stripping has reached the level of the tie. By: Principle Contractor
- Clearly display "Scaffold incomplete" sign to incomplete scaffold if scaffold is left unattended.
   By:
   Fresh Start

- 5. Continue to dismantle scaffold. Scaffolder to work back towards scaffold access. Once access is disconnected then dismantle next lift
- Slips, trips, falls and accessibility.
- Fall from heights.
- Falling objects.
- Manual task injuries
- Sprains and strains.
- Cuts and abrasions.
- Electrocution.
- Exposure to noise.
- Exposure to dust
- UV / weather exposure.
- Public access.
- Proximity of other "workers".

- Assess the site conditions including the weather and conduct a Site Specific Risk Assessment before commencing. By: Fresh Start
- Set up in a clear area and maintain a clear travel path. By: Fresh Start
- Identify the location of the electrical service By: Principle Contractor
- Identify that electrical services have been isolated and that 'tiger tails' are in place as protection from overhead wires and points of attachment before commencing. By: Principle Contractor
- All scaffolding is to be dismantled by WorkCover NSW certified Scaffolders. By: Fresh Start
- Ensure "workers" have safety glasses, noise and dust protection, appropriate protective footwear, hard hat and gloves. **By: Fresh Start**
- Training of "workers" in the setting up of ladders, electrical equipment and use of fall arrest systems [harnesses]. By: Fresh Start
- Ensure the proper use of all safety guards and fall arrest systems provided. By: Fresh Start
- Ensure that all power tools and electrical leads have current tagging. By: Fresh Start
- Ensure Scaffolder ["worker"] is harnessed up to scaffold at all times when dismantling components By: Fresh Start
- Ensure Scaffolder ["worker"] only disconnects when working on two [2] planks and protected by handrail. Bv: Fresh Start
- Ensure that power tools are attached to a residual current device [RCD]. By: Fresh Start
- Provide "Restricted Access" warning signage. By: Fresh Start
- Establish a "No access area" to work areas by barricading to prevent access to the area of work.
   Provide a spotter where necessary. By: Fresh Start
- Ensure working platforms [decks] are clean. By: Fresh Start
- Ensure scaffold ties are only removed when shade cloth and mesh has been dismantled and only once stripping has reached the level of the tie. By: Principle Contractor
- Clearly display "Scaffold incomplete" sign to incomplete scaffold if scaffold is left unattended. By:
   Fresh Start

- Site clean up on completion of work
- Manual task injuries
- Exposure to dust
- Exposure to
- Remove any temporary barricades if no longer required By: Principle Contractor
- Place all rubbish / debris in designated waste storage area By: Fresh Start
- Leave site / work area in a clean and tidy condition By: Principle Contractor & Fresh Start

Person responsible for ensuring compliance with SWMS: Person responsible for reviewing SWMS control measures:

Document Updated: 06/07/2016