

SAFE WORK METHOD STATEMENT

Page 1 of 6

Company [PCBU]:	Solid Foundations	Project Name/No:	All Jobs
Work Activity / Task:	SCAFFOLDER - ERECTION	Principal Contractor:	Cape Cod Australia Pty Ltd
Prepared by:	Liam McDonagh	Date: 19 9 2014	
Signature:	LMCOnde	Note: Sign off to be provided at Tool Box talk	

Note: Review of Control Measures -

If there are any tasks that may be included by way of variation to the plans or an alternative approach to the set task. It is a requirement to carry out a specific Risk Assessment for the tasks.

Item	Job Step	Potential Hazard	Controls	Responsible Person/s
1	Access to site.	 Slips, trips, falls and accessibility. UV / weather exposure. 	 Site specific induction. All "workers" to read the General Construction Safety Plan signage and Risk Assessment form before entering site. Tool box talk to highlight any WHS concerns relative to the site. Ensure that the site and work place access is unobstructed. Ensure all weather access to work areas. 	BUILDER CONTRACTOR
			 Wear appropriated PPE - hat, long sleeves, sun screen, sunglasses, and fluids and reduce exposure where possible. Storage of materials /plant in designated areas. 	\\
			 Provide and maintain barricades to all materials stored on footpath and on site. Regular site clean ups. 	SULVE CONT
2	Unloading tools, ladders and scaffold components	 Manual handling injuries. Slips, trips and falls. Proximity of other "workers". Public access. 	 Team lifting and carrying. Training of "workers" in correct lifting and carrying methods. Unload and move the tools, ladders and scaffold components to a designated area to keep footpath / work place access clear. 	CONTRACTOR

Reviewed by:	Gary Klomp
·	Principal Contractor's Representative
	<i>⊂</i> Signature

Construction Manager
Position

17/12/2014.

Item	Job Step	Potential Hazard	Controls	Responsible Person/s
3	Setting up	 Manual handling injuries. Slips, trips and falls. Falls from height. Uneven site. UV / weather exposure. Proximity of other "workers". Public access. 	 Assess the site conditions including the weather and conduct a Risk Assessment before commencing. Set up in a clear area and maintain a clear travel path. Identify the location of the electrical, sewer and stormwater services. Identify that the electrical service has been isolated or safely recommissioned before commencing work. 	BUILDER Contractor BUIDER BUILDER
			 All scaffolding is to be erected by WorkCover NSW certified Scaffolders. 	1 "
			 Training of "workers" in the setting up of ladders, electrical equipment and use of safety harnesses. 	CONTRACTOR
			 Ensure the proper use of all safety guards and systems provided. 	V
			Ensure that all power tools and electrical leads have current tagging.	1/
			 Ensure that power tools are attached to a residual current device [RCD]. 	"
!			Provide "Restricted Access" warning signage.	, Durse v
			 Establish a "No access area" to work areas by barricading to prevent access to the area of work. Provide a spotter where necessary. 	BULDER
4	Erection of scaffold to 2.0m.	Slips, trips, falls and accessibility.Fall from heights.	 Assess the site conditions and conduct a Risk Assessment before commencing. Identify the location of the 	u u

Reviewed by:	Gary Klomp	Construction Manage
•	Principal Contractor's Representative	Position
	Signature	17 /13 2014 Date

ltem	Job Step	Potential Hazard	Controls	Responsible Person/s
	scaffolding components from building level or ground.	injuries. Sprains and strains. Cuts and abrasions. Electrocution. Exposure to noise. Exposure to dust. UV / weather exposure. Proximity of other "workers". Public access.	electrical, sewer and stormwater services. Identify that the electrical service has been isolated and that 'tiger tails' are in place as protection from overhead wires and points of attachment before commencing. Provide "Restricted Access" warning signage. Establish a "No access area" below overhead work areas by barricading to prevent access to the area of work. Provide a spotter where necessary. Training of "workers" in correct lifting and carrying methods.	BUILDER BUILDER CONTRACTOR
			 carrying techniques are used at all times. Rotate "workers" and vary tasks performed. 	"
			Ensure "workers" have safety glasses, noise and dust protection, appropriate protective footwear, hard hat and gloves.	((
			 Training of "workers" in the safe use of power tools and equipment. 	11
			Ensure that all power tools have working safety guards.	11
			Storage of surplus scaffold components in designated areas so not to endanger the public or other "workers".	1
			Maintain a clean and tidy work area.	"
			Clearly display "Scaffold incomplete" sign to incomplete scaffold at all times prior to sign off of the	"

Reviewed by:	Gary Klomp	Construction Manager
•	Principal Contractor's Representative	Position
	Signature	17/12/2014 Date

Item	Job Step	Potential Hazard	Controls	Responsible Person/s
			scaffold.	
5	Continue to erect scaffold top out Work from two [2] plank width working platform	 Slips, trips, falls and accessibility. Fall from heights. Manual handling injuries. Sprains and strains. Cuts and abrasions. Electrocution. 	 Assess the site conditions and conduct a Risk Assessment before commencing. Identify that the electrical service has been isolated and that 'tiger tails' are in place as protection from overhead wires and points of attachment before commencing. 	BULLER
		Exposure to noise.	 Provide "Restricted Access" warning signage. 	"
		 Exposure to dust. UV / weather exposure. Proximity of other "workers". 	 Establish a "No access area" below overhead work areas by barricading to prevent access to the area of work. Provide a spotter where necessary. 	"
		Public access.	 Training of "workers" in correct lifting and carrying methods. 	CONTRACTOR
			 Ensure correct lifting and carrying techniques are used at all times. 	"
			 Rotate "workers" and vary tasks performed. 	"
			 Training of "workers" in the setting up of ladders and use of safety harnesses. 	"
			 Ensure workers have safety glasses, noise and dust protection, appropriate protective footwear, hard hat and gloves. 	"
		 Training of "workers" in the safe use of power tools and equipment. 	"	
			 Ensure that all power tools have working safety guards. 	(1
			Storage of surplus scaffold components in designated areas so not to endanger the public or	"

Reviewed by:	Gary Klomp	Construction Manager
,	Principal Contractor's Representative	Position
		17/12/2014

Date

Item	Job Step	Potential Hazard	Controls	Responsible Person/s
			 other "workers" Maintain a clean and tidy work area. Clearly display "Scaffold incomplete" sign to incomplete 	()
6	Continue to erect	Slips, trips, falls and	scaffold at all times prior to sign off of the scaffold. • Assess the site conditions and	\mathbb{D}
	Access to be built up with scaffold. Access to scaffold by ladder,	 accessibility. Fall from heights Manual handling injuries. Sprains and strains. Cuts and abrasions. Electrocution. 	 conduct a Risk Assessment before commencing. Identify that the electrical service has been isolated and that 'tiger tails' are in place as protection from overhead wires and points of attachment before commencing. 	Burrosa
	balcony deck internal stair or ladder.	Exposure to noise.Exposure to dust	 Provide "Restricted Access" warning signage. 	N
		 UV / weather exposure. Proximity of other "workers". 	 Establish a "No access area" below overhead work areas by barricading to prevent access to the area of work. Provide a spotter where necessary. 	11
		Public access.	 Training of "workers" in correct lifting and carrying methods. 	Cor
			 Ensure correct lifting and carrying techniques are used at all times. 	/(
			 Rotate "workers" and vary tasks performed. 	"
			 Ensure "workers" have safety glasses, noise and dust protection, appropriate protective footwear, hard hat and gloves. 	\\
			 Training of "workers" in the safe use of power tools and equipment. 	11
			 Ensure that all power tools have working safety guards. Storage of surplus scaffold 	"

Gary Klomp
Principal Contractor's Representative
Signature

Construction Manager
Position

17 12, 2014 Date

SAFE WORK METHOD STATEMENT [cont.]

Page **6** of **6**

Item	Job Step	Potential Hazard	Controls	Responsible Person/s
			components in designated areas so not to endanger the public or "workers".	CONTRACTO
			 Maintain a clean and tidy work area. 	~~~ //
			 Clearly display "Scaffold incomplete" sign to incomplete scaffold at all times prior to sign off of the scaffold. 	^ <u>()</u>

eviewed by:	Gary Klomp	Construction Manager
	Principal Contractor's Representative	Position
		17/22014
	Signature	Date