## Cape Cod

4th Floor, 410 Church St PARRAMATTA, NSW 2151 (02) 9849 4444 office@capecod.com.au

## Safe Work Method Statement

version 1.1

Project / Location: All Jobs

## Activity / Task: Plumber / Drainer / Gas Fitter

Company: Cape Cod

Signed by: Tara Antoniolli Date: 26/06/2017

Principal Contractor: Cape Cod

Accepted by: Tara Antoniolli Date: 26/06/2017

Steps	Potential Hazards	Controls / Responsible Person(s)
1. Access to site	<ul> <li>Slips, trips, falls and accessibility.</li> <li>UV light / weather exposure.</li> </ul>	<ul> <li>Site specific induction. By: Principal Contractor &amp; Cape Cod</li> <li>All "workers" to register before entering the site; to read the General Construction Safety Plan signage; and to read the Site Specific Risk Assessment form. By: Cape Cod</li> <li>Tool box talk to highlight any WHS concerns relative to the site. By: Cape Cod</li> <li>Ensure that the site and work place access is unobstructed. By: Cape Cod</li> <li>Ensure all weather access to work areas. By: Cape Cod</li> <li>Wear appropriated PPE - hat, long sleeves, sun screen, sunglasses, and fluids and reduce exposure where possible. By: Cape Cod</li> <li>Provision of designated waste areas. By: Principal Contractor</li> <li>Storage of materials in designated areas. By: Cape Cod &amp; Worker</li> <li>Provide and maintain barricades to all materials stored on footpath and on site. By: Cape Cod</li> <li>Regular site clean ups. By: Principal Contractor</li> </ul>
<ol> <li>Unloading plant, equipment and materials</li> </ol>	<ul> <li>Manual task injuries</li> <li>Slips, trips and falls.</li> <li>Proximity of other "workers".</li> <li>Public access.</li> </ul>	<ul> <li>Team lifting and carrying. By: Cape Cod</li> <li>Training of "workers" in correct lifting and carrying methods. By: Cape Cod</li> <li>Unload and move the equipment to designated area to keep footpath / work place access clear. By: Cape Cod</li> </ul>
3. Setting up equipment	<ul> <li>Manual task injuries</li> <li>Slips, trips and falls.</li> <li>Proximity of other "workers".</li> <li>Public access.</li> </ul>	<ul> <li>Set up in a clear area and maintain a clear travel path. By: Cape Cod</li> <li>Training of employees in setting up of electrical leads and power tools. By: Cape Cod</li> <li>Ensure the proper use of all safety guards provided. By: Cape Cod</li> <li>Ensure that all power tools and electrical leads have current tagging. By: Cape Cod</li> <li>Ensure that all power tools are attached to a residual current device [RCD]. By: Cape Cod</li> </ul>
4. Excavation for sewer and stormwater	<ul> <li>Slips, trips, falls and accessibility.</li> <li>Manual task injuries</li> <li>Sprains and strains.</li> <li>Cuts and abrasions.</li> <li>Exposure to dust / fumes.</li> <li>Exposure to noise.</li> <li>Hazardous substances.</li> <li>Proximity of other "workers".</li> <li>Public access.</li> </ul>	<ul> <li>Training of "workers" in correct lifting and excavation methods. By: Cape Cod</li> <li>Rotate "workers" and monitor air quality when connecting sewer at manholes [mains] and when working in confined spaces. By: Cape Cod</li> <li>Systematic safe removal and storage of excavation materials. By: Cape Cod</li> <li>Establish barricading to the excavations to prevent access to the area of work. Provide a 'spotter' where necessary. By: Cape Cod</li> <li>Provide "Restricted Access" warning signage to excavated trenches. By: Cape Cod</li> <li>Ensure that the excavation is adequately shored, supported, battered or benched. By: Cape Cod</li> <li>Ensure plant / equipment used and excess spoil from the excavation is positioned outside the zone of influence. By: Cape Cod</li> <li>Provide MSDS for hazardous chemicals - adhesives for Pvc pipes. By: Cape Cod</li> <li>Training of "workers" in the safe handling and use of adhesives. By: Cape Cod</li> <li>Ensure that adequate lighting and ventilation is available in confined spaces. By: Principal Contractor</li> <li>Backfill or cover the excavation immediately after plumbing and inspection is complete. By: Cape Cod</li> <li>Ensure that "workers" have safety glasses, noise protection, dust / fume protection [disposable],</li> </ul>

protective footwear and gloves. By: Cape Cod

[disposable] and protective footwear. By: Cape Cod

• Use appropriate PPE - safety glasses, footwear, noise / hearing protection, dust / fume protection

- Reduce frequency of manual excavation work. By: Cape Cod
- Team lifting and carrying. By: Cape Cod
- Regular work area clean ups. By: Cape Cod

- Access -ground floor
- Slips, trips, falls and accessibility
- Hazardous materials
- Identification of services
- Electrocution.
- Gas explosions.
- Falling objects.
- Exposure to dust / fumes.
- Exposure to noise.
- Manual task injuries
- Sprains and strains.
- Cuts and abrasions.
- Proximity of other "workers".
- Public access

- Assess the site conditions and conduct a Site Specific Risk Assessment before commencing. By:
   Cape Cod
- Identify any products or materials that may contain asbestos [ACM]. By: Cape Cod
- Identify services and make sure all electrical, gas, water and sewerage services have been isolated or safely relocated before commencing. By: Cape Cod
- Use Licensed Electrician to isolate, disconnect and relate existing services. By: Cape Cod
- Use appropriate PPE when chasing in pipes to brickwork or timber safety glasses, footwear, noise / hearing protection, dust protection [disposable], gloves and hard hats. By: Cape Cod
- Training of "workers" in the safe use of power tools, gas welding and cutting equipment.
   By: Cape
   Cod
- Ensure all gas cylinders and equipment is regularly check and maintained. By: Cape Cod
- Ensure all power tools have working safety guards. By: Cape Cod
- Provide MSDS for hazardous substances adhesives for Pvc pipes. By: Cape Cod
- Training of employees in the safe handling and use of adhesives. By: Cape Cod
- Training of "workers" in correct lifting and carrying method. By: Cape Cod
- Use team lifting and carrying when installing / building in spa or bath. By: Cape Cod
- Ensure that openings / voids in wet area floors are covered. By: Cape Cod
- Storage of materials in designated areas. By: Cape Cod
- Regular work area clean ups. By: Cape Cod

- 6. Upper floor level access by ramp and scaffold or internal access
- UV light / weather exposure
- Slips, trips, falls and 
   accessibility
- Fall from height
- Manual task injuries
- Exposure to dust / fumes
- Exposure to noise
- Proximity of other "workers".
- Public access.

- Assess the site conditions including the weather and conduct a Site Specific Risk Assessment before commencing. By: Cape Cod
- Ensure that the guard rails to the ramp are in place and that the surface of ramp is clean before commencing. By: Cape Cod
- Ensure that the perimeter protection is in place [scaffolding and edge protection] before commencing. By: Principal Contractor
- Ensure that all openings and voids in the floor platform are covered or protected by a guard rail.
   By: Principal Contractor
- Identify any products or materials in the existing roof void that may contain asbestos.
   By: Cape
   Cod
- Identify services and make sure all electrical, gas, water and sewerage services have been isolated or safely relocated before commencing. By: Principal Contractor
- Use Licensed Electrician to isolate, disconnect and relate existing services. By: Cape Cod
- Use appropriate PPE- safety glasses, footwear, noise / hearing protection, dust / fume protection [disposable] and gloves. By: Cape Cod
- Ensure that "workers" have safety glasses, noise protection, dust / fume protection [disposable], protective footwear. By: Cape Cod
- Training of "workers" in the safe use of power tools, gas welding and cutting equipment.
   By: Cape
   Cod
- Ensure all gas cylinders and equipment are regularly check and maintained. By: Cape Cod
- Ensure all power tools have working safety guards. By: Cape Cod
- Provide MSDS for hazardous substances –adhesives for Pvc pipes. By: Cape Cod
- Training of "workers" in the safe handling and use of adhesives. By: Cape Cod
- Training of "workers" in correct lifting and carrying method. By: Cape Cod
- Use team lifting and carrying when installing / building in spa or bath. By: Cape Cod
- Ensure correct lifting and carrying techniques are used at all times. By: Cape Cod
- Training of "workers" in the safe use of power tools. By: Cape Cod
- Ensure that all power tools have working safety guards. By: Cape Cod
- Check suitability of the access ladder for purpose before use. By: Cape Cod
- Check the ladder for damage / defect before use. By: Cape Cod
- Check that the ladder is stable and is secured at the base and top before use. By: Cape Cod
- Storage of materials in designated areas By: Cape Cod
- Maintain clean and tidy work area. By: Cape Cod

- 7. Roof mount solar water heater installation
- Slips, trips, falls and accessibility.
- UV light / weather exposure.
- Fall from height.
- Manual task injuries
- Assess the site conditions including the weather and conduct a Site Specific Risk Assessment before commencing. By: Cape Cod
- Ensure that the guard rails to the ramp are in place and that the surface of the ramp is clean before commencing. By: Cape Cod
- Ensure that the perimeter protection is in place [scaffolding and edge protection] before commencing. By: Cape Cod

- Proximity of other "workers".
- Public access.
- Ensure that the edge protection to the roof surface [roof rail] and level work platforms are in place before commencing work from roof surface By: Cape Cod
- Training of "workers" in safe working at heights from roof surfaces. By: Cape Cod
- Training of "workers" in correct lifting methods. By: Cape Cod
- Team lifting and carrying By: Cape Cod
- Ensure that correct lifting and carrying techniques are used at all times. By: Cape Cod
- Wear appropriated PPE hat, long sleeves, sun screen, sunglasses and fluids and reduce exposure where possible By: Cape Cod
- Ensure that "workers" have safety glasses, noise protection, dust / fume protection [disposable], protective footwear and gloves. By: Cape Cod
- Use of mechanical aids to lift and place unit to roof surface. By: Cape Cod
- Check suitability of the access ladder for purpose before use. By: Cape Cod
- Check the ladder for damage / defect before use. By: Cape Cod
- Check that the ladder is stable and is secured at the base and top before use. By: Cape Cod
- Maintain a clean and tidy work area. By: Cape Cod

- 8. Site clean up on completion of work
- Exposure to dust
- Exposure to hazardous substances
- Manual task injuries Remove any temporary barricades if no longer required By: Principal Contractor
  - Place all rubbish / debris in designated waste storage area By: Cape Cod
  - Leave site / work area in a clean and tidy condition By:

а

Person responsible for ensuring compliance with SWMS: Person responsible for reviewing SWMS control measures:

Document Updated: 26/06/2017