Company Name:	Ariel Corporary	Project Name/No:	AllJODS
Work Activity / Task:	ASBESTOS OR [A¢M] [ACD] REMOVAL - OVER 10.0m ²	Principal Contractor:	Cape Cod Australia Pty. Ltd.
Prepared by:	Philip Doughly	Date:	15 December 2013
Signature:	PA	Note: Sign off to be provided at Tool Box talk	

Note 1: Removal of materials that may contain asbestos [ACM] or [ACD] must meet the requirements of WHS Regulation 2011 - Chapter 8

Note 2: Review of Control Measures - If there are any tasks that may be included by way of variation to the plans or an alternative approach to the set task, it is a requirement to carry out a "Specific Risk Assessment" for the tasks.

Item	Job Step	Potential Hazard	Controls	Responsible Person/s
T Transfer of the Control of the Con	Access to site	Slips, trips, falls and accessibility UV light / weather exposure	 Site specific induction. All "workers" to register before entering the site; to read the General Construction Safety Plan signage; and to read the Site Specific Risk Assessment form. Tool box talk to highlight any WHS concerns. Ensure site access is unobstructed. Ensure all weather access to work areas. Wear appropriated PPE - hat, long sleeves, sun screen, sunglasses, and fluids and reduce exposure where possible. Provision of designated waste areas. Storage of materials in designated areas. Regular site clean ups. 	Philip

Reviewed by: Gary Klomo On behalf of Cape Cod Construction Manager

E-lostham as per GR

item	Job Step	Potential Hazard	Controls	Responsible Person/s
2	Unloading plant and equipment	 Manual task injuries Slips, trips and falls. Proximity of other "workers" and public. Public access, 	Team lifting and carrying. Training of "workers" in correct lifting methods. Unload and move the equipment to designated area to keep footpath / work place access clear.	Philip Doughty
3	Setting up equipment	 Manual task injuries Slips, trips and falls. Proximity of other workers*. Public access. 	 Set up in a clear area and maintain a clear travel path. Training of 'workers' in setting up of electrical leads, power tools and nail guns. Ensure proper use of all safety guards provided to plant and equipment. Ensure all electrical leads, plant and equipment have current tagging. Ensure electrical equipment is attached to a residual current device [RCD]. 	Philip Daughty
4	Removing asbestos or ACM sheet from ground level	 Stips, trips, falls and accessibility Fall from height Hazardous materials Exposure to dust Identification of services Electrocation Exposure to noise Manual task injuries Cuts and abrasions Proximity of other "workers" and public Public access 	 Assess site conditions including weather and conduct a Site Specific Risk Assessment before commencing. Identify the location of the electrical service and that the electrical service has been isolated or safely relocated before commencing work. Provide "Restricted Access" warning signage and establish a "No access area" by barricading to prevent access of anyone not connected with the removal activity into the work area and to control contamination. Position warning signage containing the words "DANGER ASBESTOS REMOVAL IN PROGRESS" in a prominent visible position at the front of the site. Signage to include the details of the licensed Contractor 	Philip Daght

Reviewed by: Gov Clong
On behalf of Cape Cod

Construction Manager

Eladham as por GK Signature 24,1,14 Date

Page 3 of 7 v1.13

ltem	Job Step	Potential Hazard	Controls	Responsible Person/s
TT PROJECTION AND AND AND AND AND AND AND AND AND AN			[PCBU], Seal all windows and doors to prevent dust entering the building during the removal and clean up process.	
The majority of the second sec			All products and materials "that may" contain asbestos [ACM] or [ACD] are to be stored, transported and disposed of in accordance with the NSW Protection of the Environment Operations Act [1997] and NSW Protection of the Environment Operations [Waste] Regulation [2005]	Philip Doughty
- 4угрози			 Prior to the removal process all products and materials "that may" contain asbastos [ACM] or [ACD] to be sealed with PVA sealant or kept damp. Prevent and or contain excess run off water. 	
- ONDOORGE-			 All products and materials "that may" contain asbestos (ACM) or [ACO] is to be either wrapped in recommended 200-micron thick plastic sheeting or placed in leak proof lined bins or vehicles and covered. 	
	TOTOGRAPHIC TOTOGR	William And Andrews (Andrews Andrews (Andrews Andrews (Andrews Andrews (Andrews Andrews (Andrews (Andr	 All products and materials "that may" contain asbestos [ACM] or [ACD] is to be stored in a secure area and removed from site as soon as practical in a covered leak proof vehicle. 	
Management of the Control of the Con			All products and materials 'that may" contain asbestos [ACM] or [ACD] is to be disposed of in a manner, and at a site approved by the NSW Office of Environment and Heritage [OEH], appropriate disposal Authority or Local Council.	
	97000	West of the second	Care in removing wall sheets and eave soffits to minimise breakage of	

Reviewed by: Gay Comp
On behalf of Cape Cod

Construction Manager

E-lasham as per GK Signature

24 , 1 , 14 Date

Page 4 of 7 v1.13

Item	Job Step	Potential Hazard	Controls	Responsible Person/s
			sheets - where possible keep sheets intact.	
			Ensure that adequate lighting and ventilation is a available.	
**************************************			 Systematic safe removal of materials. 	
			 Training of "workers" in safe working from step and extension ladders. 	P.R. W.
			 Training of "workers" in the safe removal and handling of products and materials "that may" contain asbestos (ACM) or (ACD). 	P. R.dip Doughs
Williams			Ensure "workers" wear safety glasses, noise protection, respiratory protection [disposable], protective footwear, disposable coveralls and gloves during the removal and clean up process.	
The Property of the Property o			Regularly monitor for air borne dust when removal work is being undertaken.	
PROGRESSY LAW,			Pick up visible asbestos debris around the removal area, then decontaminate using wet methods or suitable vacuum cleaner.	
A SALAMAN AND AND AND AND AND AND AND AND AND A			Use approved vacuum cleaning equipment [HEPA] that complies with AS/NZS 60335.2.69 – Industrial vacuum cleaners or its equivalent for particulates hazardous to health, to prevent the release of lead containing dust while it is being removed. Do not use household vacuum cleaners.	
			PVA seal residues of asbestos cement that cannot be removed from timber framed members.	
AMBOOK UCCAL	,		Plastic sheets used for drop sheets and debris is not be reused and is to be disposed of as asbestos waste.	
			Training of "workers" in correct lifting	

Reviewed by: Govy Clomp
On behalf of Cape Cod

Constitution Manager
Position

E-latham as per GK Signature

24, i, 14 Date

Page 5 of 7 v1.13

Item	Job Step	Potential Hazard	Controls	Responsible Person/s
			and carrying methods. Ensure that the correct lifting and carrying techniques are used at all times. Rotate 'workers' and vary tasks performed. Ensure running water is available	Philip Dought
5	Stripping of asbestos or ACM sheet roof covering	Slips, trips, falls and accessibility. UV light / weather exposure. Fall from height. Hazardous materials. Identification of services. Electrocution. Falling objects. Exposure to dust. Exposure to noise. Manual task injuries Sprains and strains. Cuts and abrasions. Proximity of other "workers". Public access.	 Assess the site conditions including the weather and conduct a Sile Specific Risk Assessment before commencing. Provide 'Demolition in Progress' and "Restricted Access' warning signage and establish a 'No access area' by barricading to prevent access of anyone not connected with the removal activity into the work area and to control contamination. Provide a spotter where necessary. Position warning signage containing the words "DANGER ASBESTOS REMOVAL IN PROGRESS" in a prominent visible position at the front of the site. Signage is to include the details of the licensed Contractor (PCBU). Identify that the electrical service has been isolated and that 'figer lails' are in place as protection from overhead wires and points of attachment before commencing. Use Licensed Electrician to isolate, disconnect and relate existing services. Ensure that the guard rails to the ramp are in place and that the surface of the ramp is clean before commencing. Ensure that the perimeter protection is in place [scaffolding and edge protection] are in place before 	This is a supply of the supply

Reviewed by: On behalf of Cape Cod

Elasham aspe GK Signature

Page 5 of 7 v1.13

ltem	Job Step	Potential Hazard	Controls	Responsible Personis
			accessing work from roof surface.	
****Completicons			 Ensure that the edge protection to the roof surface [roof rail] is in place before accessing the roof surface. Training of "workers" in safe working 	
		Shekking and a second s	at heights and safe movement on scaffolding and on roof.	
			 Training of "workers" in the safe removal and handling of products and materials "that may" contain asbestos. 	
			 Ensure that the scaffolding is safe and erected by a qualified Scaffolder. 	Doughty
			Check the access ladder for damage / defects before use.	Jondry
e tribility (VI) (Characters and Characters and Cha			Check that the ladder is stable and secured top and bottom before use.	, ·
		Tarana Antonio	Correct use of access ladder.	
		PROPOSAL STATEMENT AND	Limit use of ladders as working platforms.	
			 Ensure "workers" wear hats, safety glasses, noise protection, respiratory protection (disposable), protective footwear, disposable coveralls and gloves during the removal and clean up process. 	
The state of the s			Systematic safe removal of materials.	
W.C. THE STREET STREET			Training of *workers* in correct lifting and carrying methods.	
-			Team lifting and carrying.	
			Rotate "workers" and vary tasks performed.	
			Ensure that materials are not stored on roof or scaffold.	
	ž		Prior to the removal process asbestos seal the roofing sheets with PVA sealant or wet down.	
			Ensure dampening of the roofing	

Reviewed by: Gary Kone
On behalf of Cape Cod

Construction Manager
Fosition

Elathorn as per GK

Signature

24 , 1 , 14 . Date

Page 7 of 7 v1.13

ltem	Job Step	Potential Hazard	Controls	Responsible Person/s
			sheets is done well before removal to allow the roof surface to dry sufficiently so "workers" do not stip.	
			Prevent and or contain excess run off water from the roof surface.	
	The state of the s		Remove fixings and remove the asbestos cement sheets with minimal breakage. Lower whole sheets to the ground where possible and place in prepared designated waste area. Provide a spotter where necessary.	
		OPPOSITE SECURITY SEC	Regularly monitor for air barne dust when removal work is being undertaken.	Philip
		SSA ALIAN AND AND AND AND AND AND AND AND AND A	 Provide shade cloth around work area and wet down dust as required to prevent wind borne dust. 	Philip Doughty
•			 Pick up visible asbestos debris in the roof space and around the removal area and then decontaminate using wet methods or suitable vacuum cleaner. 	/
VVVVIII (A)			 PVA seal residues of asbestos cement that cannot be removed from timber framed members. 	
			 Plastic sheets used for drop sheets and debris is not be reused and is to be disposed of as asbestos waste. 	
			Regular site clean ups.	
			Ensure running water is available.	
ਰੰ	Site clean up on completion of	Manual task injuries Exposure to dust Exposure to hazardous	Remove any temporary barricades if no longer required	Philip Bolat
	work	substances-	 Place all rubbish / debris in designated waste storage area 	Panht
- The Control Polymon Control	*		 Leave site / work area in a clean and tidy condition 	/ 0 /

Reviewed by: Gary Klomp
On behalf of Cape Cod

Construction Manager

Elatham as:par GK

24_{11,14} Date