Scott Bartley Plumbing

43 KELVIN PDE
PICNIC POINT, NSW 2213
0418 204 151
scott@scottbartleyplumbing.com.au

Project / Location: All Jobs

Safe Work Method Statement

version 1.2

Activity / Task: Plumber / Drainer / Gas Fitter

Company: Scott Bartley Plumbing
Signed by: Tanya Bartley Date: 03/08/2017

Principal Contractor: Modum Pty Ltd

Accepted by: Date:

Steps	Potential Hazards	Controls / Responsible Person(s)
1. Access to site	 Slips, trips, falls and accessibility. UV light / weather exposure. 	 Site specific induction. By: Scott Bartley Plumbing All "workers" to register before entering the site; to read the General Construction Safety Plan signage; and to read the Site Specific Risk Assessment form. By: Scott Bartley Plumbing Tool box talk to highlight any WHS concerns relative to the site. By: Scott Bartley Plumbing Ensure that the site and work place access is unobstructed. By: Scott Bartley Plumbing Ensure all weather access to work areas. By: Scott Bartley Plumbing Wear appropriated PPE - hat, long sleeves, sun screen, sunglasses, and fluids and reduce exposure where possible. By: Scott Bartley Plumbing Provision of designated waste areas. By: Principal Contractor Storage of materials in designated areas. By: Scott Bartley Plumbing Provide and maintain barricades to all materials stored on footpath and on site. By: Scott Bartley Plumbing Regular site clean ups. By: Principal Contractor
 Unloading plant, equipment and materials 	 Manual task injuries Slips, trips and falls. Proximity of other "workers". Public access. 	 Team lifting and carrying. By: Scott Bartley Plumbing Training of "workers" in correct lifting and carrying methods. By: Scott Bartley Plumbing Unload and move the equipment to designated area to keep footpath / work place access clear. By: Scott Bartley Plumbing
3. Setting up equipment	 Manual task injuries Slips, trips and falls. Proximity of other "workers". Public access. 	
4. Excavation for sewer and stormwater	 Slips, trips, falls and accessibility. Manual task injuries Sprains and strains. Cuts and abrasions. Exposure to dust / fumes. Exposure to noise. Hazardous substances. Proximity of other "workers". Public access. 	 Training of "workers" in correct lifting and excavation methods. By: Scott Bartley Plumbing Rotate "workers" and monitor air quality when connecting sewer at manholes [mains] and when working in confined spaces. By: Scott Bartley Plumbing Systematic safe removal and storage of excavation materials. By: Scott Bartley Plumbing Establish barricading to the excavations to prevent access to the area of work. Provide a 'spotter' where necessary. By: Scott Bartley Plumbing Provide "Restricted Access" warning signage to excavated trenches. By: Scott Bartley Plumbing Ensure that the excavation is adequately shored, supported, battered or benched. By: Scott Bartley Plumbing Ensure plant / equipment used and excess spoil from the excavation is positioned outside the zone of influence. By: Scott Bartley Plumbing Provide MSDS for hazardous chemicals - adhesives for Pvc pipes. By: Scott Bartley Plumbing Training of "workers" in the safe handling and use of adhesives. By: Scott Bartley Plumbing Ensure that adequate lighting and ventilation is available in confined spaces. By: Principal Contractor

Bartley Plumbing

Backfill or cover the excavation immediately after plumbing and inspection is complete. By: Scott

Ensure that "workers" have safety glasses, noise protection, dust / fume protection [disposable],

- protective footwear and gloves. By: Scott Bartley Plumbing
- Use appropriate PPE safety glasses, footwear, noise / hearing protection, dust / fume protection [disposable] and protective footwear. By: Scott Bartley Plumbing
- Reduce frequency of manual excavation work. By: Scott Bartley Plumbing
- Team lifting and carrying. By: Scott Bartley Plumbing
- Regular work area clean ups. By: Scott Bartley Plumbing

- 5. Access -ground floor
- Slips, trips, falls and accessibility
- Hazardous materials
- Identification of services
- Electrocution.
- Gas explosions.
- Falling objects.
- Exposure to dust / fumes.
- Exposure to noise.
- Manual task injuries
- Sprains and strains.
- Cuts and abrasions.
- Proximity of other "workers".
- Public access.

- Assess the site conditions and conduct a Site Specific Risk Assessment before commencing. By:
 Scott Bartley Plumbing
- Identify any products or materials that may contain asbestos [ACM]. By: Scott Bartley Plumbing
- Identify services and make sure all electrical, gas, water and sewerage services have been isolated
 or safely relocated before commencing. By: Scott Bartley Plumbing
- Use Licensed Electrician to isolate, disconnect and relate existing services. By: Scott Bartley
 Plumbing
- Use appropriate PPE when chasing in pipes to brickwork or timber safety glasses, footwear, noise / hearing protection, dust protection [disposable], gloves and hard hats. By: Scott Bartley Plumbing
- Training of "workers" in the safe use of power tools, gas welding and cutting equipment. By: Scott Bartley Plumbing
- Ensure all gas cylinders and equipment is regularly check and maintained. By: Scott Bartley Plumbing
- Ensure all power tools have working safety guards. By: Scott Bartley Plumbing
- Provide MSDS for hazardous substances adhesives for Pvc pipes. By: Scott Bartley Plumbing
- Training of employees in the safe handling and use of adhesives. By: Scott Bartley Plumbing
- Training of "workers" in correct lifting and carrying method. By: Scott Bartley Plumbing
- Use team lifting and carrying when installing / building in spa or bath. By: Scott Bartley Plumbing
- Ensure that openings / voids in wet area floors are covered. By: Scott Bartley Plumbing
- Storage of materials in designated areas. By: Scott Bartley Plumbing
- Regular work area clean ups. By: Scott Bartley Plumbing

- 6. Upper floor level
 access by ramp
 and scaffold or
 internal access
- UV light / weather exposure
- Fall from height
- Manual task injuries
- Exposure to dust / fumes
- Exposure to noise
- Proximity of other "workers".
- Public access.

- Assess the site conditions including the weather and conduct a Site Specific Risk Assessment before commencing. By: Scott Bartley Plumbing
- Ensure that the guard rails to the ramp are in place and that the surface of ramp is clean before commencing. By: Scott Bartley Plumbing
- Ensure that the perimeter protection is in place [scaffolding and edge protection] before commencing. By: Principal Contractor
- Ensure that all openings and voids in the floor platform are covered or protected by a guard rail.
 By: Principal Contractor
- Identify any products or materials in the existing roof void that may contain asbestos. By: Scott Bartley Plumbing
- Identify services and make sure all electrical, gas, water and sewerage services have been isolated
 or safely relocated before commencing. By: Principal Contractor
- Use Licensed Electrician to isolate, disconnect and relate existing services. By: Scott Bartley
 Plumbing
- Use appropriate PPE- safety glasses, footwear, noise / hearing protection, dust / fume protection [disposable] and gloves. By: Scott Bartley Plumbing
- Ensure that "workers" have safety glasses, noise protection, dust / fume protection [disposable], protective footwear. By: Scott Bartley Plumbing
- Training of "workers" in the safe use of power tools, gas welding and cutting equipment.
 By: Scott
 Bartley Plumbing
- Ensure all gas cylinders and equipment are regularly check and maintained. By: Scott Bartley Plumbing
- Ensure all power tools have working safety guards. By: Scott Bartley Plumbing
- Provide MSDS for hazardous substances –adhesives for Pvc pipes. By: Scott Bartley Plumbing
- Training of "workers" in the safe handling and use of adhesives. By: Scott Bartley Plumbing
- Training of "workers" in correct lifting and carrying method. By: Scott Bartley Plumbing
- Use team lifting and carrying when installing / building in spa or bath. By: Scott Bartley Plumbing
- Ensure correct lifting and carrying techniques are used at all times. By: Scott Bartley Plumbing
- Training of "workers" in the safe use of power tools. By: Scott Bartley Plumbing
- Ensure that all power tools have working safety guards. By: Scott Bartley Plumbing
 Check suitability of the access ladder for purpose before use. By: Scott Bartley Plumbing
- Check the ladder for damage / defect before use. By: Scott Bartley Plumbing
- Check that the ladder is stable and is secured at the base and top before use.
 By: Scott Bartley Plumbing

- Storage of materials in designated areas By: Scott Bartley Plumbing
- Maintain clean and tidy work area. By: Scott Bartley Plumbing

- Roof mount solar water heater installation
- accessibility.
- exposure.
- Fall from height.
- Manual task injuries
- Proximity of other "workers".
- Public access.
- Slips, trips, falls and Assess the site conditions including the weather and conduct a Site Specific Risk Assessment before commencing. By: Scott Bartley Plumbing
- UV light / weather Ensure that the guard rails to the ramp are in place and that the surface of the ramp is clean before commencing. By: Scott Bartley Plumbing
 - Ensure that the perimeter protection is in place [scaffolding and edge protection] before commencing. By: Scott Bartley Plumbing
 - Ensure that the edge protection to the roof surface [roof rail] and level work platforms are in place before commencing work from roof surface By: Scott Bartley Plumbing
 - Training of "workers" in safe working at heights from roof surfaces. By: Scott Bartley Plumbing
 - Training of "workers" in correct lifting methods. By: Scott Bartley Plumbing
 - Team lifting and carrying By: Scott Bartley Plumbing
 - Ensure that correct lifting and carrying techniques are used at all times. By: Scott Bartley Plumbing
 - Wear appropriated PPE hat, long sleeves, sun screen, sunglasses and fluids and reduce exposure where possible By: Scott Bartley Plumbing
 - Ensure that "workers" have safety glasses, noise protection, dust / fume protection [disposable], protective footwear and gloves. By: Scott Bartley Plumbing
 - Use of mechanical aids to lift and place unit to roof surface. By: Scott Bartley Plumbing
 - Check suitability of the access ladder for purpose before use. By: Scott Bartley Plumbing
 - Check the ladder for damage / defect before use. By: Scott Bartley Plumbing
 - Check that the ladder is stable and is secured at the base and top before use. By: Scott Bartley Plumbina
 - Maintain a clean and tidy work area. By: Scott Bartley Plumbing

- 8. Site clean up on completion of work
- Manual task injuries
- Exposure to dust
- Exposure to hazardous substances
- Remove any temporary barricades if no longer required By: Principal Contractor
- Place all rubbish / debris in designated waste storage area By: Scott Bartley Plumbing
- Leave site / work area in a clean and tidy condition By:

Person responsible for ensuring compliance with SWMS: SCOTT BARTLEY Person responsible for reviewing SWMS control measures: SCOTT BARTLEY

Document Updated: 03/08/2017