Company [PCBU]:	Gyprocic Professionals	Gyprock Professionals	Project Name/No:	All Jobs
Work Activity / Task:	INTERNAL LININGS INSTALLER	Principal Contractor:	Cape Cod Australia Pty Ltd	
Prepared by:	Sean Jones	Date:	9.09.14	
Signature:		Note: Sign off to be provided at Tool Box talk		

## Note: Review of Control Measures -

If there are any tasks that may be included by way of variation to the plans or an alternative approach to the set task. It is a requirement to carry out a specific Risk Assessment for the tasks.

Task/Problem	Hazard						

Item	Job Step	Potential Hazard	Controls	Responsible Person/s
1	Access to site	<ul> <li>Slips, trips, falls and accessibility.</li> <li>UV / weather exposure.</li> </ul>	<ul> <li>Site specific induction.</li> <li>All "workers" to read the General Construction Safety Plan signage and Risk Assessment form before entering site.</li> <li>Tool box talk to highlight any OHS concerns relative to the site.</li> </ul>	Gyp Professionals  Gyp Professionals

Reviewed by:	Gary Klomp	Construction Manager	
	Principal Contractor's Representative	Position	
		10,9,14	
	Signature	Date	

		•	<ul> <li>Ensure that the site and work place access is unobstructed.</li> <li>Ensure all weather access to work areas.</li> <li>Provision of designated waste areas.</li> <li>Storage of materials in designated areas.</li> <li>Regular site clean ups.</li> </ul>	Gyp Professionals  Gyp Professionals  & Cape Cod Cape Cod Gyp Professionals  & Cape Cod Cape Cod Cape Cod
2	Unloading of tools and materials.	<ul> <li>Manual handling injuries.</li> <li>Slips, trips and falls.</li> <li>Proximity of other "workers".</li> <li>Public access.</li> </ul>	<ul> <li>Team lifting and carrying.</li> <li>Training of "workers" in correct lifting and carrying methods.</li> <li>Unload and move the tools and materials to a designated area to keep footpath / work place access clear.</li> </ul>	Gyp Professionals Gyp Professionals
3	Setting up equipment	<ul> <li>Manual handling injuries.</li> <li>Slips, trips and falls.</li> <li>Proximity of other "workers".</li> <li>Public access.</li> </ul>	<ul> <li>Set up in a clear area and maintain a clear travel path.</li> <li>Training of "workers" in the setting up of ladders / trestles, electrical leads and power tools.</li> <li>Ensure the proper use of all safety guards provided.</li> <li>Ensure that all power tools and electrical leads have current tagging.</li> <li>Ensure that power tools are attached to a residual current device [RCD].</li> </ul>	Gyp Professionals Gyp Professionals Gyp Professionals Gyp Professionals Gyp Professionals
4	Ground floor installation	<ul> <li>Slips, trips, falls and accessibility.</li> <li>Electrocution.</li> <li>Fall from height.</li> <li>Hazardous substances.</li> <li>Exposure to noise</li> <li>Exposure to dust.</li> </ul>	<ul> <li>Assess the site conditions and conduct a Risk Assessment before commencing.</li> <li>Identify location of the electrical and water services.</li> <li>Identify that the electrical service has been isolated or safely recommissioned before commencing work.</li> </ul>	Gyp Professionals Gyp Professionals & Cape Cod Gyp Professionals

Reviewed by:	Gary Klomp	Construction Manager		
,	Principal Contractor's Representative	- :	Position	

Signature

10,9,14

<ul> <li>Manual handlin</li> <li>Sprains and str</li> <li>Cuts and abras</li> <li>Proximity of ot "workers".</li> <li>Public access.</li> </ul>	and voids in the floor are guard railed or covered.  Team lifting and carrying of large flat sheets of plasterboard. Reduce team lifting and positioning of ceiling sheets by use mechanical panel lifter. Training of employees in correct lifting and carrying methods.  Gyp Professionals  Gyp Professionals
	<ul> <li>Ensure that the correct lifting and carrying techniques are used at all times.</li> </ul>
	• Rotate "workers" and vary tasks performed.  Gyp Professionals
	<ul> <li>Training of "workers" in safe         working from ladders.</li> <li>Check the ladder / trestles for Gyp Professionals</li> </ul>
	damage / defect before use.
	<ul> <li>Check that the trestle work platform is stable before use.</li> </ul>
	<ul> <li>Limit the use of ladders as work platforms.</li> <li>Gyp Professionals</li> </ul>
	<ul> <li>Provide MSDS for hazardous substances – plasterboard adhesives, insulation, and setting plaster.</li> </ul> Gyp Professionals
	<ul> <li>Training of "workers" in the safe handling and use of plasterboard adhesives, insulation, setting plaster.</li> <li>Gyp Professionals</li> </ul>
	<ul> <li>Use appropriate PPE – safety glasses, footwear, noise and dust protection [disposable] and gloves.</li> </ul>
	<ul> <li>Wear disposable dust protection         when mixing powders, sanding or         sweeping.</li> <li>Gyp Professionals</li> <li>Gene Cod</li> </ul>
	<ul> <li>Use disposable dust protection and power sander with vacuum attachment and dust bags to reduce air borne dust.</li> <li>&amp; Cape Cod</li> <li>Gyp Professionals</li> </ul>
	<ul> <li>Monitor dust when sanding is being undertaken.</li> <li>Gyp Professionals</li> </ul>

Reviewed by:	Gary Klomp	Construction Manager
-	Principal Contractor's Representative	Position
		10,9,14
	Signature	Date

			<ul> <li>Use scaffolding for void and raked ceilings.</li> <li>Storage of materials in designated areas.</li> <li>Maintain a clean and tidy work area by removing off cuts of plaster to designated waste area.</li> <li>Provide "Restricted Access" warning signage and establish a "No access area" to designated waste area by barricading to prevent access to the area of work. Provide a spotter where necessary.</li> </ul>	& Cape Cod
5	Carry tools and materials up ramp.  External access to upper floor	<ul> <li>Slips, trips, falls and accessibility.</li> <li>Electrocution.</li> <li>Fall from height.</li> <li>Hazardous substances.</li> <li>Exposure to noise.</li> <li>Exposure to dust.</li> <li>Manual handling.</li> <li>Sprains and strains.</li> <li>Cuts and abrasions.</li> <li>Proximity of other</li> </ul>	<ul> <li>Assess the site conditions including the weather and conduct a Risk Assessment before commencing work.</li> <li>Identify that the electrical service has been isolated and that 'tiger tails' are in place as protection from overhead wires and points of attachment before commencing.</li> <li>Ensure that the guard rails to the ramp are in place and that the surface of the ramp is clean before commencing.</li> <li>Ensure that the perimeter</li> </ul>	Gyp Professionals Cape Cod
Review	ed bv:	"workers".	protection is in place [scaffolding and edge protection] and level walk platforms are in place before accessing work from roof surface.  • Ensure that the edge protection to the roof surface [roof rail] and level work platforms are in place before accessing the upper floor level from roof surface.  • Ensure that the perimeter Consolerion visage arry guard rail]	Cape Cod
Review		ontractor's Representative	_	n
			10.011	
			<u> 10,4,14</u>	·

Signature

Date

is in place to balconies before commencing.	Gyp Professionals
<ul> <li>Training of "workers" in safe working at heights and movement on scaffolding and roof surfaces.</li> </ul>	& Cape Cod
<ul> <li>Training of "workers" in safe working at heights including over internal stairwell voids and from external balcony decks.</li> </ul>	Gyp Professionals
Ensure that all exposed openings and voids in the floor are guard railed or covered.	Gyp
<ul> <li>Provide scaffolding or platform cover to the stairwell void.</li> </ul>	Professionals
<ul> <li>Use of ladder and plank over stairwell voids is not permitted.</li> </ul>	
<ul> <li>Ensure that temporary guard rails and scaffolding is in place over stairwell void before commencing work and that the temporary guard rail is reinstalled when plastering is</li> </ul>	Gyp Professionals
complete and scaffolding has been removed.	Gyp Professionals
<ul> <li>Identify location of electrical and water services.</li> </ul>	
<ul> <li>Identify that the electrical service has been isolated or safely recommissioned before commencing work.</li> </ul>	Gyp Professionals
<ul> <li>Team lifting and carrying of large flat sheets of plasterboard.</li> </ul>	Gyp Professionals
Cut sheets at ground level before carrying to upper level.	
Reduce team lifting and positioning of ceiling sheets by use mechanical panel lifter.	
Training of "workers" in correct lifting and carrying methods.	
Ensure that the correct lifting and carrying techniques are	Cape Cod
used at all times.	Cape Cod

Reviewed by:	Gary Klomp	Construction Manager	_
ŕ	Principal Contractor's Representative	Position	
	Signature	Date	

<ul> <li>Rotate "workers" and vary tasks performed.</li> </ul>	
<ul> <li>Training of "workers" in safe working from ladders.</li> </ul>	Gyp Professionals
Check the ladder or trestles for damage / defect before use.	1 10.000.0110.0
<ul> <li>Check that the trestle work platform is level and stable before use.</li> </ul>	Gyp Professionals
• Limit the use of ladders as work platforms.	
<ul> <li>Provide MSDS for hazardous substances – plasterboard adhesives, insulation, and setting plaster.</li> </ul>	Gyp Professionals
<ul> <li>Training of "workers" in the safe handling and use of plasterboard adhesives, insulation, setting plaster.</li> </ul>	Gyp Professionals
<ul> <li>Use appropriate PPE – safety glasses, footwear, noise and dust protection [disposable] and gloves.</li> </ul>	Gyp Professionals
<ul> <li>Monitor dust when sanding is being undertaken.</li> </ul>	- - Gyp
<ul> <li>Wear disposable dust protection when mixing powders, sanding or sweeping.</li> </ul>	Professionals
<ul> <li>Use disposable dust protection and power sander with vacuum attachment and dust bags to reduce air borne dust.</li> </ul>	Gyp Professionals
<ul> <li>Use scaffolding for void and raked ceilings.</li> <li>Storage of materials in designated areas.</li> </ul>	Gyp Professionals
<ul> <li>Maintain a clean and tidy work area by removing off cuts of plaster to designated waste area.</li> </ul>	Gyp Professionals
<ul> <li>Provide "Restricted Access" warning signage and establish a "No access area" to</li> </ul>	
designated waste area by barricading to prevent access	Gyp Professionals

Reviewed by:	Gary Klomp	Construction Manager	
	Principal Contractor's Representative		Position
	Signature	<u> </u>	9,14 Date

	to the area of work. Provide a spotter where necessary.	
		Cape Cod
		Gyp Professionals
		- Gyp
		Professionals
		- Gyp
		Professionals
		Gyp Professionals

Reviewed by:	Garv Klomp	Construction Manager
	Principal Contractor's Representative	Position
		10,9,14

Signature

Date