Fresh Start

Safe Work Method Statement

Project / Location: All Jobs

version 1.0

Activity / Task: Asbestos Removal

Company: Fresh Start

Signed by: Chris Moerman Date: 09/11/2015

Principle Contractor: Cape Cod

to be sealed with PVA sealant or kept damp. Prevent and or contain excess run off water. By: Fresh

Accepted by: Tara Antoniolli Date: 30/05/2016

Steps	Potential Hazards	Controls / Responsible Person(s)
1. Access to site	 UV light / weather exposure. Slips, trips, falls and accessibility. 	 All "workers" to register before entering the site; to read the General Construction Safety Plan signage; and to read the Site Specific Risk Assessment form. By: Fresh Start Site Specific Induction By: Fresh Start Tool box talk to highlight any WHS concerns. By: Fresh Start Ensure site access is unobstructed. By: Fresh Start Ensure all weather access to work areas. By: Principle Contractor Wear appropriated PPE - hat, long sleeves, sun screen, sunglasses, and fluids and reduce exposure where possible. By: Fresh Start Provision of designated waste areas. By: Principle Contractor Storage of materials in designated areas. By: Fresh Start Regular site clean ups. By: Principle Contractor
2. Unloading plant and equipment	 Manual task injuries. Slips, trips and falls. Proximity of other "workers" and public. Public access. 	 Team lifting and carrying. By: Fresh Start Training of "workers" in correct lifting methods. By: Fresh Start Unload and move the equipment to designated area to keep footpath / work place access clear. By: Fresh Start
3. Setting up equipment	 Manual task injuries. Slips, trips and falls. Proximity of other "workers" and public. Public access. 	 Set up in a clear area and maintain a clear travel path. By: Fresh Start Training of "workers" in setting up of electrical leads, power tools and nail guns. By: Fresh Start Ensure proper use of all safety guards provided to plant and equipment. By: Fresh Start Ensure all electrical leads, plant and equipment have current tagging. By: Fresh Start Ensure electrical equipment is attached to a residual current device [RCD]. By: Fresh Start
4. Removing asbestos or ACM sheet from ground level	 Slips, trips, falls and accessibility Fall from height Hazardous materials Exposure to dust Identification of services Electrocution Exposure to noise Manual task injuries Cuts and abrasions Proximity of other "workers" and public. Public access. 	 Assess site conditions including weather and conduct a Site Specific Risk Assessment before commencing. By: Fresh Start Identify the location of the electrical service and that the electrical service has been isolated or safely relocated before commencing work. By: Fresh Start Provide "Restricted Access" warning signage and establish a "No access area" by barricading to prevent access of anyone not connected with the removal activity into the work area and to control contamination. By: Fresh Start Position warning signage containing the words "DANGER ASBESTOS REMOVAL IN PROGRESS" in a prominent visible position at the front of the site. Signage to include the details of the licensed Contractor [PCBU]. By: Principle Contractor Seal all windows and doors to prevent dust entering the building during the removal and clean up process. By: Fresh Start All products and materials "that may" contain asbestos [ACM] or [ACD] are to be stored, transported and disposed of in accordance with the NSW Protection of the Environment Operations Act [1997] and NSW Protection of the Environment Operations [Waste] Regulation [2005] By: Fresh Start Prior to the removal process all products and materials "that may" contain asbestos [ACM] or [ACD]

Start

- All products and materials "that may" contain asbestos [ACM] or [ACD] is to be either wrapped in recommended 200-micron thick plastic sheeting or placed in leak proof lined bins or vehicles and covered. By: Fresh Start
- All products and materials "that may" contain asbestos [ACM] or [ACD] is to be stored in a secure area and removed from site as soon as practical in a covered leak proof vehicle. By: Principle Contractor & Fresh Start
- All products and materials "that may" contain asbestos [ACM] or [ACD] is to be disposed of in a manner, and at a site approved by the NSW Office of Environment and Heritage [OEH], appropriate disposal Authority or Local Council. By: Principle Contractor & Fresh Start
- Care in removing wall sheets and eave soffits to minimise breakage of sheets where possible keep sheets intact. By: Fresh Start
- Ensure that adequate lighting and ventilation is available. By: Fresh Start
- Systematic safe removal of materials. By: Fresh Start
- Training of "workers" in safe working from step and extension ladders. By: Fresh Start
- Training of "workers" in the safe removal and handling of products and materials "that may" contain asbestos [ACM] or [ACD]. By: Fresh Start
- Ensure "workers" wear safety glasses, noise protection, respiratory protection [disposable], protective footwear, disposable coveralls and gloves during the removal and clean up process. By:
- Regularly monitor for air borne dust when removal work is being undertaken. By: Fresh Start
- Pick up visible asbestos debris around the removal area, then decontaminate using wet methods or suitable vacuum cleaner. By: Fresh Start
- Use approved vacuum cleaning equipment [HEPA] that complies with AS/NZS 60335.2.69 -Industrial vacuum cleaners or its equivalent for particulates hazardous to health, to prevent the release of lead containing dust while it is being removed. Do not use household vacuum cleaners. By: Principle Contractor
- PVA seal residues of asbestos cement that cannot be removed from timber framed members. By: Fresh Start
- Plastic sheets used for drop sheets and debris is not be reused and is to be disposed of as asbestos waste. By: Principle Contractor & Fresh Start
- Training of "workers" in correct lifting and carrying methods. By: Fresh Start
- Ensure that the correct lifting and carrying techniques are used at all times. By: Fresh Start
- Rotate "workers" and vary tasks performed. By: Fresh Start
- Ensure running water is available By: Principle Contractor

- Stripping of asbestos or ACM sheet roof covering
- accessibility.
- UV light / weather exposure.
- Fall from height.
- Hazardous materials.
- Identification of services
- Electrocution.
- Falling objects.
- Exposure to dust.
- Exposure to noise.
- Manual task injuries
- Sprains and strains.
- Cuts and abrasions.
- Proximity of other "workers".
- Public access.

- Slips, trips, falls and Assess the site conditions including the weather and conduct a Site Specific Risk Assessment before commencing. By: Principle Contractor
 - Provide "Demolition in Progress" and "Restricted Access" warning signage and establish a "No access area" by barricading to prevent access of anyone not connected with the removal activity into the work area and to control contamination. Provide a spotter where necessary. By: Principle Contractor
 - Position warning signage containing the words "DANGER ASBESTOS REMOVAL IN PROGRESS" in a prominent visible position at the front of the site. Signage is to include the details of the licensed Contractor [PCBU]. By: Principle Contractor
 - Identify that the electrical service has been isolated and that 'tiger tails' are in place as protection from overhead wires and points of attachment before commencing. By: Principle Contractor
 - Use Licensed Electrician to isolate, disconnect and relate existing services. By: Principle Contractor
 - Ensure that the guard rails to the ramp are in place and that the surface of the ramp is clean before commencing. By: Fresh Start
 - Ensure that the perimeter protection is in place [scaffolding and edge protection] are in place before accessing work from roof surface. By: Principle Contractor & Fresh Start
 - Ensure that the edge protection to the roof surface [roof rail] is in place before accessing the roof surface. By: Fresh Start
 - Training of "workers" in safe working at heights and safe movement on scaffolding and on roof. By: Fresh Start
 - Training of "workers" in the safe removal and handling of products and materials "that may" contain asbestos. Bv: Fresh Start
 - Ensure that the scaffolding is safe and erected by a qualified Scaffolder. By: Principle Contractor & Fresh Start
 - Check the access ladder for damage / defects before use. By: Fresh Start
 - Check that the ladder is stable and secured top and bottom before use. By: Fresh Start
 - Correct use of access ladder. By: Fresh Start
 - Limit use of ladders as working platforms. By: Fresh Start
 - Ensure "workers" wear hats, safety glasses, noise protection, respiratory protection [disposable], protective footwear, disposable coveralls and gloves during the removal and clean up process. By:

Fresh Start

- Systematic safe removal of materials. By: Fresh Start
- Training of "workers" in correct lifting and carrying methods. By: Fresh Start
- Team lifting and carrying. By: Fresh Start
- Rotate "workers" and vary tasks performed. By: Fresh Start
- Ensure that materials are not stored on roof or scaffold. By: Fresh Start
- Prior to the removal process asbestos seal the roofing sheets with PVA sealant or wet down.
 By:
 Fresh Start
- Ensure dampening of the roofing sheets is done well before removal to allow the roof surface to
 dry sufficiently so "workers" do not slip. By: Fresh Start
- Prevent and or contain excess run off water from the roof surface. By: Fresh Start
- Remove fixings and remove the asbestos cement sheets with minimal breakage. Lower whole
 sheets to the ground where possible and place in prepared designated waste area. Provide a
 spotter where necessary. By: Fresh Start
- Regularly monitor for air borne dust when removal work is being undertaken. By: Fresh Start
- Provide shade cloth around work area and wet down dust as required to prevent wind borne dust.
 By: Principle Contractor
- Pick up visible asbestos debris in the roof space and around the removal area and then
 decontaminate using wet methods or suitable vacuum cleaner. By: Fresh Start
- PVA seal residues of asbestos cement that cannot be removed from timber framed members. By:
 Fresh Start
- Plastic sheets used for drop sheets and debris is not be reused and is to be disposed of as asbestos waste. By: Fresh Start
- Regular site clean ups. By: Principle Contractor
- Ensure running water is available. By: Principle Contractor

- 6. Site clean up on completion of work
- Manual task injuries
- Exposure to dust
- Exposure to hazardous substances
- Remove any temporary barricades if no longer required By: Fresh Start
- Place all rubbish / debris in designated waste storage area By: Fresh Start
- Leave site / work area in a clean and tidy condition By: Fresh Start

Person responsible for ensuring compliance with SWMS: Person responsible for reviewing SWMS control measures:

Document Updated: 30/05/2016