Company Name:	MLC Property Solutions Pty Ltd	Project Name/No:	All Jobs
Work Activity / Task:	DEMOLITION by hand	Principal Contractor:	Cape Cod Australia Pty. Ltd.
Date:			
Prepared by:	Michael Catto	Note: Sign off to be provided at Tool Box talk	
-	Mealto		
Signature:			

Note: Review of Control Measures - If there are any tasks that may be included by way of variation to the plans or an alternative approach to the set task, it is a requirement to carry out a "Specific Risk Assessment" for the tasks.

ltem	Job Step	Potential Hazard	Controls	Responsible Person/s
1	Access to site	Slips, trips, falls and accessibility UV light / weather exposure	 Site specific induction. All "workers" to register before entering the site; to read the General Construction Safety Plan signage; and to read the Site Specific Risk Assessment form. Tool box talk to highlight any WHS concerns. Ensure site access is unobstructed. Wear appropriated PPE - hat, long sleeves, sun screen, sunglasses, and fluids and reduce exposure where possible. Regular site clean ups. 	Hichael BLOSE Contracts
			 Provision of designated waste areas. Storage of materials in designated areas. All weather access to work areas. 	Contractor
2	Unloading plant, equipment and tools	Manual task injuriesSlips, trips and falls.	 Team lifting and carrying. Training of "workers" in correct lifting methods. 	-Michael 1
			Unload and move equipment to designated area to keep footpath	''

Reviewed by:	Gary Klomp	Construction Manager
	On behalf of Cape Cod	Position
	<i>_</i> ')	
		10/07/2014
	Signature	Date

SAFE WORK METHOD STATEMENT [cont.]

Page 2 of 4 v1.13

Item	Job Step	Potential Hazard	Controls	Responsible Person/s
			/ work place access clear.	Carrocal
3	Setting up equipment	Manual task injuriesSlips, trips and falls.	Set up in a clear area and maintain a clear travel path.	-Michaeb (
			 Training of "workers" in the setting up of electrical leads, power tools and nail guns. 	n n
			Ensure proper use of all safety guards provided.	1
İ			Ensure all power tools and electrical leads have current tagging.	"
			Ensure power tools are attached to an earth leakage protection device.	•
4 Setting up access ramp		 Slips, trips, falls and accessibility Fall from height Manual task injuries 	Assess site conditions including weather and conduct a Site Specific Risk Assessment before commencing.	BIDEC
		• Wallual task injuries	Team lifting and carrying.	CONTRACTO
			Training of "workers" in correct lifting methods	11
			Ensure "workers" have protective footwear and gloves.	Michael
			Check ladder for damage before use.	
		Check ladder is stable before use.	',	
			 Install handrail and ensure adequate bracing to ramp. 	1)
			Provide a gate to the ramp with warning signage.	Busse
5	Stripping of existing roof frame and covering	 Slips, trips and falls UV / weather exposure 	 Assess site conditions including weather and conduct a Site Specific Risk Assessment before commencing. 	*
		Fall from heightHazardous materials	Training of "workers" in safe working at heights.	R 150
		Identification of servicesElectrocution	 Provide "Demolition in Progress" and "Restricted Access" warning signage. 	Bedsa

Reviewed by:	Gary Klomp	Construction Manager
	On behalf of Cape Cod	Position

Item	Job Step	Potential Hazard	Controls	Responsible Person/s
		 Gas explosions Falling objects Exposure to dust Hearing / noise 	Establish a "No Go Zone" below overhead work areas by barricading to prevent access to the area of work. Provide a spotter ["worker"] where necessary.	(duritactor
		Manual task injuries	Scaffolding and edge protection.	
		 Heavy lifting Cuts and abrasions. Proximity of other 'workers' and the public 	 Correct use of ladder Use appropriate PPE – safety glasses, footwear, noise / hearing protection, dust protection [disposable], gloves, and hard hats. 	"
			Training of "workers" in safe use of hand tools and power tools.	16
			Systematic safe removal of materials.	,
			Team lifting and carrying.	«
			Storage of materials in designated waste areas	n
			Regular site clean ups.	3 00 C-
			Ensure all roof tarps are tied down and not weighted with tiles.	3.55%- Commete
			Ensure materials are not stored on roof or scaffold.	"
			 Provide a shute for materials into designated waste area. Provide a spotter ["worker"] where necessary. 	Becol
			Provide shade cloth around work area and wet down dust as required to prevent wind borne dust.	BLOOR
6	Site clean up on	 Manual task injuries Exposure to dust 	Remove any temporary barricades if no longer required	Constacto
	completion of work	• Exposure to hazardous substances	Place all rubbish / debris in designated waste storage area	MIChael 11
			Leave site / work area in a clean and tidy condition	"

Reviewed by:	Gary Klomp	Construction Manager	
·	On behalf of Cape Cod	Position	