

VR-16C-2H quick start

16-channel PoE VaultNVR

In the box

1. Device
2. Mounting template and screws
3. Waterproof connector kit (outdoor models)
4. Regulatory information

Install

1. Check the mounting surface can hold three times the device weight.
2. Drill using the template, route the cable, and fix the base.
3. Connect a PoE switch or recorder port; the status LED turns solid when ready.
4. Open the Dhonaadhi app, scan the QR code on the label and set a strong admin password.

Next steps

1. Update to the latest firmware from the product page.
2. Configure detection zones and schedules in the web interface.