


6990

LEGO[®] LAND


LEGO




1




2



3





USE OF BATTERY BOX — PLEASE NOTE


Please obey the following points concerning the proper use of the battery box:

DO:


- Use a 9 volt battery and follow instructions carefully.
- Check the battery regularly.
- Observe polarity signs in the bottom of the battery box.
- Remove the battery from the battery box if unused for a long period.
- Use an alkaline or rechargeable battery for longer life.

DON'T


- Recharge the battery while it is in the battery box.
- Connect the battery box to other sources of power (eg. transformers, outlets, or other battery boxes).
- Throw used batteries in the fire.





1




2








3




4















8




9




1**2****3****4****5****6****7****8****10**

11









1




2









7




8




9




1




2





3




4





5




10




ON/OFF







1




2







4x

3







4







5












7










1




2
















3










4




1**2****3****4****5****5**

1**2****3****4****6****7**




9**10**


11




1





2




3




4




1




2





3







4


























4 X




2 X




2 X



2 X



2 X



5 X

