TAXI

ENGINGE START
Strobes ("NAV LTS")
Transponder on device to STBY/GND
Altimeter
Analogue Altimeter AND G5
Navigation Tablet AS REQUIRED

HeadlightsON Engine RevIDLE
Release parking brake and brake manually.
Perform brake check on first movement!
Taxi always with walking pace and ONLY
according to required clearances!

BEFORE TAKE-OFF
Parking brake SET Throttle IDLE Headlights OFF
Warm-up enging with max. 2000 RPM.
until oil temp. min. 50°C.
Run-up Check PERFORMED
At 3200 RPM. Max drop 250 RPM (L/R)
Flight Controls (Stick) FREE
Trim SET
Canopy DOUBLE CHECKED

TAKE-OFF / DEPARTURE
TARE OFF A DEFARTORE
For Line-Up:
Headlights
Transponder ALT (MODE S, ADS-B)
FlapsAS REQUIRED
Fuel Pump
•
Line-up only according to required clearances!
In Position / Take-Off
Throttle FULL FWD
Rotation earliest at 65 km/h.
Best climb w/ FLAPS-1: 110 km/m. Clean: 115 km/h.
Trim SET
At about 400 ft AGL, reduce Rev slightly.
Fuel Pumpe and lights OFF.
Retract Flaps. Climb w/ 115 to 120 km/h
•
Adjust trim accordingly.

CRUISE	
Flaps	OFF
Powersetting: Normal Cruise: 4750 to 500 Fast Cruise: up to max. 530	O RPM
CAUTION: High fuel consumption Check engine instruments rec	n from 5000 RPM on!
Check engine mstruments reg	guiariy

THE PROPERTY OF THE PROPERTY O				
Fuel Pump				

SHUT-DOWN	
At Parkingposition: Throttle	
When getting out: Parking Brake	