TAXI

ENGINGE START
Strobes ("NAV LTS")
Transponder on device to STBY/GND
Altimeter
Navigation Tablet AS REQUIRED

HeadlightsON
Engine Rev IDLE
Release parking brake and brake manually.
Perform brake check on first movement!
Taxi always with walking pace and ONLY
according to required clearances!

BEFORE TAKE-OFF
Parking brake
Warm-up enging with max. 2000 RPM.
until oil temp. min. 50°C. Run-up CheckPERFORMED
At 3200 RPM. max drop 250 RPM (L/R)
1
Canopy DOUBLE CHECKED
Flight Controls (Stick) FREE Trim SET

CRUISE	
Flaps	OFF OFF

SHUT-DOWN
At Parkingposition: Throttle
Ignition keyREMOVED Put key into middle compartment.
When getting out: Parking Brake