MQ-7 sensor:

.

ESPHome configuration:

Use the ESPHome adc sensor to interface with the built-in ADC of the devboard. For the ESP32 the pin range is: GPIO32 to GPIO39.

Example YAML:

sensor:

- platform: adc
pin: A0

name: "sensor name"
update_interval: never

The never update interval on the ADC sensor example is needed due to the measurement cycle of the MQ-7 sensor. Therefore the updates need to be trigger manually. One way to do it would be to create an interval component that:

- (a) Enables power via a switch
- (b) Wait a bit (add delay)
- (c) Triggers ADC update (component.update)
- (d) Wait again
- (e) Disable PSU

more info:

• https://esphome.io/components/sensor/adc.html