







all passive elements (resistors, capacitors) are in 0603 package



reset the mcu: EN to GND
bootloader: GPIO28 to GND



us3r_d0e5nt_3x1st

Sheet: /
File: esp32c5-airunit-nano.kicad_sch

Title: esp32c5-airunit-nano

Size: A4 Date: 2026-06-05
KiCad E.D.A. 10.0.1

Rev: V1.0
Id: 1/1