

U2 Generator CCW

Tag.#	Attachment	Isolation Device Description	Isolation Device PHID	Isolated Position	Normal Position
1	 Danger	GENERATOR COOLER SUPPLY HEADER ISOLATION	02-VCCW364	CLOSED	OPEN
2	 Danger	GENERATOR COOLER RETURN HEADER ISOLATION/THROTTLING	02-VCCW349	CLOSED	THROTTLED
3	 Danger	GENERATOR COOLER SUPPLY ISOLATION	02-VCCW320	CLOSED	OPEN
4	 Danger	GENERATOR COOLER SUPPLY ISOLATION	02-VCCW330	CLOSED	OPEN
5	 Danger	GENERATOR COOLER SUPPLY ISOLATION	02-VCCW332	CLOSED	OPEN
6	 Danger	GENERATOR COOLER SUPPLY ISOLATION	02-VCCW334	CLOSED	OPEN
7	 Danger	GENERATOR COOLER SUPPLY ISOLATION	02-VCCW336	CLOSED	OPEN
8	 Danger	GENERATOR COOLER SUPPLY ISOLATION	02-VCCW338	CLOSED	OPEN
9	 Danger	GENERATOR COOLER SUPPLY ISOLATION	02-VCCW342	CLOSED	OPEN
10	 Danger	GENERATOR COOLER SUPPLY ISOLATION	02-VCCW344	CLOSED	OPEN
11	 Danger	GENERATOR COOLER RETURN ISOLATION/THROTTLING	02-VCCW361	CLOSED	THROTTLED
12	 Danger	GENERATOR COOLER RETURN ISOLATION/THROTTLING	02-VCCW351	CLOSED	THROTTLED
13	 Danger	GENERATOR COOLER INLET DRAIN	02-VCCW318	OPEN	CLOSED
14	 Danger	GENERATOR COOLER INLET DRAIN	02-VCCW400	OPEN	CLOSED
15	 Danger	GENERATOR COOLER OUTLET DRAIN	02-VCCW403	OPEN	CLOSED
16	 Danger	GENERATOR COOLER OUTLET DRAIN	02-VCCW408	OPEN	CLOSED
17	 Danger	GEN COOLER DRAIN	02-VCCW372	OPEN	CLOSED
18	 Danger	GEN COOLER DRAIN	02-VCCW373	OPEN	CLOSED
19	 Danger	GEN COOLER DRAIN	02-VCCW374	OPEN	CLOSED
20	 Danger	GEN COOLER DRAIN	02-VCCW375	OPEN	CLOSED
21	 Danger	GEN COOLER DRAIN	02-VCCW376	OPEN	CLOSED
22	 Danger	GEN COOLER DRAIN	02-VCCW377	OPEN	CLOSED
23	 Danger	GEN COOLER DRAIN	02-VCCW378	OPEN	CLOSED
24	 Danger	GEN COOLER DRAIN	02-VCCW379	OPEN	CLOSED
25	 Danger	GENERATOR COOLER INLET DRAIN	02-VCCW398	OPEN	CLOSED
26	 Danger	GENERATOR COOLER INLET DRAIN	02-VCCW319	OPEN	CLOSED
27	 Danger	GENERATOR COOLER INLET DRAIN	02-VCCW348	OPEN	CLOSED
28	 Danger	GENERATOR COOLER INLET DRAIN	02-VCCW371	OPEN	CLOSED
29	 Danger	GENERATOR COOLER INLET DRAIN	02-VCCW399	OPEN	CLOSED
30	 Danger	GENERATOR COOLER INLET DRAIN	02-VCCW401	OPEN	CLOSED
31	 Danger	GENERATOR COOLER RETURN ISOLATION/THROTTLING	02-VCCW363	CLOSED	OPEN
32	 Danger	GENERATOR COOLER OUTLET DRAIN	02-VCCW402	OPEN	CLOSED
33	 Danger	GENERATOR COOLER RETURN ISOLATION/THROTTLING	02-VCCW359	CLOSED	OPEN
34	 Danger	GENERATOR COOLER OUTLET DRAIN	02-VCCW404	OPEN	CLOSED
35	 Danger	GENERATOR COOLER RETURN ISOLATION/THROTTLING	02-VCCW357	CLOSED	OPEN
36	 Danger	GENERATOR COOLER OUTLET DRAIN	02-VCCW405	OPEN	CLOSED
37	 Danger	GENERATOR COOLER RETURN ISOLATION/THROTTLING	02-VCCW355	CLOSED	OPEN
38	 Danger	GENERATOR COOLER OUTLET DRAIN	02-VCCW406	OPEN	CLOSED
39	 Danger	GENERATOR COOLER RETURN ISOLATION/THROTTLING	02-VCCW353	CLOSED	OPEN
40	 Danger	GENERATOR COOLER OUTLET DRAIN	02-VCCW407	OPEN	CLOSED
41	 Danger	GENERATOR COOLER RETURN ISOLATION/THROTTLING	02-VCCW347	CLOSED	OPEN
42	 Danger	GENERATOR COOLER OUTLET DRAIN	02-VCCW409	OPEN	CLOSED

Unit 2 Generator

Tag.#	Attachment	Isolation Device Description	Isolation Device PHID	Isolated Position	Normal Position
1	 Danger	U2 GCB Disconnect 89G-2	89G-1 Q91	OPEN	CLOSED
2	 Danger	SFC TO U2 GENERATOR DISCONNECT	89SS-2	OPEN	
3	 Danger	U2Generator Side Ground 57GG-2	57GG-2	CLOSED	OPEN
4	 Danger	CO2 ACTUATION LINE ISOLATION VALVE	02SGJ02AA001	CLOSED	OPEN
5	 Danger	SLIP RING HOUSING ISOLATION VALVE	02SGJ02AA202	CLOSED	OPEN

Unit 2 GSU

Tag.#	Attachment	Isolation Device Description	Isolation Device PHID	Isolated Position	Normal Position
1	 Danger	U2 Closing/Pri fuse for 02-SYD-BKR-01	02-SYD-BKR-01	OPEN	CLOSED
2	 Danger	U2 Switch Yard Disconnect	02-SYD-DSW-02	OPEN	CLOSED
3	 Danger	U2 Switch Yard Disconnect DC breaker	02-SYD-DSW-02	OPEN	CLOSED
4	 Danger	U2 Generator Disconnect GCB 89G	89G-2/Q9	OPEN	CLOSED
5	 Danger	U2 GCB Ground (transformer side)	Q82	CLOSED	OPEN
6	 Danger	MAIN FEED BREAKER	00-UAT-XFR-2	OPEN	CLOSED
7	 Danger	U2 Switch Yard Disconnect	02-SYD-DSW-01	OPEN	CLOSED
8	 Danger	U2 Switch Yard Disconnect DC breaker	02-SYD-DSW-01	OPEN	CLOSED

Unit 2 Seal Oil

Tag.#	Attachment	Isolation Device Description	Isolation Device PHID	Isolated Position	Normal Position
1	 Danger	MAIN SEAL OIL PUMP	02MKW01AP101-M01	OPEN	CLOSED
2	 Danger	SEAL OIL PUMP DISCONNECT	02MKW04AP101-M01	OPEN	CLOSED
3	 Danger	SEAL OIL REGULATOR INLET	MKW01AA110	CLOSED	OPEN
4	 Danger	SEAL OIL STRAINER OUTLET	MKW01AA112	CLOSED	OPEN
5	 Danger	SEAL OIL REGULATOR OIL SUPPLY	MKW01AA807	CLOSED	OPEN
6	 Danger	SEAL OIL REGULATOR H2 SUPPLY	MKW02AA801	CLOSED	OPEN
7	 Danger	SEAL OIL FLOAT TRAP VENT	MKW03AA901	CLOSED	OPEN
8	 Danger	SEAL OIL FLOAT TRAP INLET	MKW03AA101	CLOSED	OPEN
9	 Danger	SEAL OIL FLOAT TRAP OUTLET	MKW03AA103	CLOSED	OPEN
10	 Danger	H2 ISOLATION	02-VCMG103	CLOSED	OPEN
11	 Danger	H2 ISOLATION	02-VCMG113	CLOSED	OPEN
12	 Danger	H2 VENT	02-VCMG602	OPEN	CLOSED
13	 Danger	MINI BULK CO2 OUTLET ISO	V-1	CLOSED	OPEN

Unit 2 Lube oil

Tag.#	Attachment	Isolation Device Description	Isolation Device PHID	Isolated Position	Normal Position
1	 Danger	TURNING GEAR MOTOR VFD #1	02MAK11AE101-M01	OPEN	CLOSED
2	 Danger	TURNING GEAR MOTOR VFD #2	02MAK11AE101-M01	OPEN	CLOSED
3	 Danger	UNIT 2 MAIN LUBE OIL PUMP MOTOR A	02MPV01AP101-M01	OPEN	CLOSED
4	 Danger	UNIT 2 MAIN LUBE OIL PUMP MOTOR B	02MPV01AP102-M01	OPEN	CLOSED
5	 Danger	Emergency Lube Oil Pump Motor	02MPV01AP401-M01	OPEN	CLOSED
6	 Danger	LUBE OIL VAPOR EXTRACTOR MOTOR "A"	02MPV03AN101-M01	OPEN	CLOSED
7	 Danger	LUBE OIL VAPOR EXTRACTOR MOTOR "B"	02MPV01AN102-M01	OPEN	CLOSED
8	 Danger	JACKING OIL PUMP A	02MKV05AP201-M01	OPEN	CLOSED
9	 Danger	JACKING OIL PUMP B	02MKV05AP202-M01	OPEN	CLOSED
10	 Danger	TURNING GEAR SUPPLY OIL SOLENOID VALVE BYPASS VALVE	02MAV10AA101	CLOSED	CLOSED
11	 Danger	TURNING GEAR SUPPLY OIL SOLENOID VALVE INLET VALVE	02MAV10AA102	CLOSED	OPEN
12	 Danger	TURNING GEAR SUPPLY OIL SOLENOID VALVE OUTLET VALVE	02MAV10AA103	CLOSED	OPEN
13	 Danger	LUBE OIL HEATER (A)	02MPV01AH101	OPEN	CLOSED
14	 Danger	LUBE OIL HEATER (B)	02MPV01AH102	OPEN	CLOSED
15	 Danger	LUBE OIL HEATER (C)	02MPV01AH103	OPEN	CLOSED
16	 Danger	LUBE OIL HEATER (D)	02MPV01AH104	OPEN	CLOSED

Unit 2 Control oil

Tag.#	Attachment	Isolation Device Description	Isolation Device PHID	Isolated Position	Normal Position
1	 Danger	CONTROL OIL PUMP MOTOR (A)	02MPX01AP101-M01	OPEN	CLOSED
2	 Danger	CONTROL OIL PUMP MOTOR (B)	02MPX01AP102-M01	OPEN	CLOSED
3	 Danger	CONTROL OIL POLISHING PUMP	02MPX11AP101-M01	OPEN	CLOSED
4	 Danger	CONTROL OIL HEATER	02MPX01AH101	OPEN	CLOSED
5	 Danger	U2 GT IGV Actuator Control oil inlet valve	02MBX01AA103	CLOSED	OPEN
6	 Danger	U2 GT IGV Actuator Control oil outlet valve	02MBX01AA203	CLOSED	OPEN
7	 Danger	U2 GT VV Actuator Control oil Inlet valve	02MBX01AA104	CLOSED	OPEN
8	 Danger	U2 GT VV Actuator Control oil outlet valve	02MBX01AA204	CLOSED	OPEN

Unit 2 Waterside

Tag.#	Attachment	Isolation Device Description	Isolation Device PHID	Isolated Position	Normal Position
1	Danger	U2 BOILER FEED WATER PUMP A	02-BFW-MPM-01A	OPEN	CLOSED
2	Danger	U2 BOILER FEED WATER PUMP B	02-BFW-MPM-01B	OPEN	CLOSED
3	Danger	U2 CONDENSATE PUMP A	02-CND-MPM-01A	OPEN	CLOSED
4	Danger	U2 CONDENSATE PUMP B	02-CND-MPM-01B	OPEN	CLOSED
5	Danger	U2 CONDENSATE PUMP C	02-CND-MPM-01C	OPEN	CLOSED
6	Danger	GT 2C/ECA RECIRCULATION PUMP (A)	02LCA14AP 101	OPEN	CLOSED
7	Danger	GT 2C/ECA RECIRCULATION PUMP (B)	02LCA14AP 102	OPEN	CLOSED
8	Danger	ACC 2 LRVP 01A	02-ARM-MPM-01A	OPEN	CLOSED
9	Danger	ACC 2 LRVP 01B	02-ARM-MPM-01B	OPEN	CLOSED
10	Danger	ACC 2 LRVP 01C	02-ARM-MPM-01C	OPEN	CLOSED
11	Danger	ACC 2 LRVP 01D	02-ARM-MPM-01D	OPEN	CLOSED
12	Danger	ACC 2 LRVP 01E	02-ARM-MPM-01E	OPEN	CLOSED
13	Danger	UNIT 2 LP DRAINS TANK PUMP MTR A	02-STP-MPM-01A	OPEN	CLOSED
14	Danger	UNIT 2 LP DRAINS TANK PUMP MTR B	02-STP-MPM-01B	OPEN	CLOSED
15	Danger	UNIT 2 PHOSPHATE & AMMONIA MAIN FEED DISCONNECT	02-CCF-SKD-02	OPEN	CLOSED
16	Danger	DEMIN FILL TO CND STOP CHECK	02-VCND236	CLOSED	OPEN
17	Danger	DEMIN FILL TO CND ISOLATION	02-VCND238	CLOSED	OPEN
18	Danger	DEMIN FILL TO CND DRAIN VALVE	02-VCND237	OPEN	CLOSED
19	Danger	U2 MAKE UP CONTROL VALVE MANUAL ISOLATION	02-VDWS638	CLOSED	OPEN
20	Danger	U2 MAKE UP CONTROL VALVE MANUAL ISOLATION	02-VDWS639	CLOSED	OPEN
21	Danger	U2 MAKE UP VALVE BYPASS	02-VDWS636	CLOSED	OPEN
22	Danger	U2 MAKE WATER DRAIN VALVE	02-VDWS648	OPEN	CLOSED
23	Danger	UNIT 2 EMERGENCY MAKE UP CONTROL VALVE MANUAL ISOLATION (...)	02-VDWS641	CLOSED	OPEN
24	Danger	UNIT 2 EMERGENCY MAKE UP CONTROL VALVE MANUAL ISOLATION (...)	02-VDWS642	CLOSED	OPEN
25	Danger	UNIT 2 EMERGENCY MAKE UP DRAIN VALVE	02-VDWS643	OPEN	CLOSED
26	Danger	AUX STEAM TO CONDENSOR DRIP LEG ISO	02-VAXS200	OPEN	CLOSED
27	Danger	Aux steam to U2 main iso	02-VAXS630	CLOSED	OPEN
28	Danger	Aux steam to U2 main block iso	02-VAXS631	CLOSED	OPEN
29	Danger	Aux steam to U2 main block bypass	02-VAXS632	CLOSED	CLOSED
30	Danger	Aux steam to U2 main header vent	02-VAXS633	OPEN	CLOSED
31	Danger	02-VHHS971/983/984/985 02-HTT-HPL-2211	Brker 30/32 CB 16	OPEN	CLOSED
32	Danger	02-MOV-HHS-907 - 02-HTT-HPL-2217	Brker 1/3 CB 1	OPEN	CLOSED
33	Danger	02-HHS-993 sparge 02-HTT-HPL-1216	Brker 34/36 CB 18	open	closed

U2 Fuel gas performance heater flow meter

Tag.#	Attachment	Isolation Device Description	Isolation Device PHID	Isolated Position	Normal Position
1	Danger	U2 fgph flow meter upstream of bypass isolation	02-V-FGS003-JG	CLOSED	OPEN
2	Danger	U2 GAS FLOW METER BYPASS	02-VFGS122	CLOSED	CLOSED
3	Danger	U2 GAS FLOW METER INLET	02-VFGS113	CLOSED	OPEN
4	Danger	UNIT2 GAS FLOW METER VENT(SAMPLE)	02-VFGS116	OPEN	CLOSED

U2 CO2 fire protection

Tag.#	Attachment	Isolation Device Description	Isolation Device PHID	Isolated Position	Normal Position
1	Danger	CO2 ACTUATION LINE ISOLATION VALVE	02SGJ02AA001	CLOSED	OPEN
2	Danger	CO2 TO GAS TURBINE ENCLOSURE ISOLATION VALVE	02SGJ02AA103	CLOSED	OPEN
3	Danger	SLIP RING HOUSING ISOLATION VALVE	02SGJ02AA202	CLOSED	OPEN

Unit 2 Fireside (2024)

Tag.#	Attachment	Isolation Device Description	Isolation Device PHID	Isolated Position	Normal Position
1	 Danger	SFC TO U2 GENERATOR DISCONNECT	98SS-2/Q91	OPEN	
2	 Danger	DISCONNECT DOWNSTREAM OF GCB U2	89G-2/Q81	OPEN	CLOSED
3	 Danger	U2 GT ENHANCED AIR COMPRESSOR A	02-MBH06AN101	OPEN	CLOSED
4	 Danger	U2 GT ENHANCED AIR COMPRESSOR B	02-MBH06AN102	OPEN	CLOSED
5	 Danger	GT ECA COMPRESSOR A AUX OIL PUMP	02MBH06AP401-M01	OPEN	CLOSED
6	 Danger	GT ECA COMPRESSOR B AUX OIL	02MBH06AP402-M01	OPEN	CLOSED
7	 Danger	GT ECA COMPRESSOR A VAPOR EXTRACTOR (A)	02MBH06AN103-M01	OPEN	CLOSED
8	 Danger	GT ECA COMPRESSOR A VAPOR EXTRACTOR (B)	02MBH06AN104-M01	OPEN	CLOSED
9	 Danger	GT ECA COMPRESSOR B VAPOR EXTRACTOR (A)	02MBH06AN105-M01	OPEN	CLOSED
10	 Danger	GT ECA COMPRESSOR B VAPOR EXTRACTOR (B)	02MBH06AN106-M01	OPEN	CLOSED
11	 Danger	GT ECA COMPRESSOR A ENCLOSURE FAN (A)	02MBH06AN107-M01	OPEN	CLOSED
12	 Danger	GT ECA COMPRESSOR A ENCLOSURE FAN (B)	02MBH06AN108-M01	OPEN	CLOSED
13	 Danger	GT ECA COMPRESSOR B ENCLOSURE FAN (A)	02MBH06AN109-M01	OPEN	CLOSED
14	 Danger	GT ECA COMPRESSOR B ENCLOSURE FAN (B)	02MBH06AN110-M01	OPEN	CLOSED
15	 Danger	GT ECA COMPRESSOR A OIL HEATER	02MBH06AH101	OPEN	CLOSED
16	 Danger	GT ECA COMPRESSOR B OIL HEATER	02MBH06AH102	OPEN	CLOSED
17	 Danger	GT PACKAGE VENTILATION FAN A	02MBA11AN101-M01	OPEN	CLOSED
18	 Danger	GT PACKAGE VENTILATION FAN B	02MBA11AN102-M01	OPEN	CLOSED
19	 Danger	GT CASING COOLING AIR FAN	02QEF13AN101-M01	OPEN	CLOSED
20	 Danger	GT IGNITION EXCITER	02MBM01GU001	OPEN	CLOSED
21	 Danger	HRSG 2 AMMONIA INJECTION BLOWER A	02-SCR-MFN-100A	OPEN	CLOSED
22	 Danger	HRSG2 AMMONIA INJECTION BLOWER B	02-SCR-MFN-100B	OPEN	CLOSED
23	 Danger	UNIT 2 HRSG DUCT BURNER COOLING SKID BLOWER 1	02-BUR-MLB-01A	OPEN	CLOSED
24	 Danger	UNIT 2 HRSG DUCT BURNER COOLING SKID BLOWER 2	02-BUR-MLB-01B	OPEN	CLOSED
25	 Danger	UNIT 2 DUCT BURNER CONTROL PANEL MAIN POWER	02-BUR-CPL-01	OPEN	CLOSED
26	 Danger	TB-DC1 fuse #5	Forney - B10287-070-06	pulled	inserted
27	 Danger	TB-DC1 fuse # 6	Forney - B10287-070-06	pulled	inserted
28	 Danger	TB-DC1 fuse # 8	Forney - B10287-070-06	pulled	inserted
29	 Danger	TB-DC1 fuse # 9	forney - B10287-070-06	pulled	inserted
30	 Danger	TB-AC1 fuse # 7	Forney B10287-070-05A	pulled	inserted
31	 Danger	U2 DUCT BURNER CONTROL VALVE MANUAL ISOLATION	02-VFGS179	CLOSED	OPEN
32	 Danger	U2 DUCT BURNER CONTROL VALVE MANUAL ISOLATION	02-VFGS176	CLOSED	OPEN
33	 Danger	DUCT BURNER SOV	02-FGS-SOV293	CLOSED	OPEN
34	 Danger	U2 DUCT BURNER SKID VENT	02-VFGS120	OPEN	CLOSED
35	 Danger	U2 GAS FLOW METER INLET	02-VFGS113	CLOSED	OPEN
36	 Danger	U2 GAS FLOW METER BYPASS	02-VFGS122	CLOSED	OPEN
37	 Danger	U2 GAS FLOW METER OUTLET	02-VFGS124	CLOSED	OPEN
38	 Danger	Fuel Gas Emergency Shut Off Valve Upstream of FGPH	02MBP01AA701	CLOSED	OPEN
39	 Danger	CO2 ACTUATION LINE ISOLATION VALVE	02SGJ02AA001	CLOSED	OPEN
40	 Danger	CO2 TO GAS TURBINE ENCLOSURE ISOLATION VALVE	02SGJ02AA103	CLOSED	OPEN
41	 Danger	SLIP RING HOUSING ISOLATION VALVE	02SGJ02AA202	CLOSED	OPEN
42	 Danger	U2 GAS TURBINE ENCLOSURE FUEL VENT	02-VFGS177	OPEN	CLOSED
43	 Danger	U2 GAS TURBINE ENCLOSURE FUEL VENT	02-VFGS178	OPEN	CLOSED
44	 Danger	Ammonia injection manual isolation (upstream)	02-VAQA800	CLOSED	OPEN
45	 Danger	Ammonia injection manual isolation (downstream)	02-VAQA818	CLOSED	OPEN
46	 Danger	Ammonia injection line drain	02-VAQA813	OPEN	CLOSED

Unit 2 IGV/VV Calibration

Tag.#	Attachment	Isolation Device Description	Isolation Device PHID	Isolated Position	Normal Position
1	 Danger	CONTROL OIL PUMP MOTOR (A)	02MPX01AP101-M01	CLOSED	OPEN
2	 Danger	CONTROL OIL PUMP MOTOR (B)	02MPX01AP102-M01	CLOSED	OPEN
3	 Danger	U2 GT IGV Actuator Control oil outlet valve	02MBX01AA203	CLOSED	OPEN
4	 Danger	U2 GT VV Actuator Control oil outlet valve	02MBX01AA204	CLOSED	OPEN
5	 Danger	U2 GT IGV Actuator Control oil inlet valve	02MBX01AA103	CLOSED	OPEN
6	 Danger	U2 GT VV Actuator Control oil Inlet valve	02MBX01AA104	CLOSED	OPEN

Unit 2 GSU AND COMED Outage

Tag.#	Attachment	Isolation Device Description	Isolation Device PNID	Isolated Position	Normal Position
1	 Danger	U2 Closing/Pri fuse for 02-SYD-BKR-01	02-SYD-BKR-01	OPEN	CLOSED
2	 Danger	U2 Switch Yard Disconnect	02-SYD-DSW-02	OPEN	CLOSED
3	 Danger	U2 Switch Yard Disconnect DC breaker	02-SYD-DSW-02	OPEN	CLOSED
4	 Danger	U2 Generator Disconnect GCB 89G	89G-2/Q9	OPEN	CLOSED
5	 Danger	U2 GCB Ground (transformer side)	Q82	CLOSED	OPEN
6	 Danger	MAIN FEED BREAKER	00-UAT-XFR-2	OPEN	CLOSED
7	 Danger	U2 Switch Yard Disconnect	02-SYD-DSW-01	OPEN	CLOSED
8	 Danger	U2 Switch Yard Disconnect DC breaker	02-SYD-DSW-01	OPEN	CLOSED

Unit 2 UPS System Annual PM

Tag.#	Attachment	Isolation Device Description	Isolation Device PNID	Isolated Position	Normal Position
1	 Danger	Unit 2 UPS Bypass Switch Q500	02-LVF-UPS-01, SW Q500	Bypass	AUTO
2	 Danger	02-LVF-UPS-01	02-LVF-UPS-01, BR #4	OPEN	CLOSED
3	 Danger	02-LVF-UPS-01, Unit 2 UPS System, Fuse F6	02-LVF-UPS-01, F6	OFF	ON

Unit 2 TCP Rectifier

Tag.#	Attachment	Isolation Device Description	Isolation Device PNID	Isolated Position	Normal Position
1	 Danger	BR Q4, Unit 2 Rectifier 220 Vdc Feed to Battery Bank	02BTL01, BR Q4	OPEN	CLOSED
2	 Danger	BR Q5.1, Unit 2 Rectifier 220 Vdc Feed to Load	02BTL01, BR Q5.1	OPEN	CLOSED
3	 Danger	BR Q5.2, Unit 2 Rectifier 220 Vdc Feed to Load	02BTL01, BR Q5.2	OPEN	CLOSED
4	 Danger	BR Q5.3, Unit 2 Rectifier 220 Vdc Feed to Load	02BTL01, BR Q5.3	OPEN	CLOSED
5	 Danger	02BTL01 220V TURBINE CONTROL	02BTL01 220V DC RECT...	OPEN	CLOSED
6	 Danger	220V DC RECTIFIER PANEL 02BTL01	220V DC RECTIFIER PA...	OPEN	CLOSED

Unit 2 Helen strainer

Tag.#	Attachment	Isolation Device Description	Isolation Device PNID	Isolated Position	Normal Position
1	 Danger	BFW SUCTION LP DRUM ISOLATION	02-VBFW152	CLOSED	OPEN
2	 Danger	BFW SUCTION LP DRUM ISOLATION BYPASS	02-VBFW152A	CLOSED	CLOSED
3	 Danger	BFP SUCTION FROM CONDENSATE ISO VALVE	02-VBFW264	CLOSED	OPEN
4	 Danger	BFP SUCTION ISO FROM CONDENSATE BYPASS	02-VBFW264A	CLOSED	CLOSED
5	 Danger	BFP A SUCTION ISOLATION	02-VBFW265	CLOSED	OPEN
6	 Danger	2A BFP suction bypass	02-VBFW265A	CLOSED	CLOSED
7	 Danger	BFP B SUCTION ISOLATION	02-VBFW266	CLOSED	OPEN
8	 Danger	2B BFP suction bypass	02-VBFW266A	CLOSED	CLOSED

Unit 2 Calcite contactor

Tag.#	Attachment	Isolation Device Description	Isolation Device PNID	Isolated Position	Normal Position
1	 Danger	CALCITE FILTER CO2 INJECTION MODULE ISOLATION	02-VDWS107	CLOSED	OPEN
2	 Danger	CO2 outlet to CALCITE FILTER ISOLATION	02-VDWS106	CLOSED	OPEN
3	 Danger	U2 CALCITE BACKWASH MAIN INLET	02-VDWS820	CLOSED	OPEN
4	 Danger	U2 CALCITE CONTACTOR DEMIN INLET ISO VALVE	02-FCV-VDWS100	CLOSED	OPEN
5	 Danger	U2 CALCITE CONTACTOR VESSEL "1" WATER OUTLET	02-VDWS813	CLOSED	OPEN
6	 Danger	U2 CALCITE CONTACTOR VESSEL "2" WATER OUTLET	01-VDWS817	CLOSED	OPEN
7	 Danger	U2 CALCITE WATER MAIN OUTLET ISO	02-VDWS819	CLOSED	OPEN

Unit 2 ST building fire system water supply

Tag.#	Attachment	Isolation Device Description	Isolation Device PNID	Isolated Position	Normal Position
1	Danger	U2 Turbine Building isolation Post Indicating Valve	00-IDV-FPS610	CLOSED	OPEN
2	Danger	U2 water supply iso for TB ground floor	00-VPFS-814	CLOSED	OPEN
3	Danger	U2 water supply iso for ST/CT lube oil tank	00-VPFS-815	CLOSED	OPEN
4	Danger	U2 water supply iso for ST/GENERATOR Coupling	00-VPFS-816	CLOSED	OPEN
5	Danger	INA supply VALVE Fire System U2 ST/Generator Coupling	02-VINA198	CLOSED	OPEN
6	Danger	INA Low point drain VALVE Fire System U2 ST/Generator Coupling		OPEN	CLOSED
7	Danger	U2 Turbine building fire system header drain	00-VPFS-825	OPEN	CLOSED

Unit 2 LRVP Alpha

Tag.#	Attachment	Isolation Device Description	Isolation Device PNID	Isolated Position	Normal Position
1	Danger	ACC 2 LRVP 01A	02-ARM-MPM-01A	OPEN	CLOSED
2	Danger	ACC 2 SEAL WTR PMP 02A	02-ARM-MPM-02A	OPEN	CLOSED
3	Danger	U2 LRVP A seal water isolation valve to make up control valve	V-888E	CLOSED	OPEN
4	Danger	U2 LRVP A seal water isolation valve to make up control valve	02-V888B	CLOSED	OPEN
5	Danger	U2 LRVP A seal water isolation valve to bypass to tank	02-V-888A	CLOSED	CLOSED
6	Danger	U2 LRVP A discharge isolation valve off seal water tank	02-V-885A	CLOSED	OPEN
7	Danger	U2 LRVP A seal water discharge isolation valve after heat exchan	02-V-886A	CLOSED	OPEN
8	Danger	U2 LRVP A isolation valve to seal water spray valve	02-V-886B	CLOSED	OPEN
9	Danger	U2 LRVP A non condensable suction line	02-V883	CLOSED	OPEN
10	Danger	U2 LRVP A non condensable inlet isolation valve	02-YV-883	CLOSED	AUTO
11	Danger	U2 LRVP A seal water tank equalization isolation valve	02-V-884	CLOSED	OPEN
12	Danger	U2 LRVP A INA-YV-883 air supply valve	02-VINA131	CLOSED	OPEN
13	Danger	U2 LRVP east belly drains		OPEN	CLOSED
14	Danger	U2 LRVP west belly drains		OPEN	CLOSED

Unit 2 LRVP Bravo

Tag.#	Attachment	Isolation Device Description	Isolation Device PNID	Isolated Position	Normal Position
1	Danger	ACC 2 LRVP 01B	02-ARM-MPM-01B	OPEN	CLOSED
2	Danger	ACC 2 SEAL WTR PMP 02B	02-ARM-MPM-02B	OPEN	CLOSED
3	Danger	U2 LRVP "B" seal water isolation valve to make up control valve	V-895E	CLOSED	OPEN
4	Danger	U2 LRVP "B" seal water isolation valve to make up control valve	02-V895B	CLOSED	OPEN
5	Danger	U2 LRVP "B" seal water isolation valve to bypass to tank	02-V-895A	CLOSED	CLOSED
6	Danger	U2 LRVP "B" discharge isolation valve off seal water tank	02-V-892A	CLOSED	OPEN
7	Danger	U2 LRVP "B" seal water discharge isolation valve after heat exch	02-V-893A	CLOSED	OPEN
8	Danger	U2 LRVP "B" isolation valve to seal water spray valve	02-V-893B	CLOSED	OPEN
9	Danger	U2 LRVP "B" non condensable suction line	02-V890	CLOSED	OPEN
10	Danger	U2 LRVP "B" non condensable inlet isolation valve	02-YV-890	CLOSED	AUTO
11	Danger	U2 LRVP "B" seal water tank equalization isolation valve	02-V-891	CLOSED	OPEN
12	Danger	U2 LRVP "B" INA-YV-883 air supply valve	02-VINA131	CLOSED	OPEN
13	Danger	U2 LRVP "B" east belly drains		OPEN	CLOSED
14	Danger	U2 LRVP "B" west belly drains		OPEN	CLOSED

Unit 2 LRVP Charlie

Tag.#	Attachment	Isolation Device Description	Isolation Device PNID	Isolated Position	Normal Position
1	 Danger	ACC 2 LRVP 01C	02-ARM-MPM-01C	OPEN	CLOSED
2	 Danger	ACC 2 SEAL WTR PMP 02C	02-ARM-MPM-02C	OPEN	CLOSED
3	 Danger	U2 LRVP "C" seal water isolation valve to make up control valve	02-V903B	CLOSED	OPEN
4	 Danger	U2 LRVP "C" seal water isolation valve to make up control valve	V-903E	CLOSED	OPEN
5	 Danger	U2 LRVP "C" seal water isolation valve to bypass to tank	02-V-903A	CLOSED	CLOSED
6	 Danger	U2 LRVP "C" discharge isolation valve off seal water tank	02-V-900A	CLOSED	OPEN
7	 Danger	U2 LRVP "C" seal water discharge isolation valve after heat exch	02-V-901A	CLOSED	OPEN
8	 Danger	U2 LRVP "C" isolation valve to seal water spray valve	02-V-901B	CLOSED	OPEN
9	 Danger	U2 LRVP "C" non condensable suction line	02-V898	CLOSED	OPEN
10	 Danger	U2 LRVP "C" non condensable inlet isolation valve	02-YV-898	CLOSED	AUTO
11	 Danger	U2 LRVP "C" seal water tank equalization isolation valve	02-V-899	CLOSED	OPEN
12	 Danger	U2 LRVP "C" INA-YV-883 air supply valve	02-VINA131	CLOSED	OPEN
13	 Danger	U2 LRVP "C" east belly drains		OPEN	CLOSED
14	 Danger	U2 LRVP "C" west belly drains		OPEN	CLOSED

Unit 2 LRVP Delta

Tag.#	Attachment	Isolation Device Description	Isolation Device PNID	Isolated Position	Normal Position
1	 Danger	ACC 2 LRVP 01D	02-ARM-MPM-01D	OPEN	CLOSED
2	 Danger	ACC 2 SEAL WTR PMP 02D	02-ARM-MPM-02D	OPEN	CLOSED
3	 Danger	U2 LRVP "D" seal water isolation valve to make up control valve	V-911E	CLOSED	OPEN
4	 Danger	U2 LRVP "D" seal water isolation valve to make up control valve	02-V911B	CLOSED	OPEN
5	 Danger	U2 LRVP "D" seal water isolation valve to bypass to tank	02-V-911A	CLOSED	CLOSED
6	 Danger	U2 LRVP "D" discharge isolation valve off seal water tank	02-V-908A	CLOSED	OPEN
7	 Danger	U2 LRVP "D" seal water discharge isolation valve after heat exch	02-V-909A	CLOSED	OPEN
8	 Danger	U2 LRVP "D" isolation valve to seal water spray valve	02-V-909B	CLOSED	OPEN
9	 Danger	U2 LRVP "D" non condensable suction line	02-V906	CLOSED	OPEN
10	 Danger	U2 LRVP "D" non condensable inlet isolation valve	02-YV-906	CLOSED	AUTO
11	 Danger	U2 LRVP "D" seal water tank equalization isolation valve	02-V-907	CLOSED	OPEN
12	 Danger	U2 LRVP "D" INA-YV-883 air supply valve	02-VINA131	CLOSED	OPEN
13	 Danger	U2 LRVP "D" east belly drains		OPEN	CLOSED
14	 Danger	U2 LRVP "D" west belly drains		OPEN	CLOSED

Unit 2 LRVP Echo

Tag.#	Attachment	Isolation Device Description	Isolation Device PNID	Isolated Position	Normal Position
1	 Danger	ACC 2 LRVP 01E	02-ARM-MPM-01E	OPEN	CLOSED
2	 Danger	ACC 2 SEAL WTR PMP 02E	02-ARM-MPM-02E	OPEN	CLOSED
3	 Danger	U2 LRVP "E" seal water isolation valve to make up control valve	V-919B	CLOSED	OPEN
4	 Danger	U2 LRVP "E" seal water isolation valve to make up control valve	V-919E	CLOSED	OPEN
5	 Danger	U2 LRVP "E" seal water isolation valve to bypass to tank	V-919A	CLOSED	CLOSED
6	 Danger	U2 LRVP "E" discharge isolation valve off seal water tank	V-916A	CLOSED	OPEN
7	 Danger	U2 LRVP "E" seal water discharge isolation valve after heat exch	V-917A	CLOSED	OPEN
8	 Danger	U2 LRVP "E" isolation valve to seal water spray valve	V-917B	CLOSED	OPEN
9	 Danger	U2 LRVP "E" non condensable suction line	V914	CLOSED	OPEN
10	 Danger	U2 LRVP "E" non condensable inlet isolation valve	YV-914	CLOSED	AUTO
11	 Danger	U2 LRVP "E" seal water tank equalization isolation valve	V-915	CLOSED	OPEN
12	 Danger	U2 LRVP "E" INA-YV-883 air supply valve		CLOSED	OPEN
13	 Danger	U2 LRVP "E" east belly drains		OPEN	CLOSED
14	 Danger	U2 LRVP "E" west belly drains		OPEN	CLOSED

Unit 2 Turning Gear (2026)

TAG#	Isolation Device Description	Isolation Device PNID	Normal Position	Isolated Position
1	TURNING GEAR MOTOR VFD#1	02MAK11AE101-M01	CLOSED	OPEN
2	TURNING GEAR MOTOR VFD#2	02MAK11AE101-M01	CLOSED	OPEN
3	MANUAL TG DRIVE SHAFT	02-VSTG-001JG	UNLOCKED	OPEN
4	SSS CLUTCH (ENGAGED) OIL SUPPLY SOLENOID VALVE BYPASS VALVE	02MAV10AA108	CLOSED	CLOSED
5	SSS CLUTCH OIL DRAIN SOLENOID VALVE BYPASS VALVE	02MAV10AA112	CLOSED	CLOSED

Unit 2 Ignitor 2026

TAG#	Isolation Device Description	Isolation Device PNID	Normal Position	Isolated Position
1	GT IGNITION EXCITER	02MBM01GU001	CLOSED	OPEN
2	INA to GT ignitors	02QFF11AA112	OPEN	CLOSED

Unit 2 CCW ACHE fans (2026)

TAG#	Isolation Device Description	Isolation Device PNID	Normal Position	Isolated Position
1	UNIT 2 ACHE FAN 01A	02-CCW-MFN-01A	CLOSED	OPEN
2	UNIT 2 ACHE FAN 01B	02-CCW-MFN-01B	CLOSED	OPEN
3	UNIT 2 ACHE FAN 01C	02-CCW-MFN-01C	CLOSED	OPEN
4	UNIT 2 ACHE FAN 02A	02-CCW-MFN-02A	CLOSED	OPEN
5	UNIT 2 ACHE FAN 02B	02-CCW-MFN-02B	CLOSED	OPEN
6	UNIT 2 ACHE FAN 02C	02-CCW-MFN-02C	CLOSED	OPEN
7	UNIT 2 ACHE FAN 03A	02-CCW-MFN-03A	CLOSED	OPEN
8	UNIT 2 ACHE FAN 03B	02-CCW-MFN-03B	CLOSED	OPEN
9	UNIT 2 ACHE FAN 03C	02-CCW-MFN-03C	CLOSED	OPEN
10	UNIT 2 ACHE FAN 04A	02-CCW-MFN-04A	CLOSED	OPEN
11	UNIT 2 ACHE FAN 04B	02-CCW-MFN-04B	CLOSED	OPEN
12	UNIT 2 ACHE FAN 04C	02-CCW-MFN-04C	CLOSED	OPEN
13	UNIT 2 ACHE FAN 05A	02-CCW-MFN-05A	CLOSED	OPEN
14	UNIT 2 ACHE FAN 05B	02-CCW-MFN-05B	CLOSED	OPEN
15	UNIT 2 ACHE FAN 05C	02-CCW-MFN-05C	CLOSED	OPEN

Unit 2 Air bowl Regulators

TAG#	Isolation Device Description	Isolation Device PNID	Normal Position	Isolated Position
7	INA SUPPLY FOR 02MBH05AA753	02-VINA268	OPEN	OPEN
2	INA SUPPLY FOR 02MBP01AA711	02-VINA239	OPEN	OPEN
6	INA SUPPLY TO 02MBH05AA751	02-VINA412	OPEN	OPEN
8	INA SUPPLY TO 02MBH06AA713	02-VINA264	OPEN	OPEN
9	INA SUPPLY TO 02MBH06AA716	02-VINA140	OPEN	OPEN
3	INA SUPPLY TO 02MBP01AA721	02-VINA143	OPEN	OPEN
5	INA SUPPLY TO 02MBP01AA723	02-VINA145	OPEN	OPEN
1	INA SUPPLY VALVE TO 02MBP01AA701	02-VINA196	OPEN	OPEN
4	INA SUPPLY VALVE TO 02MBP01AA722	02-VINA182	OPEN	OPEN

Unit 1 CCW ACHE fans (2026)

TAG#	Isolation Device Description	Isolation Device PNID	Normal Position	Isolated Position
1	UNIT 1 ACHE FAN 01A	01-CCW-MFN-01A	CLOSED	CLOSED
2	UNIT 1 ACHE FAN 01B	01-CCW-MFN-01B	CLOSED	CLOSED
3	UNIT 1 ACHE FAN 01C	01-CCW-MFN-01C	CLOSED	CLOSED
4	UNIT 1 ACHE FAN 02A	01-CCW-MFN-02A	CLOSED	CLOSED
5	UNIT 1 ACHE FAN 02B	01-CCW-MFN-02B	CLOSED	CLOSED
6	UNIT 1 ACHE FAN 02C	01-CCW-MFN-02C	CLOSED	CLOSED
7	UNIT 1 ACHE FAN 03A	01-CCW-MFN-03A	CLOSED	CLOSED
8	UNIT 1 ACHE FAN 03B	01-CCW-MFN-03B	CLOSED	CLOSED
9	UNIT 1 ACHE FAN 03C	01-CCW-MFN-03C	CLOSED	CLOSED
10	UNIT 1 ACHE FAN 04A	01-CCW-MFN-04A	CLOSED	CLOSED
11	UNIT 1 ACHE FAN 04B	01-CCW-MFN-04B	CLOSED	CLOSED
12	UNIT 1 ACHE FAN 04C	01-CCW-MFN-04C	CLOSED	CLOSED
13	UNIT 1 ACHE FAN 05A	01-CCW-MFN-05A	CLOSED	CLOSED
14	UNIT 1 ACHE FAN 05B	01-CCW-MFN-05B	CLOSED	CLOSED
15	UNIT 1 ACHE FAN 05C	01-CCW-MFN-05C	CLOSED	CLOSED

Unit 1 Turning Gear

TAG#	Isolation Device Description	Isolation Device PNID	Normal Position
1	TURNING GEAR MOTOR VFD#1	01MAK11AE101-M01	CLOSED
2	TURNING GEAR MOTOR VFD#2	01MAK11AE101-M01	CLOSED
3	MANUAL TG DRIVE SHAFT	01-VSTG-001JG	UNLOCKED
4	SSS CLUTCH (ENGAGED) OIL SUPPLY SOLENOID VALVE BYPASS VALVE	01MAV10AA108	CLOSED
5	SSS CLUTCH OIL DRAIN SOLENOID VALVE BYPASS VALVE	01MAV10AA112	CLOSED

Unit 1 Seal oil (2026)

TAG#	Isolation Device Description	Isolation Device PNID	Normal Position	Isolated Position
1	MAIN SEAL OIL PUMP	01MKW01AP101-M01	CLOSED	OPEN
2	SEAL OIL PUMP DISCONNECT	01MKW04AP101-M01	CLOSED	OPEN
3	SEAL OIL VACUUM PUMP MOTOR(A)	01MKW05AP201-M01	CLOSED	OPEN
4	SEAL OIL VACUUM PUMP MOTOR(B)	01MKW05AP202-M01	CLOSED	OPEN
5	H2 ISOLATION	01-VCMG103	OPEN	CLOSED
6	H2 VENT	01-VCMG602	CLOSED	OPEN
7	H2 ISOLATION	01-VCMG113	OPEN	CLOSED
8	MINI BULK CO2 OUTLET ISO	01-VCMG-009JG	CLOSED	CLOSED
9	Unit 1 CO2 mini bulk tank vent 01-V-CMG004-JG	01-V-CMG004-JG	CLOSED	OPEN
10	HYDROGEN SUPPLY SPOOL PIECE	01-VCMG-007JG	INSTALLED	REMOVED
11	CO2 SUPPLY SPOOL PIECE	01-VCMG-006JG	INSTALLED	REMOVED
12	SEAL OIL FEED INLET (FROM L.O. SYS)	01MKW01AA101	OPEN	CLOSED
13	HYDROGEN GAS DRYER	01MKG03AT001	CLOSED	OPEN

Unit 1 Lube oil (2026)

TAG#	Isolation Device Description	Isolation Device PNID	Normal Position	Isolated Position
1	Emergency Lube Oil Pump Motor	01MPV01AP401-M01	CLOSED	OPEN
2	UNIT 1 MAIN LUBE OIL PUMP MOTOR A	01MPV01AP101-M01	CLOSED	OPEN
3	UNIT 1 MAIN LUBE OIL PUMP MOTOR B	01MPV01AP102-M01	CLOSED	OPEN
4	LUBE OIL VAPOR EXTRACTOR A	01MPV03AN101-M01	CLOSED	OPEN
5	LUBE OIL VAPOR EXTRACTOR B	01MPV03AN102-M01	CLOSED	OPEN
6	JACKING OIL PUMP A	01MKV05AP201-M01	CLOSED	OPEN
7	JACKING OIL PUMP B	01MKV05AP202-M01	CLOSED	OPEN
8	LUBE OIL PURIFIER PUMP MOTOR	01MPV21AP101-M01	CLOSED	OPEN
9	GENERATOR VAPOR EXTRACTOR MOTOR	01MKV04AN101-M01	CLOSED	OPEN
10	LUBE OIL HEATER (A)	01MPV01AH101	CLOSED	OPEN
11	LUBE OIL HEATER (B)	01MPV01AH102	CLOSED	OPEN
12	LUBE OIL HEATER (C)	01MPV01AH103	CLOSED	OPEN
13	LUBE OIL HEATER (D)	01MPV01AH104	CLOSED	OPEN

Unit 1 Control Oil

Tag.#	Attachment	Isolation Device Description	Isolation Device PNID	Isolated Position	Normal Position
1	 Danger	CONTROL OIL PUMP MOTOR (A)	01MPX01AP101-M01	OPEN	CLOSED
2	 Danger	CONTROL OIL PUMP MOTOR (B)	01MPX01AP102-M01	OPEN	CLOSED
3	 Danger	CONTROL OIL POLISHING PUMP	01MPX11AP101-M01	OPEN	CLOSED
4	 Danger	CONTROL OIL HEATER	01MPX01AH101	OPEN	CLOSED
5	 Danger	U1 GT IGV Actuator Control Oil Outlet Valve	01MBX01AA203	CLOSED	OPEN
6	 Danger	U1 GT VV Actuator Control Oil Outlet Valve	01MBX01AA204	CLOSED	OPEN
7	 Danger	U1 GT IGV Actuator Control Oil Inlet Valve	01MBX01AA103	CLOSED	OPEN
8	 Danger	U1 GT VV Actuator Control Oil Inlet Valve	01MBX01AA104	CLOSED	OPEN

Unit 1 CO2 Fire System

TAG#	Isolation Device Description	Isolation Device PNID	Normal Position	Isolated Position
1	CO2 ACTUATION LINE ISOLATION VALVE	01SGJ02AA001	OPEN	CLOSED
2	CO2 TO GAS TURBINE ENCLOSURE ISOLATION VALVE	01SGJ02AA103	OPEN	CLOSED
3	SLIP RING HOUSING ISOLATION VALVE	01SGJ02AA202	OPEN	CLOSED

Unit 1 Helen strainer

Tag.#	Attachment	Isolation Device Description	Isolation Device PNID	Isolated Position	Normal Position
1	 Danger	BFW SUCTION LP DRUM ISOLATION	01-VBFW152	CLOSED	OPEN
2	 Danger	BFW SUCTION LP DRUM ISOLATION BYPASS	01-VBFW152A	CLOSED	CLOSED
3	 Danger	BFP SUCTION ISO FROM CONDENSATE	01-VBFW264	CLOSED	OPEN
4	 Danger	BFP SUCTION ISO FROM CONDENSATE BYPASS	01-VBFW264A	CLOSED	CLOSED
5	 Danger	BFP A SUCTION ISOLATION	01-VBFW265	CLOSED	OPEN
6	 Danger	1A BFP suction bypass	01-VBFW265A	CLOSED	CLOSED
7	 Danger	BFP B SUCTION ISOLATION	01-VBFW266	CLOSED	OPEN
8	 Danger	1B BFP suction bypass	01-VBFW266A	CLOSED	CLOSED

Unit 1 Air Bowl Regulators

TAG#	Isolation Device Description	Isolation Device PNID	Normal Position	Isolated Position
7	INA SUPPLY FOR 01MBH05AA753	01-VINA268	OPEN	OPEN
3	INA SUPPLY TO 01-MBP-01AA721	01-VINA143	OPEN	OPEN
6	INA SUPPLY TO 01MBH05AA751	01-VINA412	OPEN	OPEN
8	INA SUPPLY TO 01MBH06AA713	01-VINA264	OPEN	OPEN
9	INA SUPPLY TO 01MBH06AA716	01-VINA140	OPEN	OPEN
5	INA SUPPLY TO 01MBP-01AA723	01-VINA145	OPEN	OPEN
4	INA SUPPLY VALVE TO 01-MBP-01AA722	01-VINA182	OPEN	OPEN
1	INA SUPPLY VALVE TO 01MBP01AA701	01-VINA196	OPEN	OPEN
2	INA TO FG EMERG VENT (01MBP01AA711)	01-VINA239	OPEN	OPEN

Unit 1 Generator

Tag.#	Attachment	Isolation Device Description	Isolation Device PNID	Isolated Position	Normal Position
1	 Danger	GCB Disconnect 89G-1	89G-1/ Q91	OPEN	CLOSED
2	 Danger	Generator Site Ground 57GG-1	Generator Site Ground ...	CLOSED	OPEN
3	 Danger	SFC TO U1 GENERATOR DISCONNECT	89SS-1	OPEN	
4	 Danger	CO2 ACTUATION LINE ISOLATION VALVE	01SGJ02AA001	CLOSED	OPEN
5	 Danger	SLIP RING HOUSING ISOLATION VALVE	01SGJ02AA202	CLOSED	OPEN

Unit 1 Fireside

Tag.#	Attachment	Isolation Device Description	Isolation Device PID	Isolated Position	Normal Position
1	Danger	SFC TO U1 GENERATOR DISCONNECT	89SS-1-1/Q91	OPEN	CLOSED
2	Danger	DISCONNECT DOWNSTREAM OF GCB U1	89G-1- 1/Q81	OPEN	CLOSED
3	Danger	U1 GT ENHANCED AIR COMPRESSOR A	01-MBH06AN101	OPEN	CLOSED
4	Danger	U1 GT ENHANCED AIR COMPRESSOR B	01-MBH06AN102	OPEN	CLOSED
5	Danger	GT ECA COMPRESSOR A AUX OIL PUMP	01MBH06AP401-M01	OPEN	CLOSED
6	Danger	GT ECA COMPRESSOR B AUX OIL	01MBH06AP402-M01	OPEN	CLOSED
7	Danger	GT ECA COMPRESSOR A VAPOR EXTRACTOR (A)	01MBH06AN103-M01	OPEN	CLOSED
8	Danger	GT ECA COMPRESSOR A VAPOR EXTRACTOR (B)	01MBH06AN104-M01	OPEN	CLOSED
9	Danger	GT ECA COMPRESSOR B VAPOR EXTRACTOR (A)	01MBH06AN105-M01	OPEN	CLOSED
10	Danger	GT ECA COMPRESSOR B VAPOR EXTRACTOR (B)	01MBH06AN106-M01	OPEN	CLOSED
11	Danger	GT ECA COMPRESSOR "A" ENCLOSURE FAN (A)	01MBH06AN107-M01	OPEN	CLOSED
12	Danger	GT ECA COMPRESSOR "A" ENCLOSURE FAN (B)	01MBH06AN108-M01	OPEN	CLOSED
13	Danger	GT ECA COMPRESSOR "B" ENCLOSURE (A)	01MBH06AN109-M01	OPEN	CLOSED
14	Danger	GT ECA COMPRESSOR "B" ENCLOSURE (B)	01MBH06AN110-M01	OPEN	CLOSED
15	Danger	GT ECA COMPRESSOR A OIL HEATER	01MBH06AH101	OPEN	CLOSED
16	Danger	GT ECA COMPRESSOR B OIL HEATER	01MBH06AH102	OPEN	CLOSED
17	Danger	GT PACKAGE VENTILATION FAN A	01MBA11AN101-M01	OPEN	CLOSED
18	Danger	GT PACKAGE VENTILATION FAN B	01MBA11AN102-M01	OPEN	CLOSED
19	Danger	GT CASING COOLING AIR FAN	01QEF13AN101-M01	OPEN	CLOSED
20	Danger	GT IGNITION EXCITER	01MBM01GU001	OPEN	CLOSED
21	Danger	HRSG 1 AMMONIA INJECTION BLOWER A	01-SCR-MFN-100A	OPEN	CLOSED
22	Danger	HRSG 1 AMMONIA INJECTION BLOWER B	01-SCR-MFN-100B	OPEN	CLOSED
23	Danger	UNIT 1 HRSG DUCT BURNER COOLING SKID BLOWER 1	01-BUR-MLB-01A	OPEN	CLOSED
24	Danger	UNIT 1 HRSG DUCT BURNER COOLING SKID BLOWER 2	01-BUR-MLB-01B	OPEN	CLOSED
25	Danger	HRG 1 DCT BNR MAIN 120VAC	01-BUR-CPL-01	OPEN	CLOSED
26	Danger	TB-DC1 fuse #5	Forney - B10287-070-06	pulled	inserted
27	Danger	TB-DC1 fuse # 6	Forney - B10287-070-06	pulled	inserted
28	Danger	TB-DC1 fuse # 8	Forney - B10287-070-06	pulled	inserted
29	Danger	TB-DC1 fuse # 9	forney - B10287-070-06	pulled	inserted
30	Danger	TB-AC1 fuse # 7	Forney B10287-070-05A	pulled	inserted
31	Danger	UNIT 1 DUCT BURNER CONTROL VALVE MANUAL ISOLATION	01-VFGS179	CLOSED	OPEN
32	Danger	UNIT 1 DUCT BURNER CONTROL VALVE MANUAL ISOLATION	01-VFGS176	CLOSED	OPEN
33	Danger	DUCT BURNER SOV INA SUPPLY	01-VFGS922	CLOSED	OPEN
34	Danger	UNIT 1 DUCT BURNER SKID VENT	01-VFGS217	OPEN	CLOSED
35	Danger	FLOW METER BYPASS	01-VFGS122	CLOSED	OPEN
36	Danger	GAS TURBINE FUEL GAS CARTRIDGE FILTER INLET	01-VFGS174	CLOSED	OPEN
37	Danger	EMERGENCY VENT VALVE BYPASS	01-VFGS123	OPEN	CLOSED
38	Danger	CO2 ACTUATION LINE ISOLATION VALVE	01SGJ02AA001	CLOSED	OPEN
39	Danger	CO2 TO GAS TURBINE ENCLOSURE ISOLATION VALVE	01SGJ02AA103	CLOSED	OPEN
40	Danger	SLIP RING HOUSING ISOLATION VALVE	01SGJ02AA202	CLOSED	OPEN
41	Danger	UNIT 1 GAS TURBINE ENCLOSURE FUEL VENT	01-VFGS177	OPEN	CLOSED
42	Danger	UNIT 1 GAS TURBINE ENCLOSURE FUEL VENT	01-VFGS178	OPEN	CLOSED
43	Danger	Ammonia injection manual isolation (upstream)	01-VAQA800	CLOSED	OPEN
44	Danger	Ammonia injection manual isolation (downstream)	01-VAQA818	CLOSED	OPEN
45	Danger	Ammonia injection line drain	01-VAQA813	OPEN	CLOSED

Unit 1 Waterside

Tag.#	Attachment	Isolation Device Description	Isolation Device PNID	Isolated Position	Normal Position
1	 Danger	U1 BOILER FEED WATER PUMP A	01-BFW-MPM-01A	OPEN	CLOSED
2	 Danger	U1 BOILER FEED WATER PUMP B	01-BFW-MPM-01B	OPEN	CLOSED
3	 Danger	U1 CONDENSATE PUMP A	01-CND-MPM-01A	OPEN	CLOSED
4	 Danger	U1 CONDENSATE PUMP B	01-CND-MPM-01B	OPEN	CLOSED
5	 Danger	U1 CONDENSATE PUMP C	01-CND-MPM-01C	OPEN	CLOSED
6	 Danger	GT 2C/ECA RECIRCULATION PUMP (A)	01LCA14AP101	OPEN	CLOSED
7	 Danger	GT 2C/ECA RECIRCULATION PUMP (B)	01LCA14AP102	OPEN	CLOSED
8	 Danger	ACC 1 LRVP 01A	01-ARM-MPM-01A	OPEN	CLOSED
9	 Danger	ACC 1 LRVP 01B	01-ARM-MPM-01B	OPEN	CLOSED
10	 Danger	ACC 1 LRVP 01C	01-ARM-MPM-01C	OPEN	CLOSED
11	 Danger	ACC 1 LRVP 01D	01-ARM-MPM-01D	OPEN	CLOSED
12	 Danger	ACC 1 LRVP 01E	01-ARM-MPM-01E	OPEN	CLOSED
13	 Danger	UNIT 1 LP DRAINS TANK PUMP MTR A	01-STP-MPM-01A	OPEN	CLOSED
14	 Danger	UNIT 1 LP DRAINS TANK PUMP MTR B	01-STP-MPM-01B	OPEN	CLOSED
15	 Danger	UNIT 1 PHOSPHATE & AMMONIA MAIN FEED DISCONNECT	01-CCF-SKD-02	OPEN	CLOSED
16	 Danger	DEMIN FILL TO CND STOP CHECK	01-VCND236	CLOSED	OPEN
17	 Danger	DEMIN FILL TO CND DRAIN VALVE	01-VCND237	OPEN	CLOSED
18	 Danger	DEMIN FILL TO CND ISOLATION	01-VCND238	CLOSED	OPEN
19	 Danger	UNIT 1 MAKE UP VALVE BYPASS	01-VDWS636	CLOSED	OPEN
20	 Danger	UNIT 1 MAKE UP CONTROL VALVE MANUAL ISOLATION (upstream)	01-VDWS638	CLOSED	OPEN
21	 Danger	UNIT 1 MAKE UP CONTROL VALVE MANUAL ISOLATION (downstream)	01-VDWS639	CLOSED	OPEN
22	 Danger	UNIT 1 EMERGENCY MAKE UP CONTROL VALVE MANUAL ISOLATION (...)	01-VDWS641	CLOSED	OPEN
23	 Danger	UNIT 1 EMERGENCY MAKE UP CONTROL VALVE MANUAL ISOLATION (...)	01-VDWS642	CLOSED	OPEN
24	 Danger	UNIT 1 EMERGENCY MAKE WATER DRAIN VALVE	01-VDWS643	OPEN	CLOSED
25	 Danger	UNIT 1 NORMAL MAKE WATER DRAIN VALVE	01-VDWS648	OPEN	CLOSED
26	 Danger	Aux steam to U1 main block iso	01-VAXS631	CLOSED	OPEN
27	 Danger	Aux steam to U1 main iso	01-VAXS630	CLOSED	OPEN
28	 Danger	Aux steam to U1 main block bypass	01-VAXS632	CLOSED	CLOSED
29	 Danger	Aux steam to U1 main header vent	01-VAXS633	OPEN	CLOSED

Unit 1 GSU

Tag.#	Attachment	Isolation Device Description	Isolation Device PNID	Isolated Position	Normal Position
1	 Danger	U1 Closing/Pri fuse for 01-SYD-BKR-01	01-SYD-BKR-01	OPEN	CLOSED
2	 Danger	U1 Switch Yard Disconnect	01-SYD-DSW-02	OPEN	CLOSED
3	 Danger	U1 Switch Yard Disconnect DC breaker	01-SYD-DSW-02 Brker ...	OPEN	CLOSED
4	 Danger	3000A Main Breaker 52-1-M1	00-UAT-XFR-1	OPEN	CLOSED
5	 Danger	Generator Disconnect GCB 89G	01-HYH-GEN132C	OPEN	CLOSED
6	 Danger	U1 GCB 57TG-1	01-HYH-GCB132E	CLOSED	OPEN

Unit 1 LRVP Alpha

Tag.#	Attachment	Isolation Device Description	Isolation Device PNID	Isolated Position	Normal Position
1	Danger	ACC 1 LRVP 01A	01-ARM-MPM-01A	OPEN	CLOSED
2	Danger	ACC 1 SEAL WTR PMP 02A	01-ARM-MPM-02A	OPEN	CLOSED
3	Danger	U1 LRVP A seal water isolation valve to make up control valve	V-888E	CLOSED	OPEN
4	Danger	U1 LRVP A seal water isolation valve to make up control valve	01-V888B	CLOSED	OPEN
5	Danger	U1 LRVP A seal water isolation valve to bypass to tank	01-V-888A	CLOSED	CLOSED
6	Danger	U1 LRVP A discharge isolation valve off seal water tank	01-V-885A	CLOSED	OPEN
7	Danger	U1 LRVP A seal water discharge isolation valve after heat exchan	01-V-886A	CLOSED	OPEN
8	Danger	U1 LRVP A isolation valve to seal water spray valve	01-V-886B	CLOSED	OPEN
9	Danger	U1 LRVP A non condensable suction line	01-V883	CLOSED	OPEN
10	Danger	U1 LRVP A non condensable inlet isolation valve	01-YV-883	CLOSED	AUTO
11	Danger	U1 LRVP A seal water tank equalization isolation valve	01-V-884	CLOSED	OPEN
12	Danger	U1 LRVP A INA-YV-883 air supply valve	01-VINA131	CLOSED	OPEN
13	Danger	U1 LRVP east belly drains		OPEN	CLOSED
14	Danger	U1 LRVP west belly drains		OPEN	CLOSED

Unit 1 LRVP Bravo

Tag.#	Attachment	Isolation Device Description	Isolation Device PNID	Isolated Position	Normal Position
1	Danger	ACC 1 LRVP 01B	01-ARM-MPM-01B	OPEN	CLOSED
2	Danger	ACC 1 SEAL WTR PMP 02B	01-ARM-MPM-02B	OPEN	CLOSED
3	Danger	U1 LRVP "B" seal water isolation valve to make up control valve	V-895E	CLOSED	OPEN
4	Danger	U1 LRVP "B" seal water isolation valve to make up control valve	01-V895B	CLOSED	OPEN
5	Danger	U1 LRVP "B" seal water isolation valve to bypass to tank	01-V-895A	CLOSED	CLOSED
6	Danger	U1 LRVP "B" discharge isolation valve off seal water tank	01-V-892A	CLOSED	OPEN
7	Danger	U1 LRVP "B" seal water discharge isolation valve after heat exch	01-V-893A	CLOSED	OPEN
8	Danger	U1 LRVP "B" isolation valve to seal water spray valve	01-V-893B	CLOSED	OPEN
9	Danger	U1 LRVP "B" non condensable suction line	01-V890	CLOSED	OPEN
10	Danger	U1 LRVP "B" non condensable inlet isolation valve	01-YV-890	CLOSED	AUTO
11	Danger	U1 LRVP "B" seal water tank equalization isolation valve	01-V-891	CLOSED	OPEN
12	Danger	U1 LRVP "B" INA-YV-883 air supply valve	01-VINA131	CLOSED	OPEN
13	Danger	U1 LRVP "B" east belly drains		OPEN	CLOSED
14	Danger	U1 LRVP "B" west belly drains		OPEN	CLOSED

Unit 1 LRVP Charlie

Tag.#	Attachment	Isolation Device Description	Isolation Device PNID	Isolated Position	Normal Position
1	Danger	ACC 1 LRVP 01C	01-ARM-MPM-01C	OPEN	CLOSED
2	Danger	ACC 1 SEAL WTR PMP 02C	01-ARM-MPM-02C	OPEN	CLOSED
3	Danger	U1 LRVP "C" seal water isolation valve to make up control valve	01-V903B	CLOSED	OPEN
4	Danger	U1 LRVP "C" seal water isolation valve to make up control valve	V-903E	CLOSED	OPEN
5	Danger	U1 LRVP "C" seal water isolation valve to bypass to tank	01-V-903A	CLOSED	CLOSED
6	Danger	U1 LRVP "C" discharge isolation valve off seal water tank	01-V-900A	CLOSED	OPEN
7	Danger	U1 LRVP "C" seal water discharge isolation valve after heat exch	01-V-901A	CLOSED	OPEN
8	Danger	U1 LRVP "C" isolation valve to seal water spray valve	0-V-901B	CLOSED	OPEN
9	Danger	U1 LRVP "C" non condensable suction line	01-V898	CLOSED	OPEN
10	Danger	U1 LRVP "C" non condensable inlet isolation valve	01-YV-898	CLOSED	AUTO
11	Danger	U1 LRVP "C" seal water tank equalization isolation valve	01-V-899	CLOSED	OPEN
12	Danger	U1 LRVP "C" INA-YV-883 air supply valve	01-VINA131	CLOSED	OPEN
13	Danger	U1 LRVP "C" east belly drains		OPEN	CLOSED
14	Danger	U1 LRVP "C" west belly drains		OPEN	CLOSED

Unit 1 LRVP Delta

Tag.#	Attachment	Isolation Device Description	Isolation Device PNID	Isolated Position	Normal Position
1	Danger			OPEN	CLOSED
2	Danger	ACC 1 SEAL WTR PMP 02D	01-ARM-MPM-02D	OPEN	CLOSED
3	Danger	U1 LRVP "D" seal water isolation valve to make up control valve	V-911E	CLOSED	OPEN
4	Danger	U1 LRVP "D" seal water isolation valve to make up control valve	01-V911B	CLOSED	OPEN
5	Danger	U1 LRVP "D" seal water isolation valve to bypass to tank	01-V-911A	CLOSED	CLOSED
6	Danger	U1 LRVP "D" discharge isolation valve off seal water tank	01-V-908A	CLOSED	OPEN
7	Danger	U1 LRVP "D" seal water discharge isolation valve after heat exch	01-V-909A	CLOSED	OPEN
8	Danger	U1 LRVP "D" isolation valve to seal water spray valve	01-V-909B	CLOSED	OPEN
9	Danger	U1 LRVP "D" non condensable suction line	01-V906	CLOSED	OPEN
10	Danger	U1 LRVP "D" non condensable inlet isolation valve	01-YV-906	CLOSED	AUTO
11	Danger	U1 LRVP "D" seal water tank equalization isolation valve	01-V-907	CLOSED	OPEN
12	Danger	U1 LRVP "D" INA-YV-883 air supply valve	01-VINA131	CLOSED	OPEN
13	Danger	U1 LRVP "D" east belly drains		OPEN	CLOSED
14	Danger	U1 LRVP "D" west belly drains		OPEN	CLOSED

Unit 1 LRVP Echo

Tag.#	Attachment	Isolation Device Description	Isolation Device PNID	Isolated Position	Normal Position
1	Danger	ACC 1 LRVP 01E	01-ARM-MPM-01E	OPEN	CLOSED
2	Danger	ACC 1 SEAL WTR PMP 02E	01-ARM-MPM-02E	OPEN	CLOSED
3	Danger	U1 LRVP "E" seal water isolation valve to make up control valve	V-919B	CLOSED	OPEN
4	Danger	U1 LRVP "E" seal water isolation valve to make up control valve	V-919E	CLOSED	OPEN
5	Danger	U1 LRVP "E" seal water isolation valve to bypass to tank	V-919A	CLOSED	CLOSED
6	Danger	U1 LRVP "E" discharge isolation valve off seal water tank	V-916A	CLOSED	OPEN
7	Danger	U1 LRVP "E" seal water discharge isolation valve after heat exch	V-917A	CLOSED	OPEN
8	Danger	U1 LRVP "E" isolation valve to seal water spray valve	V-917B	CLOSED	OPEN
9	Danger	U1 LRVP "E" non condensable suction line	V914	CLOSED	OPEN
10	Danger	U1 LRVP "E" non condensable inlet isolation valve	YV-914	CLOSED	AUTO
11	Danger	U1 LRVP "E" seal water tank equalization isolation valve	V-915	CLOSED	OPEN
12	Danger	U1 LRVP "E" INA-YV-883 air supply valve		CLOSED	OPEN
13	Danger	U1 LRVP "E" east belly drains		OPEN	CLOSED
14	Danger	U1 LRVP "E" west belly drains		OPEN	CLOSED

U1 Fuel gas performance heater flow meter

Tag.#	Attachment	Isolation Device Description	Isolation Device PNID	Isolated Position	Normal Position
1	Danger	UNIT 1 GAS FLOW METER INLET	01-VFGS113	CLOSED	OPEN
2	Danger	FLOW METER BYPASS	01-VFGS122	CLOSED	CLOSED
3	Danger	UNIT 1 GAS TURBINE ENCLOSURE FUEL VENT	01-VFGS177	OPEN	CLOSED
4	Danger	UNIT 1 GAS TURBINE ENCLOSURE FUEL VENT	01-VFGS178	OPEN	CLOSED

BOP Air Compressor Alpha

TAG#	Isolation Device Description	Isolation Device PNID	Normal Position	Isolated Position
2	AIR COMPRESSOR 01A ISOLATION	00-VIA636	OPEN	CLOSED
1	AIR COMPRESSOR A	01-IA-PNL-01A	CLOSED	OPEN
3	INSTURMENT AIR DRAIN	00-VIA670	CLOSED	OPEN

Air Compressor Bravo

TAG#	Isolation Device Description	Isolation Device PNID	Normal Position	Isolated Position
2	AIR COMPRESSOR 01B ISOLATION	00-VIA648	OPEN	CLOSED
1	AIR COMPRESSOR B	00-IA-CMP-01B	CLOSED	OPEN
3	COMPRESSED AIR DRAIN	00-VIA615	CLOSED	OPEN