

ECE 105: Introduction to Electrical Engineering

Lecture 13
Bio 3
Yasser Khan
Rehan Kapadia

Pulse oximetry






ECG

Pulse Ox


Respiration

Blood Pressure

- Pulse oximetry measures blood oxygenation. Using spectrophotometry of absorptivity of blood at two distinct wavelengths, blood oxygen saturation is quantified.
- Can detect hypoxemia, ie. lower than normal blood oxygenation.




Temperature




- $SO_2 = \frac{C_{HbO_2}}{C_{HbO_2} + C_{Hb}}$
- To microprocessor
 - SO₂ The saturation of oxygen in blood,
 - C_{HbO2} Concentration of oxygenated hemoglobin (HbO₂),
 - C_{Hb} Concentration of deoxygenated hemoglobin (Hb).

Transmission vs. reflectance oximetry









- Transmission-mode pulse oximetry is limited only to tissues that can be transilluminated, such as the earlobes and the fingers.
- If reflected light is used as the signal, the sensor can be used beyond the conventional sensing locations.

- AC signal is the highest at the forehead for both Red and NIR channels.
- Arms provide mid-range AC amplitude, while signal strength is low in the legs and chest area.
- Forehead is the best location for reflectance pulse oximetry.




Oximeter readout circuit








Calculating oxygen saturation

















$$R = \frac{AC_{rd}/DC_{rd}}{AC_{ir}/DC_{ir}}$$

$$R = \frac{20mV/625mV}{20mV/330mV} = .528$$

Pulse oximeter basics






Figure 4.6 The normalization of the signals. The transmitted light from the red LED (R) and from the infrared LED (IR) is divided by its individual DC component. Thus, both normalized light intensities have the same magnitude during diastole. The normalized signals determine the basis for the calculation of the arterial oxygen saturation.




Figure 4.7 Calibration curves for pulse oximeters: the solid line is the theoretical curve by Beer's law and the dashed line is the empirical curve. The difference between these curves is due mainly to light scattering effects. This empirical calibration curve is derived by a second order polynomial.

AFE - MAX30102



Click <u>here</u> for production status of specific part numbers.

MAX30102

High-Sensitivity Pulse Oximeter and Heart-Rate Sensor for Wearable Health

General Description

The MAX30102 is an integrated pulse oximetry and heart-rate monitor module. It includes internal LEDs, photodetectors, optical elements, and low-noise electronics with ambient light rejection. The MAX30102 provides a complete system solution to ease the design-in process for mobile and wearable devices.

The MAX30102 operates on a single 1.8V power supply and a separate 3.3V power supply for the internal LEDs. Communication is through a standard I²C-compatible interface. The module can be shut down through software with zero standby current, allowing the power rails to remain powered at all times.

Applications

- Wearable Devices
- Fitness Assistant Devices
- Smartphones
- Tablets

Benefits and Features


- Heart-Rate Monitor and Pulse Oximeter Sensor in LED Reflective Solution
- Tiny 5.6mm x 3.3mm x 1.55mm 14-Pin Optical Module
 - Integrated Cover Glass for Optimal, Robust Performance
- Ultra-Low Power Operation for Mobile Devices
 - Programmable Sample Rate and LED Current for Power Savings
 - Low-Power Heart-Rate Monitor (< 1mW)
 - Ultra-Low Shutdown Current (0.7µA, typ)
- Fast Data Output Capability
 - · High Sample Rates
- Robust Motion Artifact Resilience
 - High SNR
- 40°C to +85°C Operating Temperature Range

Ordering Information appears at end of data sheet.



Connection








Press capture











Keep your finger gently on the sensor








Time domain to frequency domain




• The Fourier transform is an analysis process, decomposing a complex-valued function into its constituent frequencies and their amplitudes.




Time domain to frequency domain




 The Fourier transform is an analysis process, decomposing a complex-valued function into its constituent frequencies and their amplitudes.






Time domain to frequency domain






What makes a square wave









Going back to the PPG data collected






Smoothing






Drift correction






Peak detection






Heart rate






Using single component to find heart rate






4 components in the PPG signal – signal loss






Taking all the components provides the original signal





Ratio of the ratios





(Red PPG Signal) DC Average: 99986.91, AC Average: 139.15 (IR PPG Signal) DC Average: 116077.38, AC Average: 386.22 Red signal ratio (red_ac/red_dc): 0.0013916875411345753 IR signal ratio (ir_ac/ir_dc): 0.0033272520894769473 Ratio of Ratios (Red ratio/ IR ratio): 0.4182693416997304

SpO2 calculation



