



FAQ (Frequently Asked

Q: Does the Draper Drum come with drive sprockets?

A: No, you will have to keep your OEM drive sprockets from your adapter. If yours are worn out, you may have to purchase new ones. If you are having issues with drive chain slippage, verify that your sprockets are in good condition. **The Draper Drum kit (CA20 or cA25) should come with everything else you need unless the customer has an early serial number MD D50 or a Case 2142.** Then they will need to get a spring and an eye bolt from their dealer. Consult the installation instructions for more details.

Q: Wrapping. What can I do?

A: With the new flighting design this should not be an issue. However, if wrapping continues try the following to resolve it. **Adjust the finger timing.** Do this by moving the timing lever all the way back towards the combine. This will cause the fingers to retract sooner and allow crop to flow better. If this does not fix it, **try moving the lever all the way to the front.** See which adjustment helps then fine tune it by adjusting the lever one hole at a time. Another option, if there is a specific area that wrapping continue to occur, **you can try to remove some fingers** in this area. You can remove up to half of the fingers if needed.

Q: What can I do to stop product from piling up behind the drum?

A: In this situation, try **adjusting the fingers.** Move the timing lever all the way to the front. This will keep the fingers extended longer and allow for more product being pushed into the feeder house.

Q: Is there a way to speed up the auger rotation for heavy crops or conditions?

A: Yes, we have a speed up kit available that will add some rotation speed to the Draper Drum kit. **The drive chain must be upgraded to #80 chain and this kit can not be used with the early versions of the Draper Drum before the Series 2 version as the shafts are not strong enough for the added stress. Shaft upgrade kits are available. (CWI MFG DRAPER DRUM – SPEED UP KIT)**

Q: In very light conditions the drum will not push the product into the feeder house. Any suggestions?

A: Strange as it may sound, **removing the finger timing lever on the idle side and rotating it 180 degrees can help this**. The fingers will extend towards the feeder house and push the crop in, while the flighting still pulls the product from the draper belt.

Q: How do I keep my auger from stalling?

A: There is no longer a slip clutch in the Draper Drum. There is a slip clutch in the large gearbox on the LHS of the adapter that will slip if there is too much product built up around the drum. Meaning if the drum is stalling it is due to an issue with the gearbox.

Q: Does the auger turn the same speed as the factory one?

A: Yes, the auger does turn at the same speed. The tube has a smaller diameter, but the flighting is taller, resulting in the same overall diameter of the flighting. Since you re-use the factory drive chain and sprockets, **there is no change in speed compared to factory UNLESS, a speed up kit is added.**

Q: Is there a reversing mechanism in the Draper Drum?

A: No, there is no reversing mechanism in the drum. This is one of the components that would fail in the factory drum, so it has been removed to simplify the drum and make it more durable. **The drum can still be rotated backwards, however**, if the feeder house is plugged or there is a build up of materials behind the drum, it may need to be removed by hand after reversing the feeder house and adapter drum.

Q: Is there a slip clutch in the Draper Drum?

A: No, the slip clutch has been removed to simplify the drum and because it was known to be a failure point. The next slip clutch is in the gearbox on the LHS of the adapter.

Q: Why is my shaft breaking?

A: In the earlier version of the Draper Drum the shaft was made with a lighter steel shaft. In heavy crops some people experienced their shaft breaking. The Series 2 Draper Drum has been upgraded with a heavy-duty shaft. **Upgrade kits are available to be purchased for those who have previous versions and are outside of their warranty period. (CWI MFG DRAPER DRUM – SHAFT UPGRADE KIT)**

Q: Why are fingers extending at the back and retracting at the front of the drum?

A: Remove the timing lever completely. Your drum will then spin freely, set the drum and fingers to where you want them and then put the timing lever back on and tighten. This issue can happen when there's an error installing the drum and not setting the timing lever correctly.

Q: What causes issues with feeding and wrapping?

A: Green/tough crops are the #1 issue with feeding. Light crops can cause an issue due to lack of material, not enough substance to flow smoothly. Flighting design. The old versions of the Draper had poor flighting design. This can be resolved by cutting the flighting off with a grinder to round off the snag points. **Please see photo below.**



***** Things others have done to improve feeding:**

-Remove the feeder house shroud on the JD S Series combine to allow for a larger opening for the crop.

-Cut off the center flighting pieces in extreme cases to improve product flow and reduce wrapping. This is on the early versions of the Draper Drum prior to January 2024.

-Flip centre shaft assembly by 180 degrees in light crops to keep crop flowing into the feeder house.

-Speed up rotation in heavy crops with the Combine World speed up kit.

-With beans, one customer advanced the timing forward to the 3rd hole and found it worked well.

Trouble shooting. Try these in order:

1. Finger timing adjustment
2. Remove fingers
3. Check feeder house front plate for proper angle to attain smooth transition from the adapter.

Thank you again for purchasing your Draper Drum Kit from. Any questions, please call us.



1-800-667-4515