Last Editor: DAE Ver: 1 Date: 2020-04-23 **<u>Title:</u>** TWIPe IMU Position <u>Filename:</u> SB7D-IMU-position.odg **Related files:** Scale: not to scale **IMU** Orientation and Axes (As seen through a back door in TWIPe) Up, towards TWIPe's head Pushbutton switches at the top, on the back of the board, facing forward $\Lambda \Lambda$ IMU with pins on left +Z axis comes straight up from the board, towards your eyes. TWIPe's left side ◀ TWIPe's right side Down, towards TWIPe's wheels