
IP-44 Error codes 90, 91 (pg 1 of 3)

EC-90: COM 1 Port error

EC-91: COM 2 Port error




2 Troubleshooting IP-44: Error codes 90, 91 2 - 124 LCx® Analyzer Service Manual (Text P/N 47278-102)

Chapter Contents Manual Contents

CD Main Screen Index

## IP-44 (pg 2 of 3)



2	Troubleshooting	IP-44: Error codes 90, 91	2 - 125
	LCx® Analyzer Service Manual (Text P/N 47278-102)		

Chapter	Manual	CD Main	Index
Contents	Contents	Screen	

## IP-44 (pg 3 of 3)

2

Edit parameters:

- SYSTEM
- FILES

Enter parameter to edit.

Enter correct value.

- STORE
- FWD or EXIT

Power Off analyzer to reinitialize parameters into memory.

IP44-3.vsd

2 Troubleshooting IP-44: Error codes 90, 91 2 - 126 LCx<sup>®</sup> Analyzer Service Manual (Text P/N 47278-102)

Chapter	Manual	CD Main	Index
Contents	Contents	Screen	