
Motor Driver Board (pg 1 of 2) Board Layout





Motor Driver Board (pg 2 of 2) Connector Pin Callouts

From Motor Driver

· · · · · · · · · · · · · · · · · · ·						
From Motor Driver	Pins	То	Cross-reference Connector Pin Callout(s) (See pages)			
J1	60	I/O J3	A-17, A-21			
J2	4	Door Sensor				
J3	34	Analog J3	A-33			
J4	12	Carousel/Hm	A-44			
J5	32	Boom Assy	A-41, A-42, A-43			
J6	40	Pump Assy	A-47, A-48, A-49			
J10	3	120VAC P/S P27	A-11, A-12			

From Motor Driver (cont)

From Motor Driver	Pins	То	Cross-reference Connector Pin Callout(s) (See pages)
J11	4	Air Heater	A-50, A-52
J12	6	Liquid Heater	A-50, A-51, A-52
J13	4	Reagent Receiver/ Heater Block	A-50, A-52
J14	4	Optics Heater	
J15	2	Air Heater Fan	A-48
J16	5	Remote Air Thermistor	A-50, A-53
J17	6	VDC P/S P22	A-11, A-13

A Block Diagrams, Boards and Pinouts LCx® Analyzer Service Manual (Text P/N 47278-102)

Board Layout

Appendix	Manual	CD Main	Index
Contents	Contents	Screen	

Motor Driver Board A - 25