
IP-16 Error code 35 (pg 1 of 5)


EC-35: No disposables to run



2 Troubleshooting IP-16: Error code 35 2 - 68 LCx® Analyzer Service Manual (Text P/N 47278-102)

Chapter Manual CD Main Index Contents Contents Screen


IP-16 (pg 2 of 5)



2 Troubleshooting IP-16: Error code 35 2 - 69 LCx® Analyzer Service Manual (Text P/N 47278-102)

Chapter	Manual	CD Main	Index
Contents	Contents	Screen	


IP-16 (pg 3 of 5)



2 Troubleshooting IP-16: Error code 35 2 - 70 LCx® Analyzer Service Manual (Text P/N 47278-102)

Chapter Manual Contents Contents	CD Main Screen	Index
----------------------------------	-------------------	-------


IP-16 (pg 4 of 5)



2	Troubleshooting	IP-16: Error code 35	2 - 71
	LCx [®] Analyzer Service Manual (Text P/N 47278-102)		

Chapter	Manual	CD Main	Index
Contents	Contents	Screen	

IP-16 (pg 5 of 5)



IP16-5.vsd

2	Troubleshooting	IP-16: Error code 35	2 - 72
	LCx® Analyzer Service Manual (Text P/N 47278-102)		

Chapter Contents	Manual Contents	CD Main Screen	Index	
---------------------	--------------------	-------------------	-------	--