INDEX TABLE OF CONTENTS

Index overview

Abbreviations

I- 2

CD-ROM links Page numbers

I- 2

Index Alpha Locator:

Α	В	С	D	Е	F	G	Н	I	J	K	L	M
N	0	Р	Q	R	S	Т	U	V	W	X	Υ	Z

I Index LCx[®] Analyzer Service Manual (Text P/N 47278-102)

Manual Contents

CD Main Screen

INDEX OVERVIEW (pg 1 of 1)

Abbreviations

As needed to accommodate space requirements, these abbreviations have been used:

Adjust. for Adjustment Cal. for Calibration
Config. for Configuration P/N for Part Number
Param. for Parameter P/S for Power Supply

Disconn. for Disconnect(ed)
Decon. for Decontamination
Temp. for Temperature

CD-ROM links

Links (jumps) are included in the index of the CD-ROM version of this service manual. Select the letter of the alphabet from the alphabet links on page one of this index. After you've found the desired index entry, click on the page number given for that entry.

Page numbers

The page number given is the first on which that information appears. For example:

Monitor Menu, D-7 indicates that the information begins on page D-7 and may continue on subsequent pages.

Page numbers aid the user of the paper-based manual. In the CD-ROM edition, page numbers also serve as a confirmation that the appropriate linked information has been located.

I Index LCx[®] Analyzer Service Manual (Text P/N 47278-102)

Index Alpha Locator (Index page 1)

Manual CD Main Screen

uol CD Moin

```
1 SPOOL LOCKOUT, assay param., B-48
                                                  1.18 HOST INTERFACE, sys. param., 1-40, B-16
1.1 SYSTEM REVISION, system param., B-4, B-14
                                                  1.19 CRSL ID 1=ON, system param., B-16
1.2 REVISION DATE, system param., B-4, B-14
                                                  1.20 SPOOLER WARN, system param., 1-40, B-16
1.3 SERIAL NUMBER, system param., B-14
                                                  1.28 REPORT REDIR, system param., 1-39, B-16
1.4 DOOR SENSOR, system param., B-14
                                                  1.22 NUM RGTS, system param., B-16
1.5 DATE FORMAT, system param., B-14
                                                  1.26 DISPLAY DIM, system param., B-16
1.6 COM 1 BAUD, system param., 1-39, B-14
                                                  1.27 KEY CLICKS 1=ON, system param., B-17
                                                  1.28 REPORT REDIR, system param., B-17
1.7 COM 1 CHR LEN, system param., 1-39, B-14
                                                  1.29 XOFF TIMEOUT, system param., B-17
1.8 COM 1 STOP BIT, system param., 1-39, B-14
                                                  2.1 TOT DIL 2 VOL, system param., B-18
1.9 COM 1 PARITY, system param., 1-39, B-15
1.10 COM2 BAUD, system param., 1-40, B-15
                                                  2.2 DEAD VOL 2, system param., B-18
1.11 COM2 CHR LEN, system param., 1-40, B-15
                                                  2.3 CURRENT DIL 2, system param., B-18
1.12 COM2 STOP BIT, system param., 1-40, B-15
                                                  2.4 TOT DIL 1 VOL, system param., B-18
1.13 COM2 PARITY, system param., 1-40, B-15
                                                  2.5 DEAD VOL 1, system param., B-18
1.14 DIL 1 V1 POS, system param., B-15
                                                  2.6 CURRENT DIL 1, system param., B-18
1.15 DIL 2 V1 POS, system param., B-15
                                                  2.9 WASTE TOT VOL, system param., B-18
1.16 V1 DISP POS, system param., B-15
                                                  2.10 RT SYRG SLOPE, system param., B-18
1.17 LINE FEEDS, system param., B-16
                                                  2.11 LT SYRG SLOPE, system param., B-18
                                                                                             I - 3
   Index
   LCx® Analyzer Service Manual (Text P/N 47278-102)
 Index Alpha Locator
```

(Index page 1)

Manual Contents

CD Main Screen

2.12 PRIME VOL LT, system param., B-19	3.2 STEPS PER REV, system param., B-22
2.13 PRIME VOL RT, system param., B-19	3.3 SLOTS, system param., B-22
2.14 PRIME SPEED, system param., B-19	3.4 SAMPLE DIR, system param., B-22
2.15 PRIME CYCLES, system param., B-19	3.5 HOME SAMP NUM, system param., B-22
2.17 REAG BC START, system param., B-19	3.6 PIP1 SAMP NUM, system param., B-22
2.18 REAG BC END, system param., B-20	3.7 PIP2 SAMP NUM, system param., B-23
2.19 LS CHECK, system param., B-20	3.8 READ SAMP NUM, system param., B-23
2.20 SAFETY DEPTH, system param., B-20	3.9 DET. SAMP NUM, system param., B-23
2.21 LS CHECK LOW, system param., B-20	3.10 HOME OFFSET, system param., B-23
2.22 RINSE CHECK, system param., B-20	3.11 PIPET1 OFFSET, system param., B-23
2.23 PBCD PROBE VOL, system param., B-21	3.12 PIPET2 OFFSET, system param., B-23
2.24 PBCD PROBE REP, system param., B-21	3.13 READ OFFSET, system param., B-24
2.25 PBCD RINSE VOL, system param., B-21	3.14 DETECT OFFSET, system param., B-24
2.26 PBCD RINSE REP, system param., B-21	3.15 BAR CODE START, system param., B-24
2.27 DSP CK AVG LO, system param., B-21	3.16 BAR CODE END, system param., B-24
2.28 DSP CK AVG HI, system param., B-21	3.17 LOCK POS, system param., B-24
2.29 DSP CK RANGE, system param., B-21	3.18 UNLOCK POS, system param., B-25
3.1 CAR HFLG STEP, system param., B-22	3.19 CAROUSEL ID, system param., B-25
	•
I Index	I - 4
LCx® Analyzer Service Manual (Text P/N 47278-	102)
, , ,	,
Index Alpha Locator	Manual CD Main

Index Alpha Locator (Index page 1) Manual CD Main Screen

3.20 CRSL BC OFFSET, system param., B-25 14 REAG DEV, assay param., B-49 4. WASH STATION, system param., B-26 14. INC WELL CTR 2, system param., B-26 5. REAGENT 1, system param., B-26 15. MEIA PRE FRT, system param., B-26 6 EQUIV ZONE LO, assay param., B-48 16 DIL TEMP, assay param., B-49 6. REAGENT 2, system param., B-26 16. MEIA PRE CTR 1, system param., B-26 7 EQUIV ZONE HI, assay param., B-48 17 DIL DEV, assay param., B-49 7. REAGENT 3, system param., B-26 17. MEIA PRE CTR 2, system param., B-26 18. MEIA SMP WELL, system param., B-26 8 LS CHECK LO, assay param., B-48 19 REMOTE TEMP, assay param., B-49 8. REAGENT 4, system param., B-26 19. BOOM PARK, system param., B-26 9 LS CHECK HI, assay param., B-48 20 REMOTE DEV, assay param., B-50 9. REAGENT 5, system param., B-26 10 AIR TEMP, assay param., B-48 20. DISP WELL, system param., B-26 10. MATRIX, system param., B-26 21. VIAL, system param., B-26 11 AIR DEV, assay param., B-48 22. LCx RCT WELL, system param., B-26 11. PRE WASH, system param., B-26 23. WASH TARGET, system param., B-26 12. INC WELL FRT, system param., B-26 (4-29).1 ON OFF CAR, system param., B-29 13 REAG TEMP, assay param., B-49 (4-29).2 CAR OFFSET, system param., B-27, B-29 13. INC WELL CTR 1, system param., B-26 (4-29).3 R BOOM, system param., B-27, B-29 I - 5 Index LCx® Analyzer Service Manual (Text P/N 47278-102)

Index Alpha Locator (Index page 1) Manual CD Main Screen

(4-29).22 LS ADD, system param., B-32 (4-29).4 Z LS DEFAULT, system param., B-29 (4-29).5 LS BKGRND, system param., B-30 (4-29).23 LS GAIN, system param., B-32 (4-29).6 Z LS DELTA, system param., B-30 (4-29).24 LS DELTA, system param., B-33 (4-29).7 Z ABOVE, system param., B-30 (4-29).25 LS GUARD BAND, system param., B-33 (4-29).8 Z DISP 1, system param., B-30 (4-29).26 LS BKGRND MAX, system param., B-33 (4-29).9 Z DISP 2, system param., B-30 (4-29).27 LS ADJ, system param., B-33 (4-29).10 Z DISP 3, system param., B-30 30.15 IDLE REAG TP, system param., B-34 (4-29).11 Z DISP 4, system param., B-30 30.16 MEIA AIR SET, system param., B-34 (4-29).12 Z DISP 5, system param., B-30 30.17 MEIA WARMUP TP, system param., B-34 (4-29).13 Z DISP 6, system param., B-31 30.18 MEIA PID DEV, system param., B-34 (4-29).14 Z DISP 7, system param., B-31 30.19 MEIA ADJUST SP, system param., B-35 (4-29).15 Z DISP 8, system param., B-31 30.20 MEIA INC TIME, system param., B-35 (4-29).16 Z ASPLIM, system param., B-27, B-31 30.21 MEIA CAL TIME, system param., B-35 (4-29).17 Z BTMLIM, system param., B-31 30.22 MEIA DELTA SP, system param., B-35 (4-29).18 HVR, system param., B-31 30.23 PID INFO 1= OFF, system param., B-35 (4-29).19 5 BOTTL HVR ADJ, system param., B-31 30.24 RMT ALARM DEV, system param., B-36 (4-29).20 DIVE DEPTH, system param., B-32 30.25 PID CONTROL, system param., B-36 (4-29).21 5 BOTTL R ADJ, system param., B-32 30.26 PID GAIN, system param., B-36 I - 6 Index LCx[®] Analyzer Service Manual (Text P/N 47278-102)

Index Alpha Locator (Index page 1) Manual CD Main Contents Screen

30.27 PID INTEGRAL, system param., B-37	31.24 MEIA INC TIME, system param., B-41
30.28 PID DERIVATIVE, system param., B-37	31.25 MEIA LMP REF#, system param., B-41
30.29 PID BIAS, system param., B-37	31.26 MEIA LMP 1=ON, system param., B-41
30.30 IDLE AIR TEMP, system param., B-37	31.27 MEIA LOW I, system param., B-41
31 MIN RATE, assay param., B-50	31.28 MEIA CAL VOLT, system param., B-42
31.11 MEIA STD B, system param., B-38	31.29 MTRX DET VOLT, system param., B-42
31.12 MEIA STD M, system param., B-38	31.30 MTRX DET REF, system param., B-42
31.13 MEIA STD H, system param., B-38	31.31 CRSL CAL HOLE, system param., B-42
31.14 M % DIFF, system param., B-38	31.32 CRSL CAL CELL, system param., B-42
31.15 H % DIFF, system param., B-39	32 MAX NRMSE, assay param., B-50
31.16 H THRESHOLD, system param., B-39	33 MIN CORR, assay param., B-50
31.17 INIT SLOPE, system param., B-39	34 MAX INTRCPT, assay param., B-50
31.18 INIT INTRCPT, system param., B-39	35 MUP T DELAY, assay param., B-51
31.19 MEIA SLOPE, system param., B-40	37 LVL 1 HIGH, assay param., B-51
31.20 MEIA INTRCPT, system param., B-40	38 LVL 1 LOW, assay param., B-51
31.21 B HI LIM, system param., B-40	43 CT/CAL SETUP, assay param., B-52
31.22 STATIC PREC, system param., B-40	44 CAL RANGE, assay param., B-53
31.23 DYNAMIC PREC, system param., B-40	45 CAL HIGH, assay param., B-53
I Index	I - 7
LCx® Analyzer Service Manual (Text P/N 47278-	102)
,	

Index Alpha Locator (Index page 1) Manual CD Main Contents Screen

46 CAL LOW, assay param., B-53 47 CAL AVE HIGH, assay param., B-53 48 CAL AVE LOW, assay param., B-53 54 NUM POS CNTL, assay param., B-54 55 NUM NEG CNTL, assay param., B-54 60 PRINT OPTION, assay param., B-54 61 % CUT OFF, assay param., B-54 62 FSA, assay param., B-55 65 LVL 2 HIGH, assay param., B-55 66 LVL 2 LOW, assay param., B-55 69 POS RANGE, assay param., B-55 70 POS HIGH, assay param., B-56 71 POS LOW, assay param., B-56 72 POS AVE HIGH, assay param., B-56 73 POS AVE LOW, assay param., B-56 76 INACT PROT, assay param., B-56 77 RGT VOL CHK ORD, assay param., B-57 82 BATCH SIZE, assay param., B-57 Index

83 NUM CAL, assay param., B-57 84 NEG RANGE, assay param., B-57 85 NEG HIGH, assay param., B-58 86 NEG LOW, assay param., B-58 87 NEG AVE HIGH, assay param., B-58 88 NEG AVE LOW, assay param., B-58 90 LVL 3 HIGH, assay param., B-58 91 LVL 3 LOW, assay param., B-58 101 NUM RGNTS, assay param., B-59 105 DATA REDUC, assay param., B-59 106 RGNT DELAY, assay param., B-59 107 POST PRCR, assay param., B-59 108 MODE, assay param., B-59 109 GAIN, assay param., B-59

LCx[®] Analyzer Service Manual (Text P/N 47278-102)

Index Alpha Locator (Index page 1)

Manual

CD Main Contents Screen

A to D hardware fail (EC-54) (IP-27), 2-104 activating assay params., B-45 activating the ASTM® interface, C-4 Adapter, Assy, Temp. Probe, P/N, 3-4 adjustments Bar Code Adjust. (VP-5), 5-19 Card Cage Adjust. (VP-3), 5-14 Carousel Bar Code Offset Adjust. (VP-56), 5-99 Carousel Lock Sensor Adjust. (VP-34), 5-78 Carousel Motor and Gear Adjust. (VP-19), 5-51 Enclosure Adjust. (VP-2), 5-12 Level Sense Adjust. (VP-12), 5-39 MEIA Lamp Adjust. (VP-22), 5-57 Reagent Heater Block Adjust. (VP-21), 5-54 Air Deflector, P/N, 3-4, 3-6	Air Duct Cover P/N, 3-8 RR-2.8, 4-14 Air fan not running (IP-86), 2-228 Air Heater Assy P/N, 3-11 RR-3.16, 4-38 Air Heater Insulator, P/N, 3-11 Air Heater/Thermistor Cable, P/N, 3-11 Air Purge (VP-57), 5-101 Air temp. high (EC-63) (81), 2-217 Air temp. low (EC-62) (81), 2-217 Air Thermistor Assy, RR-3.13, 4-36 Air Thermistor (Remote) Assy P/N, 3-14 RR-4.14, 4-57 Alignment, AVR (VP-64), 5-113
--	--

I Index LCx[®] Analyzer Service Manual (Text P/N 47278-102)

Index Alpha Locator (Index page 1) Manual CD Main Contents Screen

Amplification Vial	Analog to CPU Cable, P/N, 3-24
disposal, 1-26	Analog Bd to MEIA Lamp Supply Cable, P/N, 3-14
location in reaction cell, 5-34	Analog to MEIA Lamp P/S, Cable, P/N, 3-24
LLS position and delta voltage, 5-32	Analog Bd to Motor Driver Bd., Cable, P/N, 3-24
P/N, 3-4	Analog Board cable disconn. (EC-2) (IP-5), 2-45
•	Analog/HV P/S cable assy, P/N, 3-25
Amplification Vial Retainer	• • • • • • • • • • • • • • • • • • • •
P/N, 3-8	Analog/Motor Driver/Display, P/Ns (PL-8), 3-24
RR-2.11, 4-16	analyzer decon. procedure (VP-60), 5-107
amplified product	Analyzer operates too slowly (IP-3), 2-38
decontamination, 1-23	analyzer specifications, 1-32
inactivating, 1-18	Assay done - remove reagents (EC-207), 2-26
Analog Board	assay file XX, bad value in (IP-46), 2-129
block diagram, A-9	ASSAY menu, D-5
board layout, A-27	assay module
connector pin callouts, A-28	bad checksum (EC-133) (IP-53), 2-146
P/N, 3-24	incompatible with system module (EC-134), 2-25
RR-8.3, 4-92	Assay Module missing (EC-5) (IP-6), 2-47
signal pathway, A-26	rioday inicoming (20 c) (ii c), 2 ii
signal patriway, 71 20	
I Index	I - 10
LCx [®] Analyzer Service Manual (Text P/N 472	
,	,
Index Alpha Locator	Manual CD Main

Index Alpha Locator (Index page 1)

ocator e 1) Manual CD Main Contents Screen

assay parameters ASTM® interface (cont) error codes, C-15 overview, B-43 parameter access, B-45 load list feature, C-8 assay activation, B-45 log, clearing (VP-63), 5-112 list, B-46 pin assignments (COM2 port), C-6 sample printout, B-43 spooler buffer, C-12 assay params. quick ref. chart, B-47 spooler capacity warning, C-12 Assay results incorrect/Controls out of range (IP-4), system params., C-7 2-40 troubleshooting, C-13 Assay revisions mismatch (EC-104) (IP-47), 2-130 ASTM® Log, clearing (VP-63), 5-112 ASIC CPU Bd, P/N, 3-22 ASTM®-specific error codes, C-15 Assy, Carousel Pack, P/N, 3-4 audience for this manual. 1-8 Assy, System Cartridge Pack, P/N, 3-4 average out of range (EC-199), 2-25 ASTM® interface AVR Alignment (VP-64), 5-113 AVR Postioning Tool, P/N, 3-4 activating, C-4 AVR Sensor Check (VP-65), 5-115 cable/connector. C-5 connecting to the Host computer, C-5

I Index LCx[®] Analyzer Service Manual (Text P/N 47278-102)


Index Alpha Locator (Index page 1)

Manual CD Main Screen

blank cells В LLS position and delta voltage, 5-32 B is out of range (EC-144) (IP-69), 2-176 P/N, 3-4 Bad checksum on Assay Module (EC-133) (IP-53), block diagrams/voltage and/or signal pathways 2-146 Analog Board, A-9, A-26 Bad checksum on System Module (EC-132) (IP-53), Bar Code Interface, A-39 2-146 boom assembly, A-40 Bad High Voltage Power Supply (EC-74) (IP-34), Digital I/O board, A-16 2-115 dispense station, A-45 Bad value in assay XX (EC-103) (IP-46), 2-129 ground cable, A-57 Bad values in Boom Cal file XX (EC-10) (IP-8), 2-50 heater assy, A-50 Bar Code Adjust. (VP-5), 5-19 Liquid Level Sense Board, A-9, A-36 Bar Code Check (VP-4), 5-16 MEIA optics, A-55 Bar Code device test failed (EC-131) (IP-54), 2-148 Motor Driver Board, A-8 Bar code error (EC-42) (IP-20), 2-83 Power Supply, Card Cage Assy, A-7 Bar Code Interface block diagram, A-39 pump assembly, A-47 Baseplate, P/N, 3-12 system block diagram, A-6 Bearing Center Pin, P/N, 3-14 system power supply, A-10 biohazardous material, decon., 1-23, 5-107 I - 12 Index

LCx[®] Analyzer Service Manual (Text P/N 47278-102)

Index Alpha Locator (Index page 1) Manual CD Main Screen



cable (cont) Display to I/O Bd., P/N, 3-25 cable Ground, Assy, P/N, 3-27 Air Heater/Thermistor, P/N, 3-11 see also Ground Cable Analog to CPU, P/N, 3-24 host interface connection, C-5 Analog to MEIA Lamp P/S, P/N, 3-24 HV Connector Cable Assy, P/N, 3-14 Analog Bd to MEIA Lamp Supply, P/N, 3-14 Keypad to I/O Bd., P/N, 3-24 Analog Bd to Motor Driver Bd., P/N, 3-24 LLS/Analog, P/N, 3-25 Analog/HV P/S, P/N, 3-25 LLS P/S/ Mtr. Dr./Analog, P/N, 3-19 Buffer Sensors, P/N, 3-17 Main P/S to Card Cage, P/N, 3-19 see also Buffer Sensor Main P/S to Printer, P/N, 3-19 Card Cage Fan, P/N, 3-22 Main P/S 110 VAC to Mtr. Dr. Bd., P/N, 3-19 Carousel Lock Sensor, P/N, 3-14 MEIA Optics to Analog Bd, P/N, 3-14 see also Carousel Lock Sensor Cable Assy Sensor Bracket, P/N, 3-25 COM 1 external printer, 1-39 Cable/Bracket Assy, RS-232, P/N, 3-22 COM 2 host computer, 1-40 calibrations CPU to Printer, P/N, 3-19 Boom Cal. (VP-8), 5-25 Digital I/O to Analog Bd., P/N, 3-24 MEIA Carousel Cal. (VP-30), 5-73 Digital I/O to Motor Driver Bd., P/N, 3-24 MEIA Initialization Photo Cal. (VP-27), 5-63 I - 14 Index LCx[®] Analyzer Service Manual (Text P/N 47278-102) Index Alpha Locator CD Main

dex Alpha Locator (Index page 1) Manual CD Contents Sc

CD Mair Screen

```
calibrations (cont)
                                                       carousel
   MEIA Photo Cal. (VP-27A), 5-66
                                                           decontamination procedure, 5-107
   MEIA Temp. Cal. (VP-29), 5-70
                                                           label read error (EC-40) (IP-20), 2-83
                                                          load error (EC-36) (IP-17), 2-73
CALIBRATIONS menu, D-7
calibrators, handling/disposal, 1-27
                                                           missing steps (EC-23) (IP-79), 2-211
Cap, Drilled, P/N, 3-4
                                                           not locked (EC-20) (IP-10), 2-56
Card Cage
                                                       carousel bar code
   adjustment, (VP-3), 5-14
                                                           ID= (bar code error) (EC-44) (IP-20), 2-83
   P/Ns (PL-7), 3-22
                                                           label read error (EC-40) (IP-20), 2-83
Card Cage Adjust. (VP-3), 5-14
                                                       Carousel Bar Code Offset Adjust. (VP-56), 5-99
                                                       Carousel failed home (EC-13) (IP-79), 2-211
Card Cage Assy, RR-7.7, 4-81
Card Cage Cover, P/N, 3-22
                                                       Carousel Home Sensor Assy, P/N, 3-11
                                                       Carousel Home Sensor Check (VP-18), 5-50
Card Cage Fan, P/N, 3-22
                                                       Carousel ID Bar Code, P/N, 3-4
Card Cage Fan Baffle, P/N, 3-22
Card Cage Fan Cable, P/N, 3-22
                                                       Carousel ID error: Carousel ID (EC-44) (IP-20),
Card Cage Spacers, P/N, 3-22
                                                           2-83
Card Cage, Tilt Back, Procedure (RR-8.0), 4-87
                                                       Carousel label read error (EC-40) (IP-20), 2-83
                                                                                                     I - 15
   Index
   LCx<sup>®</sup> Analyzer Service Manual (Text P/N 47278-102)
```

Index Alpha Locator

Manual CD Main Contents Screen

(Index page 1)

Carousel load error (EC-36) (IP-17), 2-73 Carousel Receiver Assy Carousel Lock Arm not locked (EC-93) (IP-87), P/N, 3-12 RR-3.18, 4-41 2-229 Carousel Lock Sensor Adjust. (VP-34), 5-78 cautions and warnings Carousel Lock Sensor Cable Assy amplified product, 1-18 P/N, 3-14 decontamination, 1-23 RR-4.6, 4-52 disposal, 1-26 Carousel Master Packing, P/N, 3-4 handling calibrators, controls, reagents, 1-27 Carousel missing steps (EC-23) (IP-79), 2-211 maintenance and service, 1-29 Carousel Motor Adjust. Fixture, P/N, 3-4 personal protective equipment, 1-22 Carousel Motor and Gear Adjust. (VP-19), 5-51 universal precautions, 1-21 Carousel Motor Assy, RR-3.3, 4-25 chapter descriptions, 1-9 Carousel Motor/Home Sensor, connector pin Check MEIA Lamp XXXXX (EC-108) (IP-48), 2-131 callouts. A-44 checks Carousel Motor/Sensor/Bracket, P/N, 3-11 AVR Sensor Check (VP-65), 5-115 Carousel not locked (EC-20) (IP-10), 2-56 Bar Code Check (VP-4), 5-16 Carousel Pack Assy, P/N, 3-4 Boom Check (VP-7), 5-23 Buffer Sensor Check (VP-15), 5-45 I - 16 Index LCx® Analyzer Service Manual (Text P/N 47278-102) Index Alpha Locator Manual CD Main

(Index page 1)

Contents Screen

```
checks (cont)
                                                    checksum error
   Carousel Home Sensor Check (VP-18), 5-50
                                                        assay module (EC-133) (IP-53), 2-146
                                                        directory (EC-100) (IP-45), 2-127
   Dispense Check (VP-13), 5-42
   Door Sensor Check (VP-20), 5-53
                                                        file (EC-101) (IP-45), 2-127
   Fluorescence Background Check (VP-59),
                                                        system module (EC-132) (IP-53), 2-146
                                                    Chlamydia LCR assay, B-44
      5-105
   HV Linearity Check (VP-58), 5-103
                                                    Circuit Bd. Spacer, P/N, 3-25
   Level Sense Check (VP-11), 5-37
                                                    cleaning up spills, 1-24
   LLS Voltage Delta Check (VP-9), 5-29
                                                        see also Decontamination (VP-60)
   Matrix Count Check (VP-31), 5-75
                                                    Clearing System, ASTM, and CSC Log (VP-63),
   MEIA Photo Check (VP-26), 5-60
                                                        5-112
   MEIA Photodiode Check (VP-25), 5-59
                                                    COM 1 BAUD, system param. 1.6, 1-39
   MEIA PMT Check (VP-24), 5-58
                                                    COM 1 CHR LEN, system param. 1.7, 1-39
   MEIA Temp. Check (VP-28), 5-68
                                                    COM 1 PARITY, system param. 1.9, 1-39
   Power Supply Check (VP-1), 5-11
                                                    COM 1 Port error (EC-90) (IP-44), 2-124
   Syringe Sensor Check (VP-16), 5-47
                                                    COM 1 port specifications, 1-39
   Valve Sensor Check (VP-17), 5-49
                                                    COM 1 STOP BIT, system param. 1.8, 1-39
CHECKS menu, D-8
                                                    COM 2 BAUD, system param. 1.10, 1-40
   Index
```

LCx[®] Analyzer Service Manual (Text P/N 47278-102)

CD Main

I - 17

Index Alpha Locator (Index page 1)

Manual Contents Screen

COM 2 CHR LEN, system param. 1.11, 1-40 Cover, Protective Wire COM 2 PARITY, system param. 1.13, 1-40 P/N, 3-8 COM 2 port, ASTM interface, pin assignments, C-6 RR-2.7, 4-13 COM 2 Port error (EC-91) (IP-44), 2-124 Cover, Interior, P/N, 3-29 COM 2 port specifications, 1-40 covers, internal, P/Ns (PL-2), 3-8 COM 2 STOP BIT, system param. 1.12, 1-40 Cover, Pump, P/N, 3-17 configuration params. (File 1), B-14 covers, VDE, P/Ns (PL-10), 3-29 connector pin callouts CPU/Digital I/O Boards COM 1 external printer, 1-39 P/N, 3-22 COM 2 host computer, 1-40 RR-7.1/7.10, 4-75 see also specific board in Appendix A CPU to Printer, Cable, P/N, 3-19 Continuous Waste Tubing Assy, P/N, 3-8 CSC Log, clearning (VP-63), 5-112 Current liquid temp out of spec (EC-157) (IP-73), controls, handling and disposal, 1-26, 1-27 conventions used in this manual, 1-11 2-189 Cor. Coef. low (EC-164) (IP-65), 2-160 Cuvette Sensor (Carousel Lock Sensor Cable), cover, Air Duct P/N, 3-14 P/N, 3-8 RR-2.8, 4-14 I - 18 Index LCx[®] Analyzer Service Manual (Text P/N 47278-102)

Index Alpha Locator (Index page 1) Manual CD Main Screen

D	
date/time reset (EC-8) (IP-7), 2-49	defective parts, decontamination procedure, 5-109
DCE and DTE configuration pinouts, 1-41 decontamination amplified product, 1-18, 1-23 analyzer (VP-60), 1-23, 5-107 biohazardous material, 1-23 carousel, 5-107 defective parts, 1-25, 5-109 probe, 5-108 procedure (VP-60), 5-107 reaction chamber, 5-107 replaced parts, 1-25, 5-109 spills, 1-24 subassemblies, 1-25, 5-109 tools, 5-109 waste container, 1-24 when to perform, 1-23	Deflector, Air, P/N, 3-4 DI/AS X Y ZZZZ (EC-167) (IP-67), 2-169 Digital I/O Board board layout, A-17 connector pin callouts, A-18 RR-7.10, 4-75 signal pathway, A-16 Digital Board timed out (EC-137) (IP-55), 2-149 Digital I/O/CPU Boards P/N, 3-22 RR-7.1/7.10, 4-75 Digital I/O to Analog Bd., Cable, P/N, 3-24 Digital I/O to Motor Driver Bd., Cable, P/N, 3-24 Digital Thermometer, P/N, 3-4 Diluent Bottle not found (EC-49) (IP-23), 2-100 Diluent insufficient/empty XXXX (EC-48) (IP-23),
I Index	2-100 I - 19
LCx® Analyzer Service Manual (Text P/N 47278-102)	<u></u>

Index Alpha Locator (Index page 1)

Manual **CD** Main Contents Screen

diluent syringe	Display blank or incorrect (IP-1), 2-33	
P/N, 3-17	Display, Raise, Procedure (RR-8.1.1), 4-91	
RR-5.10/12, 4-67	Display Test (VP-43), 5-83	
Diluent Syringe failed home (EC-15) (IP-9), 2-51	Display to I/O Bd., Cable, P/N, 3-25	
Diluent Syringe missing steps (EC-25) (IP-9), 2-51	disposal	
Diluent temp. high °C (EC-61) (IP-33), 2-111	amplification vials, 1-26	
Diluent temp. low °C (EC-60) (IP-33), 2-111	calibrators, 1-26	
Directory checksum error (EC-100) (IP-45), 2-127	controls, 1-26	
dispense characteristics/specifications, 1-32	disposables, 1-26	
Dispense Check (VP-13), 5-42	inactivation diluent, 1-26	
Dispense System, A-45	inactivation reagent, 1-26	
Display	liquid waste containing acid, 1-26	
P/Ns (PL-8), 3-24	specimens, 1-26	
Raise procedure (RR-8.1.1), 4-91	Door	
RR-8.1, 4-89	Buffer Bottle, P/N, 3-5	
test, see Display Test	front, P/N, 3-5	
Display Assy (Touchpad)	Personality Module, P/N, 3-5	
P/N, 3-24	printer, P/N, 3-5	
RR-8.1, 4-89		
I Index		I - 20
LCx [®] Analyzer Service Manual (Text P/N 47278-1	02)	
Index Alpha Locator	Manual CD M	lain
(Index page 1)	Contents Scro	on

ain (Index page 1) Contents Screen

Door open (EC-43) (IP-21), 2-88 Door Sensor Assy, P/N, 3-17 Door Sensor Check (VP-20), 5-53 Door Sensor option active (EC-98) (IP-21), 2-88 Door Sensor Reflective Tape, P/N, 3-5 DTE and DCE configuration pinouts, 1-41 Dynamic Precision out of spec (EC-148) (IP-72), 2-186 EC-1: Motor Driver cable disconn. (IP-5), 2-45

EC-2: Analog Board cable disconn. (IP-5), 2-45 EC-4: Bad timer device (SM-4), 2-23 EC-5: Assay Module missing (IP-6), 2-47

EC-6: Invalid CMD in Mode sequence (SM-6), 2-23 EC-7: Invalid parameters in command (SM-7), 2-23

EC-8: Time/date reset (IP-7), 2-49

EC-10: Bad values in Boom Cal file XX (IP-8), 2-50 EC-11: Z boom failed Home (IP-78), 2-205 EC-12: R boom failed Home (IP-78), 2-205

EC-13: Carousel failed Home (IP-79), 2-211 EC-14: Multivalve failed Home (IP-80), 2-213

EC-15: Diluent Syringe failed Home (IP-9), 2-51 EC-16: Sample Syringe failed Home (IP-9), 2-51 EC-19: Photo Cal not initialized (SM-19), 2-23

EC-20: Carousel not locked (IP-10), 2-56 EC-21: Z boom missing steps (IP-78), 2-205

EC-22: R boom missing steps (IP-78), 2-205 EC-23: Carousel missing steps (IP-79), 2-211 EC-24: Multivalve missing steps (IP-80), 2-213 EC-25: Diluent Syringe missing steps (IP-9), 2-51

EC-26: Sample Syringe missing steps (IP-9), 2-51 EC-29: Reagent Pack not on module (IP-11), 2-61 EC-30: Reagent bar code mismatch (IP-10), 2-56 EC-31: Invalid assay on module (IP-12), 2-63

Index LCx® Analyzer Service Manual (Text P/N 47278-102)

Index Alpha Locator (Index page 1)


I - 21

Manual CD Main Contents Screen

EC-32: NOVRAM full (IP-13), 2-65 EC-34: Insufficient tests left XX (IP-15), 2-66 EC-35: No disposables to run (IP-16), 2-68 EC-36: Carousel load error (IP-17), 2-73 EC-37: Printer error (IP-18), 2-80 EC-38: Carousel mismatch (SM-38), 2-23 EC-39: Invalid mode definition (SM-39), 2-23 EC-40: Carousel label read error (IP-20: 2-83 EC-41: Reagent label read error (IP-20), 2-83 EC-42: Bar code error: Reagent ID= (IP-20), 2-83 EC-43: Door open (IP-21), 2-88 EC-44: Carousel ID Error: Carousel ID= (IP-20), 2-83	EC-49: Diluent bottle not found X (IP-23), 2-100 EC-52: Level sense not found XXXX (IP-22), 2-90 EC-53: F to D hardware fail (IP-26), 2-103 EC-54: A to D hardware fail (IP-27), 2-104 EC-56: MEIA Lamp out (IP-29), 2-105 EC-60: Diluent temp. low°C (IP-33), 2-111 EC-61: Diluent temp. high°C (IP-33), 2-111 EC-62: Air temp. low°C (IP-81), 2-217 EC-63: Air temp. high°C (IP-81), 2-217 EC-70: Remote temp. low°C (IP-83), 2-222 EC-71: Remote temp. high°C (IP-83), 2-222 EC-72: Reagent block temp. low°C (IP-85), 2-224			
EC-45: Wash Station overflow (IP-22), 2-90 EC-46: Liquid level too high (IP-22), 2-90	EC-73: Reagent block temp. high°C (IP-85), 2-224			
EC-47: Reagent insufficient/empty XXXX (IP-22), 2-90 EC-48: Diluent insufficient/empty X (IP-23), 2-100	EC-74: Bad high voltage power supply (IP-34), 2-115 EC-78: No sample/reagent found XXXX (IP-22),			
T. Jaday	2-90			
I Index LCx [®] Analyzer Service Manual (Text P/N 47278-10	I - 22 2)			
Index Alpha Locator (Index page 1)	Manual CD Main Contents Screen			

EC-79: File reloaded X Y (IP-45), 2-127	EC-104: Assay revisions mismatch (IP-47), 2-130
EC-81: V to F to D overflow error (SM-81), 2-23 EC-83: Sample inactivation failed XXX (SM-83),	EC-105: File parameter out of range (SM-105), 2-24
2-23	EC-108: Check MEIA Lamp XXXXX (IP-48), 2-131
EC-84: MEIA stds placed incorrectly (IP-43), 2-119	EC-109: MEIA lamp ref not initialized (IP-49), 2-139
EC-90: COM 1 port error (IP-44), 2-124	EC-110: Time expired for entering temp (IP-50),
EC-91: COM 2 port error (IP-44), 2-124	2-141
EC-92: Incompatible assay module (SM-92), 2-23	EC-111: CPU test failed (SM-111), 2-24
EC-93: Carousel lock arm not locked (IP-87), 2-229	EC-112: Reset test failed (SM-112), 2-24
EC-94: Invalid system module (SM-94), 2-24	EC-113: CPU board configuration error (SM-113),
EC-97: Level sense range error XXXX (IP-22), 2-90	2-24
EC-98: Door sensor option active (IP-21), 2-88	EC-115: Diagnostic checksum error (SM-115), 2-24
EC-99: Level sense hardware error (IP-22), 2-90 EC-100: Directory checksum error (IP-45), 2-127	EC-116: NMI Test failed (IP-51), 2-144 EC-117: U25/CPU test failed (SM-117), 2-24
EC-101: File checksum error (IP-45), 2-127	EC-118: MEM error XXX:XXXX or UX (IP-51),
EC-102: Initialize database (IP-45), 2-127	2-144
EC-103: Bad value in assay file XX (IP-46), 2-129	EC-119: Timer controller test failed (SM-119), 2-24
I Index	I - 23
LCx® Analyzer Service Manual (Text P/N 47278-10	_
Laday Alaba Lacatan	Manual CD Main


Index Alpha Locator (Index page 1) Manual CD Main Screen



EC-152: Group 3 failed (IP-75), 2-194	EC-194: Positive too high	n (SM-194), 2-2	25
EC-153: Group 4 failed (IP-75), 2-194	EC-195: Positive too low	(SM-195), 2-2	5
EC-154: Liquid heater block out of spec (IP-33),	EC-196: Calibrator range	failed (SM-196	8), 2-25
2-111	EC-197: Calibrator too hi	gh (SM-197), 2	2-25
EC-155: Remote temp out of range (IP-83), 2-222	EC-198: Calibrator too lo	w (SM-198), 2	-25
EC-156: Reagent heater block out of spec (IP-85),	EC-199: Average out of I	range (SM-199)	, 2-25
2-224	EC-200: Factory Set (A/S	Sys/Assay) (SM	-200), 2-26
EC-157: Current liquid temp out of spec (IP-73),	EC-201: MEIA temp. cali	bration (SM-20	1), 2-26
2-189	EC-202: Boom calibration	n (SM-202), 2-	26
EC-162: Intercept high (IP-64), 2-155	EC-203: MEIA carousel of	calibration (pass	s/fail)
EC-163: NRMSE too large (IP-65), 2-160	(SM-203), 2-26		
EC-164: Cor. coef. low (IP-65), 2-160	EC-204: MEIA photo cali	bration (pass/fa	ail)
EC-166: Read error (IP-66), 2-164	(SM-204), 2-26		
EC-167: DI/AS X Y ZZZZ (IP-67), 2-169	EC-205: Level Sense cal	ibration (pass/f	ail)
EC-190: Negative range failed (SM-190), 2-25	(SM-205), 2-26		
EC-191: Negative too high (SM-191), 2-25	EC-206: CLI invocation (SM-206), 2-26	
EC-192: Negative too low (SM-192), 2-25	EC-207: Assay done - re	move Reagents	s (SM-207),
EC-193: Positive range failed (SM-193), 2-25	2-26		
I Index			I - 25
LCx® Analyzer Service Manual (Text P/N 47278-10	2)		
	ſ		05.14.
Index Alpha Locator		Manual	CD Main

(Index page 1) Contents Screen

EC-208: MEIA temp. check (pass/fail) (SM-208), 2-26	EC-220: PMT high voltage 2-28	ge out of range	(IP-76),	
EC-209: MEIA photo check (pass/fail) (SM-209),	EC-221: Z boom out of r	• ,		
2-26	EC-222: R boom out of r	range (SM-222),	2-28	
EC-210: Dispense system check (pass/fail)	EC-223: Carousel out of	range (SM-223), 2-28	
(SM-210), 2-26	EC-224: Multivalve out of	of range (SM-224	4), 2-28	
EC-211: Boom check (SM-211), 2-26	EC-225: Diluent Syringe	out of range (S	M-225),	
EC-212: Carousel not calibrated (SM-212), 2-27	2-28			
EC-213: Error while parsing ASTM® message	EC-226: Sample Syringe	e out of range (S	SM-226),	
(SM-213), 2-27	2-28	•	•	
EC-214: Error processing ASTM® order (SM-214),	EC-229: Open thermistor XXXX (IP-77), 2-199			
2-27	EC-230: Shorted thermis	stor XXXX (IP-7	7), 2-199	
EC-215: Spooler Run Capacity (message logged)	EC-231: Z boom timed of	out (SM-231), 2-	-29	
Spooler capacity remaining: N Run(s) (displayed)	EC-232: R boom timed of	out (SM-232), 2	-29	
(SM-215), 2-27	EC-233: Carousel timed	out (SM-233), 2	2-29	
EC-216: ASTM® COMM timeout (SM-216), 2-28	EC-234: Multivalve timed	d out (SM-234),	2-29	
EC-217: Reset fail (SM-217), 2-28	EC-235: Diluent Syringe	timed out (SM-2	235), 2-29	
EC-218: Special operation (SM-218), 2-28	EC-236: Sample Syringe	e timed out (SM-	236), 2-29	
I Index			I - 26	
LCx [®] Analyzer Service Manual (Text P/N 47278-102	2)			
Index Alpha Locator		Manual	CD Main	
(Index page 1)		Contents	Screen	
(Illuex page 1)		Contents	Scieen	



example printouts (cont) Fan Filter, P/N, 3-11 MEIA Photo Cal, 5-67 Fan Filter Spacer, P/N, 3-12 Feedback Control, Lamp P/S, P/N, 3-14 MEIA Photo Check, 5-62 MEIA Temp Cal, 5-72 File checksum error (EC-101) (IP-45), 2-127 MEIA Temp Check, 5-69 File reloaded X Y (EC-79) (IP-45), 2-127 Printer Test, 5-81 Filter, Fan, P/N, 3-11 Fitting, Quick Disconnect, P/N, 3-8 Fitting, Waste Disposal, P/N, 3-6, 3-8 Fixture, Carousel Motor Adjust., P/N, 3-4 Flag, Z-Boom Home, P/N, 3-11 F to D hardware fail (EC-53) (IP-26), 2-103 Fluorescence Background Check (VP-59), 5-105 Factory Set (VP-62), 5-110 Foam, Display, P/N, 3-24 Fan & Gasket Assy Front Door, P/N, 3-5 P/N, 3-11 Front Panel, P/N, 3-5 RR-3.1, 4-19 Front View (PL-3), 3-11 Fan Baffle for Card Cage Fan, P/N, 3-22

Index LCx[®] Analyzer Service Manual (Text P/N 47278-102)

Index Alpha Locator (Index page 1)

Fan Baffle for Power Supply Fan, P/N, 3-19

Manual CD Main Contents Screen

GC LCR assay, B-44 Guide, Snap Slide, P/N, 3-5 Grease, Synthetic, P/N, 3-4 **Ground Cable** diagram, A-57 P/Ns (PL-9), 3-27 grounding specifications, 1-34 Group 1 failed (EC-150) (IP-75), 2-194 Group 2 failed (EC-151) (IP-75), 2-194 Group 3 failed (EC-152) (IP-75), 2-194 Group 4 failed (EC-153) (IP-75), 2-194

```
H % Diff out of spec (EC-146) (IP-70), 2-179
H below threshold value (EC-140) (IP-61), 2-152
H is not linear (EC-141) (IP-61), 2-152
HAND CONTROLS menu, D-9
handling reagents, calibrators, and controls, 1-27
hardware fail
   A to D (IP-27), 2-104
   F to D (IP-26), 2-103
Heater (Air) Assy, RR-3.16, 4-38
Heater Assembly
   connector pin callouts, A-52
   signal pathway, A-50
Heater Baffle, P/N, 3-11
Heater block out of spec (EC-156) (IP-85), 2-224
Heater Block/Reagent Receiver, RR-3.2, 4-22
```

Index LCx[®] Analyzer Service Manual (Text P/N 47278-102)

Index Alpha Locator (Index page 1) Manual CD Main Screen

Heater (Liquid) and Bracket Assy, RR-3.4, 4-28 hinges front door, P/Ns, 3-5 Personality Module door, P/N, 3-6 printer door, P/N, 3-6 host computer/ASTM® interface, 1-40, Appendix C host interface cable/connector, C-5 designated port, C-5 host order load list, C-9 lock/unlock, C-11 see also ASTM® interface HOST INTERFACE, system param. 1.18, 1-40 HV Connector Cable Assy, P/N, 3-14 HV Linearity Check (VP-58), 5-103

inactivation of amplified product, 1-18 procedure, manual (VP-14), 5-44 Initialize database (EC-102) (IP-45), 2-127 Insulator, Air Heater, P/N, 3-11 Insufficient tests left XX (EC-34) (IP-15), 2-66 Intercept high (EC-162) (IP-64), 2-155 Interconnect Tubing, P/N, 3-17 Interconnect Tubing w/ Sample Syringe, P/N, 3-17 interface, ASTM® see ASTM® interface see host interface Interior Cover, P/N, 3-29 interpreting status messages, 2-23 Invalid Assay Module (EC-129) (IP-53), 2-146

I Index LCx[®] Analyzer Service Manual (Text P/N 47278-102)

Index Alpha Locator (Index page 1)

Manual CD Main Contents Screen

Invalid assay on module (EC-31) (IP-12), 2-63	IP-16: EC-35, 2-68
Invalid System Module (EC-127) (IP-53), 2-146	IP-17: EC-36, 2-73
IP-1: Display blank or incorrect, 2-33	IP-18: EC-37, 2-80
IP-2: No alarm, 2-37	IP-20: ECs 40, 41, 42, 44, 2-83
IP-3: Analyzer operates too slowly, 2-38	IP-21: ECs 43, 98, 2-88
IP-4: Assay results incorrect/Controls out of range,	IP-22: ECs 45, 46, 47, 52, 78, 97, 99, 2-90
2-40	IP-23: ECs 48, 49, 2-100
IP-5: ECs 1, 2, 2-45	IP-26: EC-53, 2-103
IP-6: EC-5, 2-47	IP-27: EC-54, 2-104
IP-7: EC-8, 2-49	IP-29: EC-56, 2-105
IP-8: EC-10, 2-50	IP-33: ECs 60, 61, 154, 2-111
IP-9: ECs 15, 16, 25, 26, 2-51	IP-34: EC-74, 2-115
IP-10: EC-20, 2-56	IP-43: EC-84, 2-119
IP-11: EC-29, 2-61	IP-44: ECs 90, 91, 2-124
IP-12: EC-31, 2-63	IP-45: ECs 79, 100, 101, 102, 2-127
IP-13: EC-32, 2-65	IP-46: EC-103, 2-129
IP-15: EC-34, 2-66	IP-47: EC-104, 2-130
I Index	I - 31
LCx® Analyzer Service Manual (Text P/N 47278-1	02)
Index Alpha Leaster I	Manual CD Main

Index Alpha Locator

(Index page 1)

CD Main Manual Contents Screen

IP-48: EC-108, 2-131	IP-73: EC-157, 2-189
IP-49: EC-109, 2-139	IP-74: EC-149, 2-192
IP-50: EC-110, 2-141	IP-75: ECs 150, 151, 152, 153, 2-194
IP-51: ECs 116, 118, 2-144	IP-76: EC-220, 2-197
IP-52: EC-125, 2-145	IP-77: ECs 229, 230, 2-199
IP-53: ECs 126, 127, 129, 132, 133, 2-146	IP-78: ECs 11, 12, 21, 22, 2-205
IP-54: EC-131, 2-148	IP-79: ECs 13, 23, 2-211
IP-55: ECs 135, 136, 137, 138, 139, 2-149	IP-80: ECs 14, 24, 2-213
IP-61: ECs 140, 141, 2-152	IP-81: ECs 62, 63, 2-217
IP-64: EC-162, 2-155	IP-83: ECs 70, 71, 155, 2-222
IP-65: ECs 163, 164, 2-160	IP-85: ECs 72, 73, 156, 2-224
IP-66: EC-166, 2-164	IP-86: Air Fan not running, 2-228
IP-67: EC-167, 2-169	IP-87: Carousel Lock Arm not locked, 2-229
IP-68: EC-142, 2-172	isolation procedures, see specific IP number or
IP-69: EC-144, 2-176	name
IP-70: ECs 145, 146, 2-179	Isolation Procedures List, 2-2
IP-72: ECs 147, 148, 2-186	
I Index LCx [®] Analyzer Service Manual (Text P/N 4727	I - 32 78-102)
	,
Index Alpha Locator	Manual CD Main

Index Alpha Locator (Index page 1) Manual CD Main Screen

J, K

Keyboard Test (VP-42), 5-82 Keypad Enclosure, P/N, 3-24 Keypad to I/O Bd., Cable, P/N, 3-24

L

Lamp, MEIA, P/N, 3-14
Lamp Power Supply, RR-4.4, 4-48
Lamp Power Supply, Feedback Control, P/N, 3-14
Latch, P/N, 3-5
Left, VDE Cover, P/N, 3-29
Level Sense Adjust. (VP-12), 5-39
Level Sense Check (VP-11), 5-37
Level Sense hardware error (EC-99) (IP-22), 2-90
Level Sense not found XXXX (EC-52) (IP-22), 2-90

Level Sense out of range (EC-149) (IP-74), 2-192

Level Sense range error XXXX (EC-97) (IP-22), 2-90 Liquid Heater and Bracket Assy P/N, 3-11 RR-3.4, 4-28 Liquid Heater out of spec (EC-154) (IP-33), 2-111 Liquid Level Sense Board block diagram, A-9 board layout, A-37 connector pin callouts, A-38 RR-5.7, 4-63 signal pathway, A-36 Liquid level too high (EC-46) (IP-22), 2-90 liquid waste containing acid, disposal of, 1-26 LLS/Analog Cable Assy, P/N, 3-25 LLS Bd Assy, P/N, 3-17

LLS P/S/ Mtr. Dr./Analog, Cable Assy, P/N, 3-19

I Index LCx[®] Analyzer Service Manual (Text P/N 47278-102)

Index Alpha Locator (Index page 1)

I - 33

CD Main

Screen

Manual Contents LLS Voltage Delta Check (VP-9), 5-29 Main P/S 110 VAC to Mtr. Dr. Bd., Cable, P/N, 3-19 load list maintenance, preventive feature (ASTM® interface), C-8 procedure, 6-3 setup, C-8 report, 6-6 lock/unlock host interface, C-11 Manual Inactivation (VP-14), 5-44 manual overview cautions and warnings, 1-15 chapter descriptions, 1-9 M conventions, 1-11 M % Diff out of spec (EC-145) (IP-70), 2-179 intended audience, 1-8 Main Power Supply related documents, 1-8 P/Ns (PL-6), 3-19 warnings, 1-15 RR-6.13, 4-72 Matrix Count Check (VP-31), 5-75 verifying outputs (VP-1), 5-11 Matrix Detection (VP-32), 5-76 Main Power Supply to Card Cage, Cable, P/N, 3-19 MEIA Carousel Cal. (VP-30), 5-73 Main Power Supply w/Fan, P/N, 3-19 MEIA Carousel params. (File 3), B-3 Main Power Supply to Printer, Cable, P/N, 3-19

Index LCx[®] Analyzer Service Manual (Text P/N 47278-102)

Index Alpha Locator (Index page 1)

Manual CD Main Contents Screen

I - 34

MEIA Initialization Photo Cal. (VP-27), 5-63

MEIA PMT Check (VP-24), 5-58 MEIA Lamp P/N, 3-14 MEIA Stds placed incorrectly (EC-84) (IP-43), 2-119 RR-4.11, 4-54 MEIA Temp. Cal. (VP-29), 5-70 MEIA Temp. Check (VP-28), 5-68 MEIA Lamp Adjust. (VP-22), 5-57 MEIA Lamp out (EC-56) (IP-29), 2-105 Mem error XXXXXXXXX or UX (EC-118) (IP-51), MEIA Lamp Ref not initialized (EC-109) (IP-49), 2-144 2-139 Memory Board 8255 device failed (EC-139) (IP-55), MEIA Optical Standards Set, P/N, 3-4 2-149 MEIA optical system block diagram, A-56 Memory Board IO timed out (EC-136) (IP-55), 2-149 MEIA Optics Assy Memory Board timed out (EC-135) (IP-55), 2-149 MEIA optics signal pathway, A-55 Memory Module, System, P/N, 3-22 RR-4.1. 4-45 menus MEIA Optics to Analog Bd., Cable, P/N, 3-14 ASSAY, D-5 MEIA Performance Panel, P/N, 3-4 CALIBRATIONS, D-7 MEIA Performance Panel Run (VP-47), 5-89 CHECKS, D-8 MEIA Photo Cal. (VP-27A 5-66 HAND CONTROLS. D-9 MEIA Photo Check (VP-26), 5-60 MONITOR, D-7 MEIA Photodiode Check (VP-25), 5-59 overview, D-1 I - 35 Index LCx[®] Analyzer Service Manual (Text P/N 47278-102)

Index Alpha Locator (Index page 1) Manual CD Main Contents Screen

```
MTB LCR assay, B-44
menus (cont)
   PRIME, D-4
                                                      Multivalve Block
                                                         P/N, 3-17
   structure, D-2
   SYSTEM, D-11
                                                         RR-5.3, 4-61
                                                     Multivalve failed home (EC-14) (IP-80), 2-213
   system params., B-5
   TESTS, D-10
                                                      Multivalve missing steps (EC-24) (IP-80), 2-213
   UTILITY, D-12
MONITOR menu, D-7
Motor CTRL failed UX (EC-125) (IP-52), 2-145
                                                      Ν
Motor Driver, P/Ns (PL-8), 3-24
                                                      NMI Test failed (EC-116) (IP-51), 2-144
Motor Driver Board
                                                      No alarm (IP-2), 2-37
   block diagram, A-8
                                                      No disposables to run (EC-35) (IP-16), 2-68
   board layout, A-24
                                                      normal operation
   connector pin callouts, A-25
                                                         overview, 1-6
   P/N, 3-24
                                                         procedure, 2-21
   RR-8.5. 4-94
                                                     No Sample/Reagent found (EC-78) (IP-22), 2-90
Motor Driver cable disconnected (EC-1) (IP-5), 2-45
                                                                                                  I - 36
   Index
   LCx® Analyzer Service Manual (Text P/N 47278-102)
                                                                                             CD Main
 Index Alpha Locator
                                                                                Manual
```

Contents

Screen

(Index page 1)

```
NOVRAM
                                                      overview (cont)
   P/N, 3-22
                                                          assay params., B-43
   RR-7.9, 4-84
                                                          ASTM® interface, C-3
NOVRAM full (EC-32) (IP-13), 2-65
                                                          block diagrams, boards, pinouts, A-3
NRMSE too large (EC-163) (IP-65), 2-160
                                                          decontamination, 1-23
Nut Retainer, P/N, 3-17
                                                          disposal, 1-26
                                                          isolation procedures, 2-18
                                                          menu structure, D-2
                                                          normal operation, 1-6, 2-21
                                                          parts lists, 3-2
Open thermistor XXXXXXXXXXXXX (EC-229)
                                                          preventive maintenance, 6-2
   (IP-77), 2-199
                                                          removal/replacement procedures, 4-7
operating procedure, normal, 2-21
                                                          service manual. 1-8
Optics Assy, P/N, 3-14
                                                          system params., B-3
output voltages, specifications, 1-35
                                                          total service call, 6-2
Overlay, P/N, 3-24
                                                          troubleshooting, 2-19
overview
                                                          verification procedures, 5-8
   analyzer, 1-3
   analyzer params., B-3, B-43
```

I Index LCx[®] Analyzer Service Manual (Text P/N 47278-102)

Index Alpha Locator (Index page 1) Manual CD Main Contents Screen

Paper Feed Switch Assy, P/N, 3-19 Paper Hanger Rod, P/N, 3-19 Paper, Thermal Printer, P/N, 3-20 parameters assay, B-43 system, B-3 system, for ASTM® interface, 1-40, C-7 parts (replaced/defective), decontamination procedure, 5-107 parts lists (PLs), see specific PL number personal protective equipment, 1-22 Personality Module door, P/N, 3-5 pin hinge, P/N, 3-6 Photo params. (File 31), B-38	gnments TM® interface (COM 2 port), C-6 E and DTE configurations, 1-41 Appendix A overs, 3-5 ternal Covers, 3-8 ront View, 3-11 ptics, 3-14 ump, 3-17 rinter/Main Power Supply, 3-19 ard Cage, 3-22 nalog/Motor Driver/Display, 3-24 round Cable, 3-27 //DE Covers, 3-29 / Power Supply 3-14 4.5, 4-50
--	--

I Index LCx[®] Analyzer Service Manual (Text P/N 47278-102)

Index Alpha Locator (Index page 1) Manual CD Main Screen

```
PMT High Voltage out of range XXXXXX (EC-220)
                                                      preventive maintenance (PM) and total service call
   (IP-76), 2-197
                                                          procedure, 6-3
port, ASTM, C-5
                                                          report, 6-6
Power Cord, P/N, 3-19
                                                      PRFM assay, B-44
Power Supply Fan, P/N, 3-19
                                                      PRIME menu, D-4
Power Supply Fan Baffle, P/N, 3-19
                                                      Printer Assy
Power Supply (Lamp), RR-4.4, 4-48
                                                          P/N, 3-19
Power Supply (Main)
                                                          RR-6.3, 4-70
   board layout, A-11
                                                      printer cable, COM 1 port, 1-39
   connector pin callouts, A-12
                                                      printer door, P/N, 3-5
   RR-6.13, 4-72
                                                      printer door pin hinge, P/N, 3-6
   voltage pathway, A-10
                                                      Printer error (EC-37) (IP-18), 2-80
Power Supply (PMT HV), RR-4.5, 4-50
                                                      Printer/Main Power Supply, P/N (PL-6), 3-19
Power Supply, Card Cage Assy block diagram, A-7
                                                      printer, selecting, 1-39
Power Supply Check (VP-1), 5-11
                                                      Printer Test (VP-41), 5-81
precautions, universal, 1-21
                                                      Probe Assy
                                                          P/N, 3-11
                                                          RR-3.5, 4-31
                                                                                                   I - 39
   Index
   LCx® Analyzer Service Manual (Text P/N 47278-102)
 Index Alpha Locator
                                                                                 Manual
```

dex Alpha Locator (Index page 1)

Manual CD Main Screen

Probe Assy Thumb Nut, P/N, 3-12 probe decontamination procedure, 5-108 Raise Display Procedure (RR-8.1.1), 4-91 Probe Holder, P/N, 3-12 R boom failed home (EC-12) (IP-78), 2-205 Probe LLS Cable Clamp Assy, P/N, 3-12 R boom missing steps (EC-22) (IP-78), 2-205 Probe Positioning Pack Assy, P/N, 3-4 reaction chamber, decon. procedure, 5-107 Protective Wire Cover Read error XXXX (EC-166) (IP-66), 2-164 P/N, 3-8 reagent RR-2.7, 4-13 disposal, 1-26 Pump Assy handling, 1-27 diagram, A-47 heater block, see reagent heater block P/N, 3-17 pack, see reagent pack RR-5.1, 4-59 receiver, *see* reagent receiver/heater block Pump Cover, P/N, 3-17 shroud, see reagent shroud Reagent block temp. high (EC-73) (IP-85), 2-224 Reagent block temp. low (EC-72) (IP-85), 2-224 reagent heater block Quick Disconnect Fitting, P/N, 3-8 see Reagent Receiver/Heater Block

Index LCx[®] Analyzer Service Manual (Text P/N 47278-102)

_

I - 40

Index Alpha Locator (Index page 1) Manual CD Main Screen

Reagent Heater Block Adjust. (VP-21), 5-54 Remote temp. high (EC-71) (IP-83), 2-222 Reagent insufficient/empty XXXX (EC-47) (IP-22), Remote temp. low (EC-70) (IP-83), 2-222 Remote temp. out of range (EC-155) (IP-83), 2-222 2-90 removal and replacement procedures Reagent label read error (EC-41) (IP-20), 2-83 Reagent Pack not on module (EC-29) (IP-11), 2-61 see specific procedure or component by name Reagent Receiver Assy, P/N, 3-11 REPORT REDIR system param. 1.28, 1-39 Reagent Receiver/Heater Block retaining ring, P/N, 3-6 adjustment (VP-21), 5-54 Ribbon Cable, MEIA Optics to Analog Bd, P/N, 3-14 P/N, 3-11 RR-1.3: Enclosure Assv. 4-9 RR-3.2, 4-22 RR-2.3: Reagent Shroud, 4-12 Reagent Shroud RR-2.7: Protective Wire Cover (Interior Cover), P/N, 3-8 4-13 RR-2.3, 4-12 RR-2.8: Air Duct Cover. 4-14 Receiver (Carousel) Assy, RR-3.18, 4-41 RR-2.11: Amplification Vial Retainer, 4-16 Retainer Clip Assy, RR-3.19, 4-43 RR-3.1: Fan & Gasket Assy, 4-19 RR-3.2: Reagent Receiver/Heater Block, 4-22 Remote Air Thermistor Assy P/N, 3-14 RR-3.3: Carousel Motor Assy, 4-25 RR-3.4: Liquid Heater/Bracket Assy, 4-28 RR-4.14, 4-57 I - 41 Index LCx® Analyzer Service Manual (Text P/N 47278-102) Index Alpha Locator Manual CD Main

dex Alpha Locator (Index page 1) Manual Contents

Screen

RR-3.5: Probe Assy, 4-31 RR-6.3: Printer Assy, 4-70 RR-3.9: Boom Assy, 4-33 RR-6.13: Main Power Supply, 4-72 RR-3.13: Air Thermistor Assy, 4-36 RR-7.1/10: CPU/Digital I/O Boards, 4-75 RR-3.16: Air Heater Assy, 4-38 RR-7.4: RS-232 Cable/Bracket Assy, 4-79 RR-3.18: Carousel Receiver Assy, 4-41 RR-7.7: Card Cage Assy, 4-81 RR-3.19: Retainer Clip Assy, 4-43 RR-7.9: NOVRAM Replacement, 4-84 RR-4.1: MEIA Optics Assy, 4-45 RR-8.0: Tilt Back Card Cage, 4-87 RR-4.4: Lamp Power Supply, 4-48 RR-8.1: Display Assy (Touchpad), 4-89 RR-4.5: PMT HV Power Supply, 4-50 RR-8.1.1: Raise Display Procedure, 4-91 RR-4.6: Carousel Lock Sensor Cable Assy, 4-52 RR-8.3: Analog Board, 4-92 RR-4.11: MEIA Lamp, 4-54 RR-8.5: Motor Driver Board, 4-94 RR-4.14: Remote Air Thermistor Assy, 4-57 RS-232 Bracket Centering (VP-55), 5-98 RS-232 Cable/Bracket Assv RR-5.1: Pump Assy, 4-59 RR-5.3: Multivalve Block. 4-61 P/N, 3-22 RR-5.7: Liquid Level Sense Board, 4-63 RR-7.4, 4-79 RR-5.8: Buffer Sensor Cable. 4-65 RS-232 COM Port Test (VP-44), 5-84 RR-5.10/12: Syringes, 4-67 RS-232 interface specifications, 1-39 Index LCx[®] Analyzer Service Manual (Text P/N 47278-102)

I - 42

Index Alpha Locator (Index page 1)

Manual CD Main Contents Screen

	Sample syringe P/N, 3-17 RR-5.10/12, 4-67 Sample Syringe failed home (EC-16) (IP-9), 2-51 Sample Syringe missing steps (EC-26) (IP-9), 2-51 screws, P/Ns, see specific PL lists selecting a printer, 1-39 sensor AVR, 5-45, 5-115 boom, 5-23 buffer, 5-45 carousel home, 5-50 carousel lock, 5-78 door, 5-53 door, option active (EC-98) (IP-21), 2-88 inactivation diluent, 5-45 syringe, 5-47	sensor (cont) system diluent, 5-45 valve, 5-49 Sensor Bracket Assy, P/N, 3-14 Sensor Bracket Cable, P/N, 3-25 Sensor, Door, Assy, P/N, 3-17 Sensor with Buffer Tray Assy, P/N, 3-17 Serial Number Label, P/N, 3-5 service call, total procedure, 6-3 report, 6-6 Shipping Container Assy, P/N, 3-4 Shorted thermistor XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
I	Index LCx [®] Analyzer Service Manual (Text P/N 47278-10	I - 43

LCX Analyzer Service Manual (Text P/N 47276-102)

Index Alpha Locator (Index page 1)

Manual Contents

CD Main Screen

Snap Slide Guide, P/N, 3-5 subassemblies, decontamination procedure, 1-25, 5-109 spacers Card Cage, P/N, 3-22 Superuser Circuit Bd., P/N, 3-25 access code numbers, 5-45, B-60 Fan Filter, P/N, 3-12 (VP-45), 5-85 specifications, analyzer Superuser parameter access dimensions, physical, 1-32 assay params., B-45 environment, 1-32 system params., B-4 humidity, 1-32 supplemental tools/supplies, P/Ns, 3-4 location, 1-32 syringes specifications, RS-232 interface, 1-39 P/N, 3-17 specimens, disposal, 1-26 RR-5.10/5.12. 4-67 spooler buffer, ASTM®, C-12 Syringe Sensor Check (VP-16), 5-47 spooler capacity warning, C-12 system block diagrams SPOOLER WARN, system param. 1.20, 1-40 general system overview, A-6 standards, MEIA Optical, P/N, 3-4 Power Supply, Card Cage Assy, A-7 Static Precision out of spec (EC-147) (IP-72), 2-186 Motor Driver Board. A-8 status messages, interpreting, 2-23 Analog and Liquid Level Sense boards, A-9 Index LCx[®] Analyzer Service Manual (Text P/N 47278-102)

Index Alpha Locator (Index page 1)

Manual Contents

CD Main Screen

System Cartridge Pack Assy, P/N, 3-4 System parameters quick ref. charts (cont) System File Reloading (VP-53), 5-93 File 2: System params., B-18 System Log, clearing (VP-63), 5-112 File 3: MEIA Carousel params., B-22 System Memory Module, P/N, 3-22 Files 4-29: Boom locations params., B-26 SYSTEM menu, D-11 File 30: Temperature params., B-34 System Module missing (EC-126) (IP-53), 2-146 File 31: Photo params., B-38 system params. (File 2), B-18 system parameters list, B-6 menu, B-5 Tape, Door Sensor Reflective, P/N, 3-5 overview, B-3 Temp. Probe Adapter Assy, P/N, 3-4 parameter access, B-4 temperature control, internal, 1-33 quick reference charts, B-14 Temperature params. (File 30), B-34 System parameters list, B-6 tests System parameters menu, B-5 Display Test (VP-43), 5-83 System parameters quick ref. charts Keyboard Test (VP-42), 5-82 overview, B-13 Printer Test (VP-41), 5-81 File 1: Configuration, B-14 RS-232 COM Port Test (VP-44), 5-84 I - 45 Index LCx® Analyzer Service Manual (Text P/N 47278-102) Index Alpha Locator

(Index page 1)

Manual Contents CD Main Screen

TESTS menu, D-10 total service call Thermal Printer Paper, P/N, 3-20 procedure, 6-3 thermal protection for analyzer, 1-33 report, 6-6 Thermistor Assy, Air, P/N, 3-11 Touchpad Assy (Display), RR-8.1, 4-89 Thermometer, Digital, P/N, 3-4 troubleshooting Tilt Back Card Cage procedure (RR-8.0), 4-87 ASTM® error codes, C-13 Time/Date reset (EC-8) (IP-7), 2-49 introduction, 2-19 Time expired for entering Temp (EC-110) (IP-50), troubleshooting ASTM® errors 2-141 ASTM®-specific ECs, C-15 error logs, C-13 Tool Adapt-A-Case, P/N, 3-4 tips, C-14 carousel alignment tool, 5-51 Tubing Assy, Buffer Inlet, P/N, 3-17 Hex Key 9/64", P/N, 3-4 Tubing, Interconnect, P/N, 3-17 loopback, 5-84 Tubing, Interconnect Probe, P/N, 3-11 supplemental tools and supplies, P/Ns, 3-4 Tubing, Interconnect, w/ Sample Syringe, P/N, 3-17 Tubing, Waste, Assy, P/N, 3-8 I - 46

I Index LCx[®] Analyzer Service Manual (Text P/N 47278-102)

Index Alpha Locator (Index page 1) Manual CD Main Contents Screen

Uuniversal precautions, 1-21 Unknown NMI...Contact CSC (EC-138) (IP-55), 2-149 unlock/lock host interface, C-11 using this manual, 1-8 UTILITY menu, D-12

٧

Valve Sensor Check (VP-17), 5-49
Vials, Amplification, P/N, 3-4
VDE Covers, P/N (PL-10), 3-29
ventilation specification, 1-32
verification procedures, *see* specific procedure by name

VP-1: Power Supply Check, 5-11 VP-2: Enclosure Adjust., 5-12 VP-3: Card Cage Adjust., 5-14 VP-4: Bar Code Check, 5-16 VP-5: Bar Code Adjust., 5-19 VP-6: Boom and Wash Station Screw Lube., 5-21 VP-7: Boom Check, 5-23 VP-8: Boom Cal., 5-25 VP-9: LLS Voltage Delta Check, 5-29 VP-11: Level Sense Check, 5-37 VP-12: Level Sense Adjust., 5-39 VP-13: Dispense Check, 5-42 VP-14: Manual Inactivation. 5-44 VP-15: Buffer Sensor Check. 5-45 VP-16: Syringe Sensor Check, 5-47 VP-17: Valve Sensor Check. 5-49

VP-18: Carousel Home Sensor Check. 5-50

I Index LCx[®] Analyzer Service Manual (Text P/N 47278-102)

Index Alpha Locator (Index page 1)

Manual CD Main Screen

VP-19: Carousel Motor and Gear Adjust., 5-51	VP-43: Display Test, 5-83
VP-20: Door Sensor Check, 5-53	VP-44: RS-232 COM Port Test, 5-84
VP-21: Reagent Heater Block Adjust., 5-54	VP-45: Superuser, 5-85
VP-22: MEIA Lamp Adjust., 5-57	VP-46: Buffer Run, 5-87
VP-24: MEIA PMT Check, 5-58	VP-47: MEIA Performance Panel Run, 5-89
VP-25: MEIA Photodiode Check, 5-59	VP-53: System File Reloading, 5-93
VP-26: MEIA Photo Check, 5-60	VP-55: RS-232 Bracket Centering, 5-98
VP-27: MEIA Initialization Photo Cal., 5-63	VP-56: Carousel Bar Code Offset Adjust, 5-99
VP-27A: MEIA Photo Cal., 5-66	VP-57: Air Purge, 5-101
VP-28: MEIA Temp. Check, 5-68	VP-58: HV Linearity Check, 5-103
VP-29: MEIA Temp. Cal., 5-70	VP-59: Fluorescence Background Check, 5-105
VP-30: MEIA Carousel Cal., 5-73	VP-60: Decontamination, 5-107
VP-31: Matrix Count Check, 5-75	VP-62: Factory Set, 5-110
VP-32: Matrix Detection, 5-76	VP-63: Clearing System, ASTM®, and CSC Logs,
VP-34: Carousel Lock Sensor Adjust., 5-78	5-112
VP-41: Printer Test, 5-81	VP-64: AVR Alignment, 5-113
VP-42: Keyboard Test, 5-82	VP-65: AVR Sensor Check, 5-115
I Index LCx [®] Analyzer Service Manual (Text P/N 47278-	I - 48

Index Alpha Locator (Index page 1)

Manual **CD** Main

Screen

Contents

W

warnings, see cautions and warnings Wash Station, P/N, 3-8 Wash Station overflow (EC-45) (IP-22), 2-90 washers, P/Ns, see specific PL lists Waste Bottle, P/N, 3-8 Waste Cap, P/N, 3-8 waste container, decontamination, 1-24 Waste Disposal Fitting, P/N, 3-6, 3-8 Waste Tubing, P/N, 3-8

X, **Y**, **Z**

Z boom failed home (EC-11) (IP-78), 2-205 Z boom missing steps (EC-22) (IP-78), 2-205

I Index LCx[®] Analyzer Service Manual (Text P/N 47278-102)

Index Alpha Locator (Index page 1)

Manual CD Main Contents Screen