
IP-76 Error code 220 XXXXXX (pg 1 of 2)


EC-220: PMT High Voltage out of range XXXXXX



2 Troubleshooting IP-76: Error code 220 2 - 197 LCx[®] Analyzer Service Manual (Text P/N 47278-102)

Chapter	Manual	CD Main	Index
Contents	Contents	Screen	

IP-76 (pg 2 of 2)



2 Troubleshooting IP-76: Error code 220 2 - 198 LCx® Analyzer Service Manual (Text P/N 47278-102)

Chapter Manual CD Main Index Contents Contents Screen