SUPPLEMENTAL TOOLS/SUPPLIES (pg 1 of 1)

Part No.	Description		
4A34-01	Adapter, Assy. Temp Probe		
8373-01	Assy, Carousel Pack		
8384-03	Assy, System Cartridge Pack		
8392-01	Blank Cells		
3-31320-01	Cap, Drilled		
LN 9A42-51	Carousel ID Bar Code		
9518-11	Carousel Master Packing		
8387-01	Digital Thermometer		
3-31290-01	Fixture, Carousel Motor Adjustment		
14233-101	Grease, Synthetic, .5 oz tube		
4A91-01	LCx® Air Deflector		

Part No.	Description		
LN 2C39-01	LCx® Amplification Vials/empty		
3-79200-01	LCx® AVR Postioning Tool		
LN 9A42-18	MEIA Optical Standards Set		
LN 6A20-01	MEIA Performance Panel		
LN 9A42-21	Probe Positioning Pack Assy.		
14482-136	Screw, 4-40 x 0.500 PHP		
14557-037	Screw, 6-32 x 0.187		
14451-204	Screw, 8-32 x 0.125		
4690-101	Shipping Container Assy.		
14207-050	Tool, Adapt-A-Case		
14205-022	Tool, Hex Key 9/64"		

3 Parts Lists LCx[®] Analyzer Service Manual (Text P/N 47278-102)

Chapter	Manual	CD Main	Index
Contents	Contents	Screen	

Supplemental Tools and Supplies

3 - 4